Frequently Asked Questions

<u>Internet</u>	Camera Feed	Robot Movement	Battery Charging	<u>Laptop</u>	Power On/Off

Internet


The WiFi network is not showing up.

1. Unplug the portable wireless router.



Aerial view of wireless router

- 2. Plug the router back in, and wait for a few minutes for it to start up.
- 3. Check the list of available WiFi connections again.



Not sure what to label this

Camera Feed

The camera feed is not showing up or is frozen.

- 1. Close Firefox and the terminal.
- 2. Unplug the camera from the robot laptop and plug it back in.




Laptop, camera, and robot set up

3. Open a terminal again (Ctrl+Alt+T) and open Firefox

Robot Movement

The robot won't move.

- 1. Make sure the laptop can connect to the robot laptop.
- 2. Make sure camera is not frozen.
- 3. Close the terminal and Firefox.
- 4. Make sure the base is powered on.
- 5. Unplug the cord connecting the robot to the robot laptop and then plug it back in.



Laptop, camera, and robot set up

6. Open a terminal (Ctrl+Alt+T) and Firefox again.

The robot won't stop moving.

- 1. Turn off the robot.
- 2. Shut down both laptops.

Battery Charging

How do I tell if the battery is low?

1. When the light on the base of the robot turns yellow, connect robot to a charger.



Low battery robot

2. Plug charger in



Where to plug in robot charger

Laptop

The laptop cannot connect to the robot.

- 1. Make sure the robot laptop is powered on.
- 2. Check that the WiFi connection on the control laptop and the robot laptop are the same network.

[Picture of what a connected laptop and robot look like. Is there a symbol? How can you tell?]

Power On/Off

The robot will not turn on.

- 1. Make sure this is actually the problem.
 - a. When you turn the base on, it should make a series of beeps.
 - b. The light on the base should also turn on.



Charged robot powered on

- 2. Plug in the robot's charger.
- 3. Allow it to charge for a few minutes, then try turning it on again.
- 4. Allow the robot to charge at least until the light on the base turns green.

How do I turn the robot off?

1. Flip the switch on the base. There should be no light on after.



Robot on/off switch

ĺ						I
	<u>Internet</u>	Camera Feed	Robot Movement	Battery Charging	<u>Laptop</u>	Power On/Off