




B530-A


B780-A




R670-A




R780-A




Blue_LaserDelay




Red_LaserDelay




FSC-A




FSC-H




FSC-W




SSC-A




SSC-H




SSC-W




B530-A_Gain




B585-A_Gain




B695-A_Gain




B780-A_Gain




R670-A_Gain




R780-A_Gain




FSC-A_Gain




SSC-A_Gain






Blue_LaserDelay




Red_LaserDelay







B585-A-% rCV




B695-A-% rCV




B780-A-% rCV




R670-A-% rCV




R780-A-% rCV




FSC-A-% rCV




FSC-H-% rCV



FSC-W-% rCV



SSC-A-% rCV



SSC-H-% rCV

