







B530-A**B585-A****B695-A**









R670-A




R780-A









SSC-H




SSC-W




B530-A_Gain




B585-A_Gain




B695-A_Gain




B780-A_Gain




R670-A_Gain




R780-A_Gain




FSC-A_Gain




SSC-A_Gain




Blue_LaserDelay




Red_LaserDelay




Blue_AreaScalingFactor







Red_AreaScalingFactor




B530-A-% rCV







R670-A-% rCV




R780-A-% rCV




FSC-A-% rCV



FSC-H-% rCV



FSC-W-% rCV



SSC-A-% rCV

