



**B530-A**


B780-A



R670-A



R780-A




### Blue\_LaserDelay




### Red\_LaserDelay




### FSC-A




FSC-H



FSC-W



SSC-A



### SSC-H



### SSC-W



### B530-A\_Gain



### B585-A\_Gain




### B695-A\_Gain




### B780-A\_Gain




### R670-A\_Gain



### R780-A\_Gain




### FSC-A\_Gain




### SSC-A\_Gain




### Blue\_LaserDelay




### Red\_LaserDelay




### Blue\_AreaScalingFactor




### Red\_AreaScalingFactor




### B530-A-% rCV




### B585-A-% rCV




### B695-A-% rCV




### B780-A-% rCV




R670-A-% rCV



R780-A-% rCV



FSC-A-% rCV



FSC-H-% rCV

