








**B530-A****B585-A****B695-A**

B780-A







FSC-H




FSC-W




SSC-A




## SSC-H




## SSC-W




## B530-A\_Gain




### B585–A\_Gain




### B695–A\_Gain




### B780–A\_Gain




### R670-A\_Gain




### R780-A\_Gain




### FSC-A\_Gain




### SSC-A\_Gain




### Blue\_LaserDelay




### Red\_LaserDelay




### Blue\_AreaScalingFactor




### Red\_AreaScalingFactor




### B530-A-% rCV




### B585-A-% rCV




### B695-A-% rCV




### B780-A-% rCV




### R670-A-% rCV




### R780-A-% rCV




### FSC-A-% rCV




### FSC-H-% rCV




### FSC-W-% rCV



### SSC-A-% rCV



### SSC-H-% rCV



### SSC-W-% rCV

