




B530-A




B585-A




B695-A




B780-A




R670-A




R780-A




Blue\_LaserDelay




Red\_LaserDelay




FSC-A




### FSC-H




### FSC-W




### SSC-A




SSC-H




SSC-W




B530-A\_Gain




B585-A\_Gain




B695-A\_Gain




B780-A\_Gain




R670-A\_Gain




R780-A\_Gain




FSC-A\_Gain




SSC-A\_Gain




Blue\_LaserDelay




Red\_LaserDelay




# Blue\_AreaScalingFactor




# Red\_AreaScalingFactor




# B530-A-% rCV




B585-A-% rCV




B695-A-% rCV




B780-A-% rCV




R670-A-% rCV




R780-A-% rCV




FSC-A-% rCV




FSC-H-% rCV




FSC-W-% rCV



SSC-A-% rCV



SSC-H-% rCV



SSC-W-% rCV

