

-
-
-
-
-

Chapter 6

Change Management



Change Management Introduction

To ensure a controlled and ordered production environment, it is advisable to use change management.

If a change needs to be made to some aspect of the production system, then a change must be requested. This change request can include further details about the changes, called change details. Each of the change details, and the change request itself, must be authorised by someone before the work can begin on the changes. If there are other people who want to know about the changes, they can be notified.

Several change requests can be grouped together as a project. You can configure the default authorisations and notifications for the changes requests and change details associated with the project.



Note: It is advisable for appropriate procedures to be implemented within the working environment, so that change management can be recorded on the production system.

At each stage of the change management process, the status of the change request and change details differs, as follows:

00 - Requested.

20 - Referred.

30 - Submitted For Authorisation.

35 - Being Authorised.

40 - Authorised.

50 - Active.

60 - Held.

70 - Rejected.

80 - Cancelled.

90 - Completed.

You can carry out the following change management tasks using the Change Management menu:

- Add and edit change requests.
- Add and edit authorisations for the change request and change details.
- Add and edit notifications for the change request and change details.
- Add and edit projects.
- Add and edit parameters.
- Display information about change requests, projects and parameters.
- Print information about change requests, authorisations and notifications.

There are several system parameters that need to be set up via Maintain Parameters. These include the following:-

- AUDT Audit Type. This single character parameter determines whether change control is set up . No Control (0 or blank) and Change Controlled (2).
- CMRQ Change Order Request Type codes. This two character parameter allows you to specify the nature of the change order request. Work Order Concession (10), New Item (11), Amend Item (12), Delete Item (13), New Route Header (21), Amend Route (22), Delete Entire Route (23), Amend route Header (24), Copy Route (25), New Operation (31), Amend Operation (32), Delete Operation (33), New Input (41), Amend Input (42), Delete Input (43), New Output (51), Amend Output (52), Delete Output (53) and Mass Item Replace (62). The maximum number of codes is 19.
- CMRS Change Order Status codes. This two character parameter defines the status of the change request at each stage of its cycle. The values are Requested (00), Referred (20), Submitted (30), Being Authorised (35), authorised (40), Active (50), Held (60), Rejected (70), Cancelled (80) and Completed (90). The maximum number of codes is 10.
- RCTL Route Classification. This is a two character parameter code depicting whether or not there should be change control applied to this route, and if so what type. Each code can have a value consisting of two characters. The first being either 0 or blank and the second being 0, blank or 2. The second character position reflects the change control policy where blank or 0 means no change control and 2 means that change control is required. For example an RCTL parameter code NC could have a value of 00 which means that there should be no change control, whereas parameter code CC might have a value of 02 indicating change control is required. The maximum number of codes is 99.

Register Change Requests



1/PDR



Select Register Change Requests on the menu to display the Change Request Maintenance Selection screen.

Change Request Maintenance Selection Screen



Select Register Change Requests on the menu to display the Change Request Maintenance Selection screen.

CH690	Z1 - UK Demonstration Company	USER GBJBAEPB	24/02/98 16:32:11
Change Request Maintenance Selection			
Request Number.?. _			
Or from outstanding authorisation. _ (1=Yes)			
Or from outstanding notifications _ (1=Yes)			
Requested _ (1=Yes)			
Submitted for author _ (1=Yes)			
Authorised _ (1=Yes)			
Limit to User... _			
F3=Exit F4=Prompt F8=Continue F10=New request F12=Reselect			
8-51	SP	MW	KS CL IM DM II STUD140 KB PET165S1

Fields:

Request Number

You can enter the code of a change request you want to edit. If you enter a valid number and select **F8=Continue**, other entries in this screen are ignored and the Change Request Maintenance screen is displayed.

If you do not know the change request code, you can enter ?, and select **F4=Prompt** to display a list of existing numbers.

Alternatively, select **F10=New Request** to enter a new change request.

Or From Outstanding Authorisation

If there is no entry in the Request Number field, you can decide whether or not to select a change request waiting for authorisation. You can enter one of the following:

0 - No. You do not want to select a change request waiting for authorisation.

1 - Yes. You want to select a change request waiting for authorisation. In this case, when you select **F8=Continue**, the Change Request Selection window is displayed.



Note: The Or From Outstanding Authorisation and Or From Outstanding Notifications fields are mutually exclusive. This means that if you enter 1 in one field, you must enter 0 in the other.

Or From Outstanding Notifications

If there is no entry in the Select By Request Number field, you can decide whether or not to select a change request with notification. You can enter one of the following:

0 - No. You do not want to select a change request with notification.

1 - Yes. You want to select a change request with notification. In this case, when you select **F8=Continue**, the Change Request Selection window is displayed.



Note: The Or From Outstanding Authorisation and Or From Outstanding Notifications fields are mutually exclusive. This means that if you enter 1 in one field, you must enter 0 in the other.

Requested

If you enter 1 in the Or From Outstanding Notification field, you must enter 1 in at least one of the three fields below it: Requested; Pending; Applied.

You can decide whether or not to select a change request which has a requested notification. You can enter one of the following:

0 - No. You do not want to select a change request with requested notification.

1 - Yes. You want to select a change request with requested notification. In this case, when you select **F8=Continue**, the Change Request Selection window is displayed.

Submitted for author

If you enter 1 in the Or From Outstanding Notification field, you must enter 1 in at least one of the three fields below it: Requested; Submitted for author; Authorised.

You can decide whether or not to select a change request which has been submitted for authorisation. Enter one of the following:

0 - No. You do not want to select a change request which has been submitted for authorisation.

1 - Yes. You want to select a change request which has been submitted for authorisation. In this case, when you select **F8=Continue**, the Change Request Selection window is displayed.

Authorised

If you enter 1 in the Or From Outstanding Notification field, you must enter 1 in at least one of the three fields below it: Requested; Submitted for author; Authorised

You can decide whether or not to select a change request which has an applied notification. Enter one of the following:

0 - No. You do not want to select a change request with an applied notification.

1 - Yes. You want to select a change request with an applied notification. In this case, when you select **F8=Continue**, the Change Request Selection window is displayed.

Limit To User

Any authorisation or notification constraints selected above can be further constrained to those change requests addressed to a specific user. To do this, enter the name of the user in this field.

-  Select **F8=Continue** or press **Enter**.
-  If you enter a valid number in the Select By Request Number field in the Change Request Maintenance Selection screen, other entries in this screen are ignored and the Change Request Maintenance screen is displayed for the selected change request.
-  If you enter valid entries in the other fields on the Change Request Maintenance Selection screen, a constrained list of change requests is displayed in the Change Request Selection window.

Functions:

F10

New Request. You can add a new request to the system. To do this, first select this function. The Change Request Maintenance screen is displayed.

Change Request Selection Window

The Change Request Selection window displays a list of change requests selected in the Change Request Maintenance Selection screen.



If you enter valid entries in the other fields on the Change Request Maintenance Selection screen, a constrained list of change requests is displayed in the Change Request Selection window.

S	Project	Request	Status	Origin of request
-		2	00	NUMBER
-		4	00	CHANGE
-		11	00	TEST
-	KEIPER1	15	00	NICK
-		16	00	ROB CLEAR
-		1	00	NICK

F12=Previous
F3=Exit F4=Prompt F8=Continue F10=New request F12=Reselect

8-36 SA MW KS CL IM DM II STU0140 KB PET165S1

Fields:

S

1 - Select. You can select the change request you want to edit by entering 1 in this field.



Note: You can only edit a change request with the appropriate status, that is, 00, 20 or 30.

Project

The relevant project for each change request is displayed here.

Request

This field displays the number of each change request.

Status

This field displays a written description of the status of each change request.

Origin Of Request

This field displays the name of the user who made each change request.



Press **Enter** to display the Change Request Maintenance screen for the selected change

requests.

Change Request Maintenance Screen

You can edit a selected change request.



If you enter a valid number in the Select By Request Number field in the Change Request Maintenance Selection screen, other entries in this screen are ignored and the Change Request Maintenance screen is displayed for the selected change request.

CH060	PB - Manufacturing test company	USER GBJBAEPB	27/02/98 09:47:56
Change Request Maintenance			
Change request.....	2	Request Date.....	26/02/98
Project.....?	ALPHA	PROJECT ALPHA	
Status.....?	00	Requested	
Requested By.....	PB		
Changes Required			
Target dates	Authorise by... 26/02/98	Action by... 26/02/98	
	Authorised by..		
F3=Exit F4=Prompt F8=Update F12=Previous			
F18=Additional Details F20=Request Details F21=Text			
6-71	SA	MW	KS CL IM DM II MARVIN KB PET165S1

Fields:

Change Request

If you are adding the change request, then ? is displayed in this field and the change request is allocated a number when **F8=Update** is selected. Alternatively, the change request number you are editing is displayed here.

Project

You can enter a project name in this field. The project description is automatically displayed beside the project name and is for your information only.

Status

You can enter the status number in this field. The status description is automatically displayed beside the status number and is for your information only.

Requested By

You can enter the name of the user who requested the change.

Changes Required

Enter a description of the changes being made.

Authorised By

Enter the date that authorisation is to be recorded against. The default value is today's date.

Action By

Enter the date by which the change is to be carried out.

Functions:

F18

Additional Details. Use this to display a window for entering additional change request header information.

F20

Request Details. If change details exist for this change request, you can display them. In this case, when you select this function, the Select Change Detail window is displayed.

If change details do not exist for this change request, you can add them. In this case, when you select this function, the Change Request Maintenance Detail screen is displayed.

F21

Text. If you need to enter request, action or review text information then this function displays the Text Selection window.



Select **F18=Additional Details** on the Change Request Maintenance screen to display the Additional Details window.



Select **F20=Request Details** on the Change Request Maintenance screen to display the Select Change Detail window.



Select **F21=Text** on the Change Request Maintenance screen to display the Text Selection window.



Select **F8=Update**. The edits on the selected change request are saved on the system.

Additional Details Selection Window (F18)



Select **F18=Additional Details** on the Change Request Maintenance screen to display the Additional Details selection window.

The screenshot shows the 'Change Request Maintenance' screen. At the top, it displays 'CH060', 'Z1 - UK Demonstration Company', 'USER GBUJBAEPB', and the date/time '25/02/98 15:00:15'. The main area contains fields for 'Change request..... 16', 'Request Date..... 18/12/97', 'Project.....?', 'Status.....? 00 Requested', 'Requested By..... BOB_CLEAL', and 'Changes Required'. Below these are 'Target dates' and 'Authorise by.. Authorised by..'. There are also fields for 'Express Change Request', 'Change type...?', 'Item.....?', and 'Route.....?'. An 'Additional details' window is open over the bottom right, showing fields for 'Department.....', 'Change Reason....?', 'Stock Review.....?', 'Estimated Cost.....', and 'Estimated Benefit..'. At the bottom of this window are the options 'F4=Prompt', 'F12=Previous', and 'Enter=Continue'. The bottom of the main screen has a list of function keys: 'F3=Exit F4=Prompt F8=Update F12=Previous F13=Authorisations F14=Notifications F18=Additional Details F20=Request Details F21=Text F22=Revision Details'. At the very bottom is a status bar with '13-55', 'SA', 'MW', 'KS', 'CL', 'IM', 'DM', 'II', 'MARVIN', 'KB', and 'PET165S1'.

Fields:

Department

Enter the name of the department which carries out the change request.

Change Reason

You can enter the change reason code in this field. When you enter a code, a text description is automatically displayed.

Stock Review

This field is reserved for future use.

Estimated Cost

Enter the estimated amount of money, if any, that is spent by carrying out the change request.

Estimated Benefit

Enter the estimated amount of money, if any, that is saved by carrying out the change request.



Select **Enter=Continue** to save the changes.

Select Change Detail Window (F20)



Select **F20=Request Details** on the Change Request Maintenance screen to display the Select Change Detail window.

```

CH060          PB - Manufacturing test company  USER GBUBAEPB  26/02/98
                                         08:57:29

Change Request Maintenance

Select Change Detail
Change Request..... 2          Status.. Requested
Project ..... ALPHA    PROJECT ALPHA
S Line Type Item      Rte Opsq Iseq Oseq Structure Item  New Rev. Sts
█ 001  12 PB001.1                                Rev1    00

1-Select
F10=Add Request Detail  F12=Previous

F3=Exit F4=Prompt F8=Update F12=Previous
F18=Additional Details  F20=Request Details  F21=Text

9-4  SA  MW  KS  CL  IM  DM  II  MARVIN  KB  PET165S1
  
```

Fields:

S

1 - Select. Use this field to choose which change request detail line you wish to maintain.

Functions:

F10

Add Request. Select this function to add a new change request detail line.



Select 1 or **F10=Add Request** to display the Change Request Maintenance Detail screen.

Change Request Maintenance Detail Screen (F20)



Select 1 or **F10=Add Request** on the Select Change Detail window to display the Change Request Maintenance Detail screen.

CH070	PB - Manufacturing test company	User GBJBAEPB	2/03/98 10:54:14
Change Request Maintenance - Detail			
Change Request.....	2	Request Status....	Requested
Project.....	ALPHA	PROJECT ALPHA	
Detail Number.....	001	First change	
Change Type.....?	12	Amend Item	
Item.....?	PB001..1	Current Revision..	Rev1
Route.....?		New Revision	Rev1 First change
Operation..			
Input.....		Output.....	
Structure Item...?			
Use at Revision...			
Allowed Changes....	0001	Changes Actioned...	0000
Changes Required			
F3=Exit F4=Prompt F8=Update F12=Previous F13=Authorisation F14=Notifications F18=Additional Details F21=Text F22=Revision Details			
8-26	SA	MW	KS CL IM DM II MARVIN KB PET165S1

Fields:

Change Request

This field contains the allocated change request number. It is for your information only and cannot be amended.

Request Status

This field displays the status of the change request and is for your information only.

Project

This field contains the project associated with the change request and is displayed for your information only. It cannot be amended.

Detail Number

A change detail number is automatically generated. This field is displayed for your information only and cannot be amended.

Status

Contains the status of the change request and is for your information only.

Change Type

If a change type is defined on the Change Request Maintenance screen, it is displayed in this field. Otherwise, you must enter an existing change type in this field.

A text description is automatically displayed beside the change type and is for your information only.

Item

An existing item can be entered in this field.

Route

You can enter the route in this field.

Operation

You can enter the operation in this field.

Effective From/To

Selects the effectivity range to be applied to the operation.

Input

Use to select which input item to apply the change request to.

Output

Use to select which output item to apply the change request to.

Structure Item

Input either the input item or output item depending on what was entered in the last two fields.

Effective From/To

Selects the effectivity range applied to the input or output structure item.

Use at Revision

This field is reserved for future use.

Allowed Changes

Keeps a total of the number of change requests allowed.



Select **F8=Update** to add the change detail to the system.

If you select **F3=Exit** or **F12=Previous**, the change detail is not added to the system and the change detail number is used for the next change detail to be added to the system.

Functions:

F13

Authorisation. Select this function to display the Maintain Authorisation List window for the selected change request.

F14

Notifications. Select this function to display the Maintain Notification List window for the selected change request.

F18

Additional Details. Use this to display a window for entering additional detail line information.

F21

Text. Select this to bring up a window to update Request Text and Action Text.

Maintain Authorisation List Window (F13)



Select **F13=Authorisation** on the Change Request Maintenance screen to display the Maintain Authorisation List window.

```

CH070      PB - Manufacturing test company      User GBUBAEPB      27/02/98
                                           11:14:37

Change Request Maintenance - Detail

Change Request.....      2      Request Status.... Requested

P
D      Project ALPHA      Change request      2 Detail 001
C      Line  Dep      UserID      Name
I      001      █      GBUBAEPB      PB
R      002      _____
O      003      _____
I      004      _____
S      005      _____
U      006      _____
A      007      _____
C      008      _____
-      009      _____
-      010      _____
-
-      F12=Previous F8=Update
F3=Exit F4=Prompt F8=Update F12=Previous F13=Authorisation F14=Notifications
F18=Additional Details F21=Text F22=Revision Details

10-10      SA      MW      KS      CL      IM      DM      II      MARVIN      KB      PET165S1
  
```

Fields:

Dep

Enter the authorising department for the change request.

UserID

Enter the userID's of those who need to authorise the change request.

Name

Enter the names of those who need to authorise the change request.



Select **F8=Update** to validate and update the authorisation list.

Maintain Notification List Window (F14)



Select **F14=Notifications** on the Change Request Maintenance screen to display the Maintain Notification List window.

CH060 Z1 - UK Demonstration Company USER GBUJBAEPB 25/02/98 14:52:08

Change Request Maintenance

Change request..... 16 Request Date..... 18/12/97

Maintain Notification List			
UserID	Name	Change request	Request Pending Applied
001		16	- - -
002			- - -
003			- - -
004			- - -
005			- - -
006			- - -
007			- - -
008			- - -
009			- - -
010			- - -

F12=Previous F8=Update

F3=Exit F4=Prompt F8=Update F12=Previous F13=Authorisations F14=Notifications
F18=Additional Details F20=Request Details F21=Text F22=Revision Details

10-8 SA MW KS CL IM DM II MARVIN KB PET165S1

Fields:

UserID

Enter the userID's of those who are to be notified of the change request.

Name

Enter the names of those who are to be notified of the change request.



Select **F8=Update** to validate and update the notification list.

Text Selection Window (F21)

- ➔ Select **F21=Text** on the Change Request Maintenance screen to bring up the Text Selection window.

The screenshot shows the 'Change Request Maintenance' screen. At the top, it displays 'CH060', 'PB - Manufacturing test company', 'USER GBUJBAEPB', and the date '2/03/98' with time '11:06:21'. The screen contains several fields: 'Change request..... 2', 'Request Date..... 26/02/98', 'Project.....? ALPHA PROJECT ALPHA', 'Status.....? 00 Requested', 'Requested By..... PB', and 'Changes Required'. There are also fields for 'Target dates' and 'Authorise by..'. A 'Text Selection' window is overlaid on the right side, showing three options: 'Request Text' (selected with a black square), 'Action Text' (indicated by a dash), and 'Review Text' (indicated by a dash). Below these options, it says '1=Select', 'Enter=Continue', and 'F12=Previous'. At the bottom of the screen, there is a legend: 'F3=Exit F4=Prompt F8=Update F12=Previous', 'F18=Additional Details F20=Request Details F21=Text', and a status bar with '13-40', 'SA', 'MW', 'KS', 'CL', 'IM', 'DM', 'II', 'MARVIN', 'KB', and 'PET165S1'.

Fields:

Request Text

This option allows you to enter free format Request Text against the change request.

Action Text

This option allows you to enter free format Action Text against the change request.

Review Text

This option allows you to review previously entered text.

- ➔ Enter **1=Select** against whichever text you wish to maintain.
- ➔ Select **Enter=Continue** or **F12=Previous** to return to the Change Request Maintenance screen.

Revision Details (F22)

Normally, only the changes to form, fit or function of a product necessitates a change of its revision. You can choose whether you want the item and route to be maintained at the same time or independently.

This revision window will be available and will prompt for a new revision whenever a change request is created, and revision control is active. For an item or item/route change request where revisions are not expected, then the revision window can be ignored by pressing **Enter**.



Select **F22=Revision Details** on the Change Request Maintenance Detail screen to display the Revision Selection Entry window.

CH070	PB - Manufacturing test company	User: GJBABEPB	26/02/98 9:38:13
Change Request Maintenance - Detail			
Change Request.....	2	Request Status....	Requested
Project.....	ALPHA	PROJECT ALPHA	
Detail Number.....	001	First change	
Change Type.....?	12	Amend Item	
Item.....?	PB001.1		
Route.....?	-		
Operation..			
Input.....		Outp	
Structure Item...?			
Use at Revision...			
Allowed Changes....	0001		
Changes Required			

Revision Selection/Entry

Current Revision Level . Rev1 9/99

New Revision Level...?.. Rev1 9/99

Description..

F4=Prompt Enter=Continue

F3=Exit F4=Prompt F8=Update F12=Previous F13=Authorisation F14=Notifications
F18=Additional Details F21=Text

14-56 SA MW KS CL IM DM II MARVIN KB PET165S1

Fields:

Current Revision Level

This shows the existing revision contents for the item or route.

New Revision Level

Allows you to enter the changed revision value for the item or route.

Description

Records a descriptive comment for the revision change.



Select **Enter=Continue** to return to the Change Request Maintenance Detail screen.



Note: You need to activate the revision control by setting the default settings in the Change Management parameter maintenance function.



Note: For a co-product process group primary route, only the revision of the primary co-product item in that group route will be updated. For a concurrent process group, the revision of each concurrent co-product on the route will be updated if the process group is also their primary planning route.

Authorise Request



2/PDR



Select Authorise Request on the menu to display the Change Request Prompt window.

Each change detail on the change request must be authorised by the appropriate person. To do this, first print the authorisation list for the selected change request, then get the appropriate people to sign the list. For more information see Change Request Authorisation List Report. When all the list is signed, you then authorise the change request. You can do this using the Authorise Request option.

When all the change request is authorised, you can action the change request. For more information, see Action Request.

Change Request Prompt Window

The Change Prompt window displays a list of change requests available for authorisation.



Select Authorise Request on the menu to display the Change Request Prompt window.

Fields:

Position To Request

You can display the list of change requests starting from a specific change request. To move to a specific change request, enter the change request in this field and press Enter. The list is displayed starting from the selected change request.

S

1 - Select. When you enter 1 in this field, the window is removed from the screen and the Authorise Change Request screen is displayed.

Project

This field displays the name of the project and is for your information only.

Request

This field displays the change request code and is for your information only.

Status

This field is displayed for your information only. Change requests with a status of 30, 60 or 70 are displayed.

Origin Of Request

This field displays text about the change request and is for your information only.

Authorise Change Request Screen

The Authorise Change Request screen contains the same fields and functions as the Change Request Maintenance screen.

If a change request has a status of 30, the status is immediately updated to 35 when it is displayed in this screen.

In this case, the Requested By, Request Date and Changes Required fields are displayed for your information only and cannot be amended.

Press **Enter** or select **F8=Update** to display the Change Request Maintenance Detail screen. You can amend the Status field to 20, 40, 60 or 70.

If you amend the status to 20, you can edit the other fields on this screen, but you cannot select the change request for authorisation again until the status is 30.

You can amend the status to 40 or 60 if the change details and change request have been authorised. Otherwise, an error message is displayed.

If all the change details have been completed and have a status of 90, then you can amend the status of the change request to complete. i.e. 90. If any change details are cancelled, they do not affect the completion of the change request.

You can authorise the change details. Enter 1 - Select in the S field, and press **Enter** or select **F8=Update** to display the Select Change Detail window. For more information see Select Change Detail Window (F20). You can select a change detail on the list and authorise it.

When the change request has been authorised, you cannot edit the other fields on this screen except the Status field. In this case, you can enter 35, 60 or 70 in the Status field.

When the transaction to add, amend or delete an item or a route has been carried out following its authorisation, the change order line status is changed to completed. Once all the detail lines on the order have been actioned then the order status is set to complete.

Action Request



3/PDR

You can edit the status of an authorised change request. This is known as actioning the change request.

This means that, when a change request has been authorised (status is 40), you can edit the status to the following:

- Held (60) i.e. change request suspended until an action is requested
- Rejected (70) i.e. change is not carried out
- Cancelled (80) i.e. change is not carried out
- Completed (90) i.e. change is done

Any of these actions can be performed on the change request or the change details.

When an action is carried out, any appropriate notifications configured for the selected change request or change details are reported.

Raise Project



11/PDR

This option allows you to enter project information used in raising change requests.



Select Raise Project on the menu to display the first Project Maintenance screen.

Project Maintenance



Select Raise Project on the menu to display the first Project Maintenance screen.

```
CH050      PB - Manufacturing test company      User GBJBAEPB      4/03/98
                                                11:07:39

Project Maintenance

Project.....? █

F3=Exit  F4=Prompt

5-21  SP  MW  KS  CL  IM  DM  II  STUD140  KB  PET165S1
```

Fields:

Project

You must enter the name of a project in this field.

If the project name does not exist, you can add the project to the system.

If the project name already exists on the system, you can edit the project on the system.



Press **Enter** on the first Project Maintenance screen to display the second screen.

Project Maintenance Screen 2



Press **Enter** on the first Project Maintenance screen to display the second screen.

CH050	PB - Manufacturing test company	User GBUBAEPB	4/03/98 11:07:58
Project Maintenance			
Project	ALPHA		
Description.....	PROJECT ALPHA		
Project Group.....	_____		
Project Type.....	_____		
Project Manager...	_____		
Product Manager...	_____		
Coordinator.....	_____		
Project Originator	_____		
Internal sponsor..	_____		
External sponsor..	_____		
Estimated Cost ...	.00		
Estimated Benefit.	.00		
F3=Exit F12=Previous F16=Authorisations F17=Notifications F21=Project Text			
6-21	SR	MW	KS CL IM DM II STUD140 KB PET165S1

Fields:

Project

This field contains the project name and is displayed for your information only.

Description

Description. This field contains a text description of the project.

Project Group

Enter the project group in this field.

Project Type

Enter the project type in this field.

Project Manager

Enter the project manager in this field.

Product Manager

Enter the product manager in this field.

Co-ordinator

Enter the co-ordinator in this field.

Project Originator

Enter the project originator in this field.

Internal Sponsor

Enter the internal sponsor in this field.

External Sponsor

Enter the external sponsor in this field.

Estimated Cost

Enter the estimated cost of the project in this field.

Estimated Benefit

Enter the estimated profit to be made from the project in this field.

Functions:

F16

Authorisations. Select this function to display the Maintain Authorisation List window for the selected change request. See Change Request Maintenance Detail Screen (F20) for further details.

F17

Notifications. Select this function to display the Maintain Notification List window for the selected change request. See Change Request Maintenance Detail Screen (F20) for further details.

F21

Project Text. Select this function to enter text about this project.



Press **Enter** on the second Project Maintenance screen to display the third screen.

Project Maintenance Screen 3



Press **Enter** on the second Project Maintenance screen to display the third screen.

CH050	PB - Manufacturing test company	User GBJBAEPB	4/03/98 11:08:35
Project Maintenance			
Project ALPHA			
Description..... PROJECT ALPHA			
Review Required... 0 (1=Yes)			
Target Approval... 31/12/98			
Target Completion. 31/12/98			
Reason code.....?. _			
Notification defaults			
Request 1 (1=Yes) Pending 1 (1=Yes) Applied 1 (1=Yes)			
F3=Exit F4=Prompt F8=Update F12=Previous			
F16=Authorisations F17=Notifications F21=Project Text			
8-21	SR	MW	KS CL IR DM II STUD140 KB PET165S1

Fields:

Target Approval

Enter the date you want the project to be approved by. The default is the current date.

Target Completion

Enter the date you want the project to be completed by. The default is the current date.

Reason code



Press **F8=Update** to validate and update the Project Maintenance details.

Parameters



12/PDR



Select Maintain Parameters to display the Change Management Parameters Maintenance screen.

Change Management Parameters Maintenance Screen



Select Maintain Parameters to display the Change Management Parameters Maintenance screen.

CH010	PB - Manufacturing test company	GBJBAEPB	030398
Change Management parameters Maintenance			
Change Management Text Types			
Description	Major text type	Minor text type	
1. Project text	CHPT	PBJ	
2. Request header text	CHHT	BQS	
3. Request header review	CHHT	BLW	
4. Request action text	CHHT	ACT	
5. Request details	CHDT	BQS	
6. Request detail review	CHDT	BLW	
7. Request detail action	CHDT	ACT	
Last automatic request number _____ 2 Use manual numbering 0 (1=Yes)			
Express change request.. 0 (1=Yes)			
F3=Exit			
10-44 SA MW KS CL IM DM II MARVIN KB PET165S1			

Fields:

Request Text

Enter the major and minor text types for the change request project.

Request Text

Enter the major and minor text types for the change request header.

Review Text

Enter the major and minor text types for the change request review header.

Action Text

Enter the major and minor text types for the change request action header.

Request Text

Enter the major and minor text types for the change request detail.

Review Text

Enter the major and minor text types for the change request review detail.

Action Text

Enter the major and minor text types for the change request action detail.



Note: Default text values are obtained from

those set up in Text Type Maintenance. There are three text types. Project Text is text associated with a project. Request text can only be entered at request maintenance time. This is before the change request is at status 30 (submitted). Review text can be entered at the review stage when the change request has been submitted for authorisation and is at status 30 (submitted) or 35 (review in progress). If the review phase is by-passed this text is not available. Action text can be entered at input or review stage, and can be used for specifying particular actions.

Last automatic request number

This shows the last change request number generated by the system.

Use manual numbering

0 - No.

1 - Yes. Use this to indicate that you wish to enter your own change request numbers.

Express Change request

0 - No.

1 - Yes. Select this to invoke the express change request facility. This facility is only used on items and route headers.



Press **Enter** on the Change Management Parameters Maintenance screen to display the second Change Management Parameters Maintenance screen.

Change Management Parameters Maintenance Screen 2



Press **Enter** on the Change Management Parameters Maintenance screen to display the second Change Management Parameters Maintenance screen.

CH010	PB - Manufacturing test company	GBJBAEPB	3/03/98 11:41:35
Change Management parameters Maintenance			
Default project.....?.. ALPHA PROJECT ALPHA			
Revision Control policy.. 1 0=No Revision level expected to be entered 1=Revision level expected to be entered			
Item and route revision policy... 1 0=Revisions maintained automatically 1=Revisions maintained independently			
Revision check in production..... 1 0=No revision check 1=Check revisions			
F3=Exit F4=Prompt F8=Update F12=Previous			
7-31	SA	MW KS CL IM DM II	MARVIN KB PET165S1

Fields:

Default project

Enter the name of the project to always appear as default when entering subsequent change requests.

Revision Control policy

0=No. This means that you do not want to enter details about revision control for change requests.

1=Yes. Revision Control is a required feature.

Item and route revision policy

Revision control on items and routes can be maintained in synchronisation if desired.

0=Yes. You require that revision changes occurring on either the item or the route should automatically update the other.

1=No. You would like the revisions to item and route to be maintained independently.

Revision check in production

Reserved for future use.



Select **F8=Update** to validate and update the Change Management parameters.

Change History Enquiries

You can display old and current change requests and change details for a selected project or item.



21/PDR



Select Change History in the Enquiries section on the menu to display the Change History Enquiry Selection screen.

Change History Enquiry Selection Screen



Select Change History in the Enquiries section on the menu to display the Change History Enquiry Selection screen.

Fields:

Select By Request Number

You can enter the code of a change request you want to display. If you enter a valid number and select **F8=Continue**, other entries in this screen are ignored and the Change Request Enquiry screen is displayed.

Or From Project

You can enter the code of a project you want to display. If you enter a valid number and select **F8=Continue**, and the Change Request Prompt window is displayed.

Or From Primary Item

You can enter the code of an item you want to display. If you enter a valid number and select **F8=Continue**, and the Change Request Prompt window is displayed. This window contains a list of change requests which use the selected item.

Completed Requests

You can decide whether or not to display the change requests with a status of 60, 70, 80 or 90. To do this enter one of the following:

0 - No.

1 - Yes.

Or Active Requests

You can decide whether or not to display the change requests with a status of 00, 20, 30, 35 or 40. To do this enter one of the following:

0 - No

1 - Yes

Or All Requests

You can decide whether or not to display all the change requests. To do this enter one of the following:

0 - No

1 - Yes



Select **F8=Continue** to display the selected screen or window.

Change Request Enquiries



22/PDR



Select Change Request in the Enquiries section on the menu to display the Change Request Enquiry screen.

The fields displayed on this screen are exactly the same as those displayed on the Change Request Maintenance screen, but these fields are displayed for your information only and cannot be amended.

Projects Enquiries



23/PDR



Select Projects in the Enquiries section on the menu to display the Project Prompt window.

The fields displayed on this screen are exactly the same as those displayed on the Projects Maintenance screen, but these fields are displayed for your information only and cannot be amended.

Parameters Enquiries



24/PDR



Select Parameters in the Enquiries section on the menu to display the Parameters Enquiry screen.

The fields displayed on this screen are exactly the same as those displayed on the Parameters Maintenance screen, but these fields are displayed for your information only and cannot be amended.

Revision Enquiry



25/PDR

This option is used to track all the revision changes being applied to items and routes. For a chosen item or item/route, previous, current and pending revisions are summarised and detailed.



Select Revisions to display the Pending Revision Enquiry screen.

Pending Revision Enquiry



Select Revisions to display the Pending Revision Enquiry screen.

```
CH675                PB - Manufacturing test company  USER GBJBAEPB   3/03/98
                                                           14:01:37

Pending Revision Enquiry
Item .....?.. █
Route Policy..... 1  1=Item Only  2=All Routes  3=Specific Route
Route .....?.. _
From Date .....
To Date ..... 99/99/99

F3=Exit  F4=Prompt

6-26  SP  MW  KS  CL  IM  DM  II  STUD140  KB  PET165S1
```

Fields:

Item

Enter the item you wish to enquire upon.

Route Policy

Select the route policy to be used.

Route

Choose the appropriate route. This field cannot be used for route policy 1 and 2.

From Date

Enter the earliest date required for enquiry selection purposes.

To Date

Enter the latest date required for enquiry selection purposes.



Press Enter on the Pending Revision Enquiry screen to display the Revision Enquiry selection screen.

Revision Enquiry Selection Screen

This screen presents the revision changes made to the item selected and also allows you to view the details behind the change.



Press Enter on the Pending Revision Enquiry screen to display the Revision Enquiry selection screen.

CH675	PB - Manufacturing test company	USER GBJBAEPB	3/03/98
			14:52:24
Revision Enquiry			
Item	PB001 .1		
Route			
Revision			
S Date	Rte	Status	Old New Change Request Type
█	35	Being author	Rev1 Rev1 2/001 12 Amend Item
1=Display Details			
F3=Exit F12=Previous			
Bottom			
8-4 SR MW KS CL IM DM II STUD140 KB PET165S1			

Fields:

S

1=Display Details. Enter 1 in this field to select a change revision to view.



Enter 1 in the S field and press **Enter** on the Revision Enquiry Selection screen to display the Revisions Change Detail.

Revisions Change Detail Screen



Enter 1 in the S field and press **Enter** on the Revision Enquiry Selection screen to display the Revisions Change Detail.

CH675	PB - Manufacturing test company	USER GBJBAEPB	3/03/98 14:52:42
Revisions Change Detail			
Revision No..... Rev1			
Description..... First change			
Project..... ALPHA PROJECT ALPHA			
Change Request..... 2/001			
Requested Date..... 3/03/98			
Status..... 50 Active			
Change Type..... 12 Amend Item			
Operation.....			
Input Seq..... Output Seq.....			
Input/Output Item.....			
Effective From..... to			
Authorisation Date... 3/03/98 Department.....			
Action Date.....			
Action Time.....			
Estimated Cost.....			
F3=Exit F12=Previous			
1-1 SR MW KS CL IM DM II STUD140 KB PET165S1			

Fields:

The following fields are represented on this screen :

Revision No.

Description.

Project.

Change Request.

Requested Date.

Status.

Change Type.

Operation.

Input seq.

Output seq.

Input/Output Item.

Effective From/To.

Authorisation Date.

Department.

Action Date.

Action Time.

Estimated Cost.



Select **F12=Previous** to return to the Revision Enquiry Selection screen.

Change History Reports

You can display a report about an old or current change request, and then display a report for another one.



31/PDR



Select Change History in the Reports section on the menu to display the Change History Report Selection screen.

Change History Report Selection Screen



Select Change History in the Reports section on the menu to display the Change History Report Selection screen.

The fields displayed on this screen are exactly the same as those displayed on the Change History Enquiry Selection screen.

You can enter data in the fields.



Select **F8=Continue** on the Change History Report Selection screen to display the Change Request Selection window.

Change Request Selection Window



Select **F8=Continue** on the Change History Report Selection screen to display the Change Request Selection window.

The Change Request Selection window is displayed. For more information see Change Request Selection Window.



Press **Enter** on the Change Request Selection window to display the Change History Report/Enquiry screen for the selected change requests.

Change History Report/Enquiry Screen



Press **Enter** on the Change Request Selection window to display the Change History Report/Enquiry screen for the selected change requests.

The Change History Report/Enquiry screen contains the same fields and functions as the Change Request Maintenance screen. However, these fields are for your information only and cannot be amended. For more information see the Change Request Maintenance screen.



Press **Enter** to display a report about the selected change request.

You can display the Change Request Selection window, select another change request and display a report about it.

Change Request Reports

You can display a report about a selected change request.



32/PDR



Select Change Request in the Reports section on the menu to display the Change Request Report Selection screen.

Change Request Report Selection Screen



Select Change Request in the Reports section on the menu to display the Change Request Report Selection screen.

This screen contains the same fields and functions as the Change Request Maintenance Selection screen. For more information see Change Request Maintenance Selection Screen above.



Select **F8=Continue** or press **Enter** on the Change Request Report Selection screen to display the Change Request Selection window.

If you enter a valid number in the Select By Request Number field, other entries in this screen are ignored and the Change Request Report screen is displayed for the selected change request.

If you enter valid entries in the other fields on the screen, a constrained list of change requests is displayed in the Change Request Selection window.

Change Request Selection Window



Select **F8=Continue** or press **Enter** on the Change Request Report Selection screen to display the Change Request Selection window.

A constrained list of change requests is displayed in the Change Request Selection window. For more information about this window see Change Request Selection Window above.



Press **Enter** on the Change Request Selection window to display the Change Request Report screen for the selected change request.

Change Request Report Screen



Press **Enter** on the Change Request Selection window to display the Change Request Report screen for the selected change request.

All the fields displayed on this screen are for your information only and cannot be amended.

This screen displays all the fields displayed on the Change Request Maintenance screen. For more information see Change Request Maintenance Screen above.

This screen also displays lists of any authorisations and notifications configured for this change request.

All the line text, action text and review text associated with the change request are displayed.

Authorisation List Reports

You can print an authorisation report for a selected change request or change detail. This can be used to get signatures from the people as proof of authorisation.



33/PDR



Select Authorisation List in the Reports section on the menu.

Select a change request. The Change Request Authorisation List report for the selected change request is printed.

This report displays information about the change request, and any change details associated with it. Each change detail is printed on a separate page.

Fields:

Request Number

This is the change request number.

Status

This is the current status of the change request.

(Untitled)

This is descriptive text about the change request.

Requested By

This is the user ID of the person who originally requested the change.

On

This is the date the change request was first requested.

Target Authorisation Date

This is the date by which the authorisation for this change request is planned to be completed.

Actual Date

This is the date by which the authorisation for this change request was actually completed.

By

This is the user ID of the person who completed authorisation.

Target Action Date

This is the date by which this change request is to be actioned.

Actual Date

This is the actual date by which this change request was actioned.

By

This is the user ID of the person who completed the action.

Request Type

This field displays the code and description of the type of request.

Request Origin

This field displays the name of the user who made the change request.

Request Reason

This field displays the code and description of the request reason.

Estimated Cost

This field displays the estimated cost of the project in this field.

Estimated Benefit

This field displays the estimated profit to be made from the project in this field.

Revision Level Change

This field is reserved for future use.

From Level

This field is reserved for future use.

To Level

This field is reserved for future use.

Authorisation Required

This field displays whether or not authorisation is required.

Default Authoriser

If authorisation is required, this field displays the user ID of the person who can authorise the change request if the designated person is unable to comply.

Authorise Headers

This field displays whether or not authorisation is required for the change request.

Authorise Details

This field displays whether or not authorisation is required for the change details.

Notify Details

This field displays whether or not notification is required.

Cancel Lines Allowed

This field displays whether or not you can cancel lines when the status is at the action stage.

Associated Project No

If a project is associated with this change request, this field displays the project number and a text description of the project.

Number

More than one person may be required to authorise the change request. A list of authorisations are displayed.

For each authorisation, the number of the authorisation is displayed.

User

For each authorisation, the user ID of the user to give the authorisation is displayed.

Dept

For each authorisation, the user's department is displayed.

Name

For each authorisation, the name of the user to give the authorisation is displayed.

Date

For each authorisation, the date by which the authorisation must be given is displayed.

Authorised By

For each authorisation, a space is left for the user's signature.

On

For each authorisation, a space is left for the user to write the date they signed their authorisation.

For each change detail, the fields displayed on this report are as follows:

Change Detail Number

This is the change detail number.

Status

This is the current status of the change request.

Request Type

This field displays the code and description of the type of request.

Primary Item

This field displays the name and description of the primary item.

Item Type

This field displays the code and description of the item type.

Route Code

This field displays the route code.

Operation

This field displays the code and description of the operation.

Secondary Item

This field displays the name and description of the secondary item.

Sequence

The field displays the sequence.

Type

This field displays the code and description of the sequence type.

Requested By

This is the user ID of the person who originally requested the change.

On

This is the date the change request was first requested.

Target Authorisation Date

This is the date by which the authorisation for this change detail is planned to be completed.

Actual Date

This is the date by which the authorisation for this change detail was actually completed.

By

This is the user ID of the person who completed authorisation.

Target Action Date

This is the date by which this change detail is to be actioned.

Actual Date

This is the actual date by which this change detail was actioned.

By

This is the user ID of the person who completed the action.

Effectivity From Date

This displays the date from which this change detail is effective.

To Date

This displays the date to which this change detail is effective.

Estimated Cost

This field displays the estimated cost of the project in this field.

Number

More than one person may be required to authorise the change request. A list of authorisations are displayed.

For each authorisation, the number of the authorisation is displayed.

User

For each authorisation, the user ID of the user to give the authorisation is displayed.

Dept

For each authorisation, the user's department is displayed.

Name

For each authorisation, the name of the user to give the authorisation is displayed.

Date

For each authorisation, the date by which the authorisation must be given is displayed.

Authorised By

For each authorisation, a space is left for the user's signature.

On

For each authorisation, a space is left for the user to write the date they signed their authorisation.

Notification List Reports

You can print a notification report for a selected change request or change detail. This can be used to notify the appropriate people or departments when the status of a change request or change detail has changed.



34/PDR



Select Notification List in the Reports section on the menu to display the Notification Report Selection Prompt screen.

Notification Report Selection Prompt Screen



Select Notification List in the Reports section on the menu to display the Notification Report Selection Prompt screen.

Fields:

Select By Project

You can enter the code of a project whose notifications you want to print.

Or By Request Number

You can enter the code of a change request whose notifications you want to print.

Limit By User

You can enter the name of a user whose notifications you want to print.

From Date

You can enter the date from which the notifications are printed. You can configure the order in which the notifications are printed by entering numbers in the Project, Or Request and Or User fields.

Project

Enter the number 1, 2 or 3 to configure the order in which the notifications are printed.

Or Request

Enter the number 1, 2 or 3 to configure the order in which the notifications are printed.

Or User

Enter the number 1, 2 or 3 to configure the order in which the notifications are printed.



Select **Enter** on the Notification Report Selection Prompt screen to print the selected notifications on the Change Request Status Change Notifications report.

Change Request Status Change Notifications Report



Select **Enter** on the Notification Report Selection Prompt screen to print the selected notifications on the Change Request Status Change Notifications report.

This report displays information about the selected notifications. Each change detail is printed on a separate page.

For a change request, the fields displayed on this report are the same as the fields displayed on the Change Request Authorisation List report.

For a change detail, the fields displayed on this report are the same as the fields displayed on the Change Request Authorisation List report.