

1.

Trigger Boundary

Access  
Point (AP)

Edge of Coverage

User  
Equipment  
(UE) with IMU

2.

Trigger  
Boundary  
CrossedControl  
Frame

3.

Realignment  
Completed

Time

UE

Data



AP

Data

Control  
Frame $T_{frame}$ 

IMU-Aided Beam Steering

Control  
Processing $T_{proc}$ IMU-Aided  
Beam Steering

Data



Data

Trigger Boundary Crossed

Realignment Completed