

Food Living Outside Play Technology Workshop

Fritzing - A Tutorial

by kaitlyn1franz on June 12, 2014

Table of Contents

Fritzing - A Tutorial	1
Intro: Fritzing - A Tutorial	2
Step 1: Core Parts	2
Step 2: My Parts	2
Step 3: Import Parts	3
Step 4: BreadBoard View - Drag Parts	3
Step 5: Connect Parts	4
Step 6: Parts Inspector	4
Step 7: Completed Circuit	4
Step 8: Schematic View	5
Step 9: Schematic View - Finalized	5
Step 10: PCB View	6
Step 11:	6
Related Instructables	6
Advertisements	7
Comments	7

Intro: Fritzing - A Tutorial

Fritzing is a free tool that allows users to create clean and professional images of electronics projects for teaching or sharing. Digilent uses Fritzing in all of our interncreated projects, and we're working closely with Fritzing to have a bin of Digilent parts soon.

As promised a couple of weeks ago, we've created a tutorial for designing circuits in Fritzing!






Step 1: Core Parts


The first step in creating a Fritzing image is to find the parts you want to use. Fritzing comes with core parts bin, a "my parts" bin, and many other parts bins from specific manufacturers.

The core parts bin is filled with many useful and generic parts. Here you can find things like LEDs, breadboards, connectors, and anything you might need other than manufacturer-specific boards.



Step 2: My Parts

The original my parts bin will be empty, but mine is full of Digilent parts I or other Digilent employees have created.




Step 3: Import Parts

If you would like to import Digilent or other user-created parts click on the drop down menu on the right side of the bar that says My Parts, and select import. Find the file on your computer and it will be in the bin ready for use. You can download many parts, including Digilent parts, from the User Parts Repository.




Step 4: BreadBoard View - Drag Parts

If you drag the any part onto the breadboard, Fritzing will automatically show you all the pins that are connected to that part in green. The blue and white LEDs in my sketch show this nifty feature. If you just place the LED on the grid, it will not be connected to anything, but don't fret. We can always connect them with wires.



Step 5: Connect Parts

To connect a wire, click on the first pin you want to connect and drag it to the second one.




Step 6: Parts Inspector

Now our LED is connected to the breadboard! On the bottom right you can see the part inspector. This allows you to change certain features, such as wire color. The features will be different based on the specific part.

Step 7: Completed Circuit


Before we switch views, I'll make a completed circuit. In breadboard view, it looks like this.

Notice that I have two separate circuits here, one using the Uno32 from Digilent and one using a battery pack. Using the Uno32 allows more control over the LED as can be seen here. Now we'll shift to the schematic view. To change views, select the appropriate tab on the top of the sketch.




Step 8: Schematic View

Fritzing creates the schematics for you as long as you've connected everything in the breadboard view correctly. However, Fritzing doesn't do all the work for you. When you first open up the schematic view, it looks like this.



Step 9: Schematic View - Finalized


As you saw in the previous step the generated schematic view is a bit of a tangled mess. All you have to do now is move and rotate the parts as necessary.




Step 10: PCB View

The same procedure applies for the PCB view. Fritzing makes all the connections for you, it just requires a little tweaking. The PCB view allows you to create your own PCB boards from the circuits that you design.

On the bottom of the page it talks about routing. That just means you have to go over the dotted lines with solid lines in the way that you connected wires.





Step 11

This tutorial can be found on the Digilent blog at blog.digilentinc.com.

Related Instructables



Digilent MRK + Line-Following Robot Assembly Instructions by kaitlyn1franz



How To Use Fritzing For Your Arduino/Raspberr Instructable by digipup1



Making an Arduino RTC Shield by

Quick Start Test 2007jingz Demo: Zybo (Xilinx Zynq 7000) Image Filtering Demo + GoPro by LariSan



Getting started with Xilinx Vivado w/ Digilent Nexys 4 FPGA 1 - Build multiple inputs AND Logic gate



Soda Can Theremin w/ Digilent Analog Discvoery by WillW_Digilent

Comments

2 comments Add Comment



incognito0288 says:
very useful. .. Thank you for this ;)

Jun 12, 2014. 10:30 PM **REPLY**



liquidhandwash says:

That looks like a great software package, does it export dxf files of a cnc router?

Jun 12, 2014. 6:24 PM **REPLY**