
Top > Tools > Filters > Multiple Feedback Low-pass Filter Design Tool > Result

Multiple Feedback Low-pass Filter Design Tool - Result -

Calculated the Transfer Function for the multiple feedback Low-pass filter, displayed on graphs, showing Bode diagram, Nyquist diagram, Impulse response and Step response

Multiple Feedback Filter



Transfer Function:

$$G(s) = \frac{-90909090.909091}{s^2 + 19181.81818181818s + 90909090.909091}$$

Cut-off frequency

fc = 1517.4828413163[Hz]

Gain at f=0Hz

 $G_{pk} = -1[times] (0)[dB]$

Quality factor

Q = 0.49706580481998

Damping ratio

 $\zeta = 1.0059030316541$

Pole(s)

p = -1361.3142667097[Hz] |p| = 1361.3142667097[Hz] p = -1691.5669144167[Hz]|p| = 1691.5669144167[Hz]


Phase margin

pm = INF[deg] (f = 0[Hz])

R1=11k	Ω	C1=10n	F
R2=100k	Ω	C2=1n	F
R3=11k	Ω		

p:pico, n:nano, u:micro, k:kilo, M:mega

Frequency analysis	
■ Bode diagram	
Phase Group delay	
✓ Nyquist diagram	
Pole, zero	
✓ Phase margin	
✓ Oscillation analysis	
Analysis on frequency range:	_
f1= ~f2=	[Hz] (optional)



Calculate

The system does not oscillate.


Overshoot (in absolute value)


The peak of transient waveform is not detected.

Final value of the step response (on the condition that the system converged when t goes to infinity)

$$g(\infty) = -1$$

Frequency analysis






<u>Gain characteristics at the Bode Diagram</u> (provides up to 1 minute)

Group delay characteristics (provides up to 1 minute)

Bode Diagram text data (provides up to 1 minute)


NyquistDiagram



Nyquist Diagram text data (provides up to 1 minute)

Transient analysis

StepResponse



(c)okawa-denshi.jp

Suggestion box					
We'll use your	suggestion to improv	e site quality in fut	ture.		
				 Post Comment	
<u>disclaimer</u>	<u>blog</u>				

© 2004 - 2020 OKAWA Electric Design