
# PINOUT

# DevLab: I2C LM35 Temperature Sensor

## Top view








**Open the pad to disable the I²C SIG signal**

## Bottom view

**NOTE**
**Optional JST connectors; not included.**
**Solder them if you wish to extend the I²C bus.**




**NOTE**
**Optional connector (not included).**