COMENTARIO TECNICO

Como manejar un Display Inteligente LCD por medio de un Microcontrolador de la Familia HC908..

Por Ing. Daniel Di Lella D.F.A.E For Motorola Products Depto. Técnico Electrocomponentes S.A. Fae@electrocom.com.ar

Hoy en día, es una necesidad cada vez más frecuente, la visualización de comandos y estados de una gran variedad de equipos con el usuario final. Es evidente que, al ir mejorando las prestaciones generales de un sistema o equipo, se hace necesario disponer de un medio práctico de comunicar las diferentes informaciones "Usuario - Máquina".

Uno de los elementos más usados en este sentido, es el display LCD de tipo "inteligente". Estos módulos, son la forma más eficiente de comunicación alfanumérica con el mundo exterior. Los hay de distintos tamaños, cantidad de caracteres y cantidad de filas. Por ejemplo, la empresa **WINTEK Corporation** (Electrocomponentes, es distribuidor exclusivo en la Argentina), posee módulos desde 8 caracteres x 1 línea (osea una línea de 8 caracteres) , hasta módulos de 40 caracteres x 4 líneas. Un opcional que mejora la visibilidad en cualquier condición es el "Back - Light" o luz de fondo que puede ser del tipo a LED (array de LEDs uniformemente distribuidos) o del tipo Electroluminicente.

El propósito del siguiente artículo, no es entrar en detalles constructivos o de presentación, sino aportar datos útiles para poder utilizar uno de estos display con un microcontrolador en un proyecto determinado.

Introducción:

Los módulos de display inteligentes, son denominados así, ya que poseen la "inteligencia" necesaria como para efectuar en forma totalmente automática y transparente para el usuario, las complejas operaciones de control, presentación y mantenimiento de los caracteres en pantalla. Para ello, todos cuentan con controladores dedicados, integrados a la estructura de los mismos. Estos controladores integrados, aunque de distintos fabricantes, presentan repertorios o sets de instrucciones (lista de comandos) hacia el mundo exterior muy similares entre sí, por lo cuál, en la mayoría de los casos, no importa la marca del display a emplear, sino el hecho que utilicen controladores integrados compatibles, haciendo de esta forma "genérico" el uso de un display LCD inteligente.

Electrocomponentes S.A.
Solis 225 / 227 / 229 - Cap. Fed. - (1078) - Buenos Aires - Argentina
Tel: (5411) 4375- 3366 Fax: (5411) 4325-8076

Líneas de Conexión:

Los display inteligentes poseen líneas de conexión con el mundo exterior que pueden dividirse en :

- Líneas de Datos / Comandos.
- Líneas de Control

Las líneas de Datos / Comandos son las utilizadas por el display para recibir Datos o Comandos y eventualmente pueden utilizarce para conocer el estado de ocupación del controlador interno (display "Busy"). Según el modo empleado, pueden necesitarse 8 o 4 líneas de Datos / Comandos.

Si se utiliza el modo de 8 líneas de Datos, se tiene la ventaja de un manejo más sencillo a la hora de implementar el software en el microcontrolador elegido, pero se paga el precio de tener que disponer más puerto I/O del MCU para el envío de datos o comandos al display.


En cuanto a las líneas de Control, son necesarias para coordinar las distintas operaciones que puede realizar un display LCD, a saber:

- Escritura de Datos al display (Data Word).
- Escritura de Comandos al display (Control Word).
- Lectura de estados del display (Busy, Address Counter, DD RAM, CG RAM)


Solo son necesarias 3 líneas de control para efectuar la tarea, RS, E, y R/W.


Cuando se quiere trabajar con alguno de estos displays, se pueden utilizar varias formas de control de los mismos. Por ejemplo se puede trabajar con **8 bits** o con **4 bits de palabra de datos.** También puede utilizarse el método de demora fija entre envío de caracter y caracter, o emplear el método de lectura del estado "Busy" que proporciona el controlador integrado en el display.

Los diagramas de tiempos correspondientes a las distintas señales de control se observan en las siguientes figuras:



La inicialización de estos displays , puede efectuarse en forma automática por medio del propio controlador integrado, al detectar este un Power - On Reset (P.O.R) , osea durante el encendido del sistema, o bien por medio de comandos de software enviados al controlador para efectuar esta tarea de inicialización. Muchas veces puede ocurrir, que la pendiente de subida de la fuente de alimentación, no es lo suficientemente abrupta como para garantizar que el controlador integrado detecte la condición de P.O.R. , por lo que es conveniente tener contemplado el uso de una rutina de inicialización por software en nuestra aplicación.





Una vez efectuado el "Reset" del display, el mismo se encuentra en condiciones de recibir palabras de comando que personalizan la forma de presentar los sucesivos caracteres

enviados a este. Por ejemplo se pueden enviar comandos de "Clear Display" para limpiar la presentación en pantalla, "Return Home" para posicionar al cursor en la posición "Home" o primer carácter superior izquierdo, etc, etc. En las siguientes figuras, pueden verse la lista completa de los mismos y algunos ejemplos de uso de estos.

Function	1833		2073	В	D	В	В	В	D B	В	Description	Execu. Time*
Clear Display	0	0	-	-	-	-			0		Clears entire display and returns the cursor to home position (address 0).	1.64mS
Return Home	0	0	0	0	0	0	0	0	1	x	Return the cursor to the home position. Also returns the display being shifts to the original position. DD RAM contents remain unchanged. Set DD RAM address to zero.	1.64mS
Entry mode set	0	0	0	0	0	0	0	1	1 / D	s	Set cursor move directly and specifies or not to shift the display. These operations are performed during data write/read of DD RAM/CG RAM. For normal operation, sets S to zero. I/D=1; increment; I/D=0; decrement S=1; accompanies display shift when data is written, for normal operation, set to zero.	40μS
Display ON/OFF control	0	0	0	0	0	0	1	D	С	В	Set ON/OFF all display (D), cursor ON/OFF(C), and blink of cursor position character (B). D=1: ON display, D=0:OFF display, C=1: ON Cursor, C=0: OFF cursor, B=1: ON Blink Cursor, B=0, OFF Blink Cursor	40µS
Cursor or Display shift	0	0	0	0	0	1	I	S / C	1	×	Move the crusor and shift the display without changing DD RAM contents. S/C=1: Display Shift, S/C=0: Cursor move, R/L=1: shift to right, R/L=0:shift to left.	40µS
Function Set	0	0	0	0	1	D	N	F	x	x	Set the interface data length (DL), number of display lines (N) and character font (F). DL=1: 8 bits, DL=0: 4bits N=1: 2 lines, N=0:2 lines, N=0:1 lines, F=1: 5x10 dots, F=0: 5x7 dots	40μS
Set CG RAM Addr.	0	0	0	1 ACG					3		Set CG RAM address, CG RAM data is sent and received after this setting.	40μS
Set DD RAM Addr.	0	0	1			1	ADE)			Set DD RAM address. DD RAM data is sent and received after this setting.	40μS
Read busy flag & Addr	0	1	B	AC							Reads BUSY FLAG (BF) indicating internal operation is beginning perfrmed and reads address counter contents. BF=1:internally operating. BF=0; can accept instruction.	0μS
Write Data to	1	0		٧	VR	TE	D	AT/	4		Write data into DD RAM or CG RAM.	40µS*
Read Data from CG/DD RAM	1	1		- 6	READ DATA						Read data from DD RAM or CG RAM	40μS**

- * 1. When f_{cp} or f_{DSC} is 250 KHz
- 2. Execution time changes when frequency changes. When f_{co} or f_{OSC} is 270KHz: 40μ S x $\frac{250}{270}$ = 37μ S
- ** t_{ADD} = 6μS

Software Examples

8-bit	operation	(8-bits 2lines)

Function	RS RW D7 D6 D5 D4 D3 D2 D1 D0						D3	D2	D1	D0	Display	Description
Power on delay												Initialization. No display appears.
Function set	0	0	0	0	1	1	0	0	x	X		Sets 8-bit operation and selects 2-line display and 5x7 dots character font. (Note: number of display lines and character fonts cannot be change after this.)
Display OFF	0	0	0	0	0	0	1	0	0	0		Turn off display.
Display ON	0	0	0	0	0	0	1	1	1	0	()	Turn on display and cursor.
Entry Mode Set	0	0	0	0	0	0	0	1	1	0		Set mode to increment the address by one and to shift the cursor to the right, at the time of write, to the DD/CG RAM Display is not shifted.

CG/DD RAM	1	0	0	1	0	1	0	1	1	1	(MC)	Write "W". Cursor incremented by one and shift to right
Write data to	1	0	0	1	0	0	1	0	0	1	(w)	Write"1". Cursor incremented by one and shift to right
Write data to					:						(WINTER.	Write"N", "T", "E", and "K".
Set DD address.	0	0	1	1	0	0	0	0	0	0	WNTK	Set RAM address so that the cursor is propositioned at the head of the Second line.
Write data to CG/DD RAM					•						WNIEK CR_	Write "C", and "R".
Cursor or display	y 0	0	0	0	0	1	0	0	×	×	CH	Shift only the cursor position to the left.
Write data to CG/DD RAM					•						WHITEK CORPORAT_	Write"O", "R", "P", "O", "R", "A", and "T".
Entry Mode Set	0	0	0	0	0	0	0	1	1	1	(WMTR CORPORAT_)	Set display mode shift at the time during writing operation.
Write data to	1	0	0	1	0	0	1	0	0	1	N/BK ORD/ORATE	Write T. Cursor incremented by one and shift to right. (The display move to left)
Write data to					•							Write other characters.
				0	0	0	0	0	1	0	WINTEX CORPCRATIO	Return both display and cursor to the original position.
Return Home	0	0	0									(Set address to zero.)
Return Home					e)							(Set address to zero.)
Return Home		its	11	ine		5 D	4	0	isi	olay	1	(Set address to zero.) Description
Return Home 4-bit operation Function	(4-b	its	11	ine		5 D	4	0)isį	olay		
Return Home	(4-b	oits	11 D7	ine D6	D			0	Disp	olay	Sets to 4 In this ca	Description
A-bit operation Function Dower on delay Function set	(4-b	oits	11 D7	ine D6	D))isj	olay	Initializati Sets to 4 In this ca instruction	Description on. No display appearsbit operation. se, operation is handled as 8-bits by initialization, and only this
Return Home 4-bit operation Function power on delay Function set	(4-b)	oits 0	11 D7 0	0 0	1	C)	0)isj	olay	Initializati Sets to 4 In this ca instructio Sets 4-bi character	Description on. No display appearsbit operation. se, operation is handled as 8-bits by initialization, and only this n completes with one write. t operation and selests 1-line display and 5x7 dot
Return Home 4-bit operation Function power on delay Function set	(4-b)	oits 0	0 0	0 0	1	C)))()isį	olay	Initializati Sets to 4 In this ca instructio Sets 4-bi character character	Description on. No display appearsbit operation. se, operation is handled as 8-bits by initialization, and only this in completes with one write. t operation and selests 1-line display and 5x7 dot font on and resetting is needed. (number of display lines and
Return Home 4-bit operation Function power on delay Function set Function set	(4-b)	o o o	0 0	0 0	1 1 X	0)	0)is _į	olay	Initializati Sets to 4 In this ca instructio Sets 4-bi character character	Description on. No display appearsbit operation. se, operation is handled as 8-bits by initialization, and only this in completes with one write. It operation and selests 1-line display and 5x7 dot of font on and resetting is needed. (number of display lines and of fonts cannot be changed hence after.)
Return Home 4-bit operation Function power on delay Function set Function set Display ON/OFF Control	(4-b) RS F	0 0 0 0	0 0 0 0 1	0 0 0 0 1	1 1 X 0 1 0	000000000000000000000000000000000000000) ()is _į	olay	Initializati Sets to 4 In this ca instructio Sets 4-bi character Turn on 6	Description on. No display appearsbit operation. se, operation is handled as 8-bits by initialization, and only this in completes with one write. It operation and selests 1-line display and 5x7 dot font on and resetting is needed. (number of display lines and r fonts cannot be changed hence after.) display and cursor.
Return Home 4-bit operation Function power on delay	(4-b) RS F	0 0 0	0 0 0 0	0 0 0 0	1 1 X 0 1	0 0) ((0		olay	Initializati Sets to 4 In this ca instructio Sets 4-bi character character Turn on 6 Set mode right, at the	Description on. No display appears, -bit operation. se, operation is handled as 8-bits by initialization, and only this in completes with one write. It operation and selests 1-line display and 5x7 dot of font on and resetting is needed. (number of display lines and of fonts cannot be changed hence after.)

A continuación veremos una aplicación típica de manejo de display a 8 bits de datos, la forma de envío de los distintos caracteres es por el método de demora fija, utilizando para ello un microcontrolador de la línea FLASH HC908 de Motorola.


El MCU elegido es el MC68HC908GP32 pero la aplicación es valida para cualquier MCU de la familia.

Si bien el método de demora fija, es el menos eficiente en cuanto a velocidad de transferencia de información desde el MCU al display, es también el más sencillo de implementar por el usuario sin experiencia previa. Si el lector evaluara conveniente el uso

de un método más eficiente para una aplicación específica, sugerimos consultar la nota de aplicación de Motorola AN 1745 (e-www.motorola.com, sección "Microcontrollers") y la Información técnica disponible en el Web Site de WINTEK CORP (www.wintek.com.tw).

A continuación veremos una aplicación típica de manejo de display a 8 bits de datos, la forma de envio de los distintos caracteres es por el método de demora fija.

El MCU elegido es el MC68HC908GP32 pero la aplicación es valida para cualquier MCU de la familia.



^{*} DISP8BIT.ASM – PROGRAMA DE APLICACION PARA DISPLAY LCD

* 16 CARACTERES X 2 LINEAS

```
*
 El display aquí usado es marca WINTEK modelo WM-C1602Q1GLY
  pero puede aplicarse a cualquier tipo de display LCD inteligente
 Se utilizará un MC68HC908GP32CP para esta aplicación, con la siguiente config.
 de puertos:
  PORTA ---- PTA0 a PTA7 como salida de datos a conectar a DB0 a DB7 respec.
  PORTC ---- PTC0 a PTC2 como salida líneas de control de la siguiente forma:
 PTC0 ---- R/W
* PTC1 ---- RS
                                                                    *
* PTC2 ---- E
********************************
   base 10T
                                   ;Base Decimal por Default
   include "gp32head.asm"
                                 ; Equates grales. p/ GP32
*****
   EQUATES
*****
           EQU $0040
RAMSPACE
                                    ;Comienzo de la RAM en el GP32
FLASHSPACE EQU $8000
                                    ;Comienzo de la FLASH en el GP32
******
* VARIABLES RAM *
******
              ORG RAMSPACE
                                     ;Comienzo de la RAM
TEMPA
             RMB 1
                                     ;Almacenamiento Temporal del ACC
TEMPX
             RMB 1
                                     ;Almacenamiento temporal de X
             RMB 2
TEMPHX
                                     ;Almacenamiento Temporal del H:X
            RMB 1
PANTALLAS
                                     ;Cdor. Tot. de pantallas a mostrar
DELAY1S
             RMB 1
                                     ;Cdor. Delay de 1 seg. (20 x 50mS)
; INICIALIZACIÓN DEL 908GP32
;Setup de los Configuration Registers
```

```
Tel: (5411) 4375- 3366 Fax: (5411) 4325-8076
;-----
             MOV #$0B,CONFIG1
START
                                   ;Set LVI5OR3 and COPD, enable STOP
             MOV #$03,CONFIG2
                                   ;Selecciono Fbus como SCI clock
             NOP
             NOP
             MOV #$00,PORTA
             MOV #$FF,DDRA
                                   ; PORT A todo como SALIDA
             MOV #00, PORTA
             MOV #$00,PORTB
             MOV #$00,DDRB
                                   ; PORT B todo como entrada
             MOV #$00,PORTB
             MOV #$00,PORTC
             MOV #$0F,DDRC
                                   ; PORT C PTC0/3 ->OUT, PTC4/6 ->IN
             MOV #$00, PORTC
             MOV #$00, PORTD
             MOV #$00,DDRD
                                   ; PORT D todo como entrada
             MOV #$00,PORTD
             MOV #$00,PTAPUE
                                   ; PORT A sin PULL UPS
             MOV #$00,PTCPUE
                                   ; PORT C sin PULL UPS
             MOV #$00,PTDPUE
                                   ; PORT D sin PULL UPS
             SEI
                                    ; I MASK = 1 -> NO USO INTS
                                    ; para esta aplicación
```

```
* PREPARO EL DISPLAY p/ POWER ON RESET *
* del mismo (Ver gráficos aparte) y su *
* inicialización de comandos
**********
            JSR DLY50
                                ; DELAY 50MS DESPUES DEL POWER-ON
            LDA #$38
                                ;FUNTION SET -8 BITS - 2LINE - 5X7
            JSR WCTRL
            JSR DLY50
                                ;DELAY 50MS
            LDA #$38
                                ;FUNTION SET - 8BITS - 2LINE - 5X7
            JSR WCTRL
            JSR DLY50
            LDA #$38
                                ;FUNTION SET - 8BITS - 2LINE - 5X7
            JSR WCTRL
            LDA #$38
                                ;FUNTION SET - 8BITS - 2LINE - 5X7
            JSR WCTRL
            LDA #$08
                                ;DISPLAY OFF
            JSR WCTRL
            LDA #$01
                                ;CLEAR DISPLAY
            JSR WCTRL
                                ;ENTRY MODE - INC ADDR - NO SHIFT
            LDA #$06
            JSR WCTRL
*******
* INICIALIZO EL LCD *
```

```
Tel: (5411) 4375- 3366 Fax: (5411) 4325-8076
```

```
LDA #$01
                                 ;CLEAR DISPLAY
             JSR WCTRL
             LDA #$02
                                 ; HOME CURSOR
             JSR WCTRL
             LDA #$38
                                 ;FUNTION SET - 8BITS - 2LINE - 5X7
             JSR WCTRL
             LDA #$0C
                                 ;DISPLAY ON , CURSOR OFF
             JSR WCTRL
             LDA #$06
                                 ;ENTRY MODE - INC ADDR - NO SHIFT
             JSR WCTRL
*******
* RUTINA PRESENTACION
* PANTALLAS EN DISPLAY *
* CADA 1 SEG APROX.
;H=$00, solo uso X como indice
             CLRH
AGAIN
            CLRX
                                 ; APUNTO X AL COMIENZO DE TABLA
            MOV #5,PANTALLAS
                                 ;5 PANTALLAS A MOSTRAR !!!
NEW_SCREEN
            MOV #20,DELAY1S
                                 ;CADA PANTALLA ESTARA 1 SEG
             JSR DISPLAY L1
             JSR DISPLAY L2
LOOP1S
             JSR DLY50
             DEC DELAY1S
             BNE LOOP1S
             DEC PANTALLAS
             BNE NEW SCREEN
             BRA AGAIN
************
* DISPLAY_L1/L2 - SUBRUTINAS DE PRESENTACION DE 1ERA*
            Y 2DA LINEA DISPLAY LCD CON MENSAJES *
* CONTENIDOS EN UNA TABLA ( TDISPLAY )
* SE ENTRA CON VALOR DE X ( COMIENZO DEL STRING )
* Y SOLA LA RUTINA INCREMENTA X PARA MOSTRAR TODO
* EL STRING EN PANTALLA
DISPLAY L1
            LDA #$02
                                 ; POSICION HOME
             JSR WCTRL
            BRA DISPLOOP
DISPLAY L2
            LDA #$C0
                                 ; POSICIONO COMIENZO 2DA LINEA
             JSR WCTRL
            LDA TDISPLAY,X
                               ;ACC->1ER CARAC. DE TABLA TDISPLAY
DISPLOOP
             CMP #4
                                 ;SI CARACTER=$04 -> FIN 1ER STRING
             BEQ STE
                                 ;SINO SIGO MOSTRANDO OTRO CARACTER
                                 ;ESCRIBO CARACTER EN LCD
             JSR WDAT
                                 ; INCR. PUNTERO AL PROX. CAR.
             INCX
             BRA DISPLOOP
                                 ;BUSCO OTRO CARACTER
STE
                                 ; ***** RETORNO *******
             RTS
**************
* WCTRL - RUTINA DE ESCRITURA DE PALABRAS DE CONTROL *
* EN EL LCD, ENTRO CON UN COMANDO EN EL ACC Y
```

```
Tel: (5411) 4375- 3366 Fax: (5411) 4325-8076
```

```
* RETORNO CON EL VALOR ORIGINAL DE X
* DELAY 4,5 mS SI ACC=$01 O $02 SINO DE 120 MICROSEG *
****************
            STX TEMPX
WCTRL
                                ;SALVO X
            STHX TEMPHX
                               ;SALVO H:X
                               ;ESCRIBO PALABRA CONTROL EN LCD
            STA PORTA
            BSET 2, PORTC
                               ;E--->1 PULSO PARA ACTIVAR LCD
            NOP
            BCLR 2, PORTC
                                ;E--->0
            LDX #160
                                ;160*6*125nSEG = 120 MICROSEG
L120U
            DECX
                                ; DELAY LOOP 120 MICROSEG
            NOP
            NOP
                          ;160,159.....0
            BNE L120U
            CMP #$02
                               ;SI COMANDOS = 01 o 02 EXTRA DELAY
            BHI ARN5M
                               ;SI COMANDOS >02 -> LO SALTO
            LDHX #2164
L5M
            JSR ANRTS
                               JSR Y RTS TOMAN 9 CICLOS
            AIX #-1
                                ;2164x(9+2+3+3)x125Nseg = 4,6mS
            CPHX #0
            BNE L5M
            LDX TEMPX
ARN5M
                                ;RESTAURO X
            LDHX TEMPHX
                                ;RESTAURO H:X
ANRTS
            RTS
                                 ; * * * RETORNO * * * *
* WDAT - RUTINA DE ESCRITURA DE DATOS EN EL LCD
      ENTRO CON PALABRA DE DATOS EN EL ACC Y RETORNO
      CON VALOR ORIGINAL DE X Y A
STX TEMPX
WDAT
                                ;SALVO X
            STHX TEMPX
                                ;SALVO H:X
            STA TEMPA
                                ;SALVO A
            STA PORTA
                                ;ESCRIBO PALABRA DATOS EN EL LCD
            BSET 1, PORTC
                                ;RS -->1
            BSET 2, PORTC
                                ;E--->1 PULSO PARA LCD
            NOP
            BCLR 2,PORTC
BCLR 1,PORTC
                                ; E - - > 0
                                ;RS-->0
            LDX #160
                                ;160*6*125nSEG = 120 MICROSEG
                                ; DELAY LOOP 120 MICROSEG
L120
            DECX
            NOP
            NOP
            BNE L120
                               ;160,159...0
            LDA TEMPA
                                ; RESTAURO ACC
            LDX TEMPX
                                ;RESTAURO X
            LDHX TEMPHX
                                ;RESTAURO H:X
                                ;*** RETORNO ***
            RTS
*******
* DLY50
* RUTINA DELAY 50 mS
```

```
* con Xtal= 32 Mhz
* T = 125 \text{ nSeq}
*******
                                  ;Salvo ACC en RAM
             STA TEMPA
DLY50
             STHX TEMPXH
                                  ;Salvo X:H en RAM
             LDHX #10000
                                  ;H:X <-- 10000 para llegar a 10mS
             LDA #5
                                  ;ACC <-- 5 para llegar a 50mS
OUTLP1
                                  ¡Loop interno de 10mS ya que:
            LDHX #10000
INNRLP1
                                  ;10000 x8 ciclos x 125 nS = 10mS
            AIX #-1
             CPHX #0
             BNE INNRLP1
             DECA
                                  ; ACC = 5, 4, 3...0
                                  ;5 \times 10 \text{ mS} = 50 \text{ mSeg}
             BNE OUTLP1
             LDA TEMPA
                                  ;RECOBRO EL ACC DE LA RAM
             LDHX TEMPXH
                                 ;RECOBRO X:H DE LA RAM
             RTS
                                  ; RETORNO
**********
```

```
TDISPLAY
             FCB 'BIENVENIDO !!!!!' ;
              FCB 'AL MUNDO DEL...';
              FCB $04
                                    ;STE
              FCB 'DISPLAY INTELIG.';
              FCB 'LCD 16 X 2 LIN. ' ;
              FCB $04
                                    ;STE
              FCB 'WINTEK CORP....';
              FCB 'TIENE UN MODELO ' ;
              FCB $04
                                    ;STE
              FCB 'PARA CADA UNA DE' ;
              FCB 'LAS APLICACIONES' ;
                                    ;STE
              FCB $04
              FCB 'POSIBLES QUE UD.';
              FCB 'HABIA ESPERADO..' ;
              FCB $04
                                    ;STE
```

```
* -----
```

^{*} ASIGNACION DE VECTORES

^{* ------}

```
* LOS VECTORES NO UTILIZADOS POR LAS INT'S APUNTARAN A "START"
```

* -----

ORG TBVEC FDB START ORG ADCVEC FDB START ORG KBIVEC FDB START ORG SCITXVEC FDB START ORG SCIRXVEC FDB START ORG SCIERVEC FDB START ORG SPITXVEC FDB START ORG SPIRXVEC FDB START ORG T2OFVEC FDB START ORG T2CH1VEC FDB START ORG T2CH0VEC FDB START ORG T10FVEC FDB START ORG T1CH1VEC FDB START ORG T1CH0VEC FDB START ORG PLLVEC FDB START ORG IRQ1VEC FDB START ORG SWIVEC FDB START ORG RESETVEC FDB START

Hasta aquí, se há mostrado la aplicación típica de control del display a 8 bits de datos, ahora veremos un ejemplo de control a 4 bits de datos, que como se dijo anteriormente, es más eficiente en el uso de líneas dedicadas para controlarlo (7 líneas total, contra 11 líneas del método anterior), pero paga el precio de ser menos "claro" la forma de manejo del mismo.

Para este ejemplo, se há utilizado nuevamente un MC68HC908GP32, pero este ejemplo puede aplicarse a cualquier otro MCU de la familia HC908 FLASH de Motorola.

* ************************************

*PROGRAMA APLICATIVO DEL USO DE UN DISPLAY LCD INTELIGENTE

```
* POR MEDIO DE 4 BITS DE DATOS --> TOTAL 7 LINEAS DE CONTROL
 Se usará el método de demora fija entre envio y envio de los distintos caracteres al
  display.....
   MC68HC908GP32 Interface
* LCD module (1x16 display, 4-bit interface)
* Conexiones hechas al PORT B
* PB4-PB7 = DB4-DB7
* PB1 = RS (register select)
* PB2 = RW (Read! Write)
* PB3 = E LCD (enable)
**************************
 base 10T
                          :Base Decimal como default
 include "gp32head.asm"
                          ;Header file defines registers, etc.
* ______
* CHANGE THIS TO MATCH OPPORATING FREQUENCY (MHz)
* To allow adaptable delays.
BUSFREO EOU 4
USCOUNT EQU $0E
USDELAY EQU BUSFREQ*USCOUNT
; Miscellaneous equates
DELAYVAL EQU $50 ;Default value for delays
PRESCALER2 EQU
                     %0000010 ;Prescaler bits determine timer freq.
                     %00000000 ;Prescaler bits determine timer freq.
PRESCALER EQU
; ASCII character definitions
         EQU $20 ;ASCII space
SPACE
EOT
       EQU $04 ;ASCII end-of-text
CR
       EQU $0D ;ASCII carriage return
LF
      EQU $0A ;ASCII linefeed
TABLEEND EQU $FF
;LCD Control lines, E = enable, RS = Register Select (Data vs. Instruction)
;R/W = Read! Write; Referidas a los pines del PORT B
```

Solis 225 / 227 / 229 – Cap. Fed. – Tel: (5411) 4375- 3366 Fax: (5411)	
RS EQU 1 RW EQU 2 E_LCD EQU 3	
MAXCHARS EQU \$10 ;Ma MAXLINE EQU \$08	xima cantidad de caracteres por linea del LCD
TOFMAXCOUNT EQU 2; ;TOFMAXCOUNT EQU 1	Changed for monitor mode debugging (/2)
** RAM variables	
ORG RAMSPACE	
TempVar RMB 1	;Counter variable for delay ;Temporary 8-bit storage ;Temporary 16-bit storage
*	
MsgIndex RMB 2	Counter variable ;Index counter variable ;Stores starting point of string
* Program code	
*ORG FLASHSPACE	

Electrocomponentes S.A.

Start:

;-----;908GP32 Initialization ;Setup configuration registers <u>:-----</u> MOV #\$0B,CONFIG1 ;Set LVI5OR3 and COPD, enable STOP MOV #\$03,CONFIG2 ;Select bus as SCI clock source **NOP NOP CLR PORTA** CLR PORTB **CLR PORTC CLR PORTD** MOV #\$FF.PTAPUE :PORT A PULLUP ENABLE REGISTER PORT C PULLUP ENABLE REGISTER MOV #\$6F,PTCPUE MOV #\$FF.PTDPUE :PORT D PULLUP ENABLE REGISTER MOV #\$FF,DDRB PORT B SET TO OUTPUTS :PORT C BIT4 AS OUTPUT FOR LED MOV #\$10.DDRC CLR EventCount _____ * Main program code * _____ :-----;Port B setup for LCD module :-----BCLR RS.PORTB ;Preset control line output levels **BCLR RW, PORTB** BCLR E LCD,PORTB MOV #\$FE,DDRB ;Setup PB1-PB7 as outputs for LCD **BCLR RS.PORTB** Preset control line output levels **BCLR RW.PORTB** BCLR E_LCD,PORTB CLI ;clear interupt mask :-----;LCD setup :-----JSR LCDInit ;Initialize LCD -----* Demo program 1

Electrocomponentes S.A.

Tel: (5411) 4375- 3366 Fax: (5411) 4325-8076

Solis 225 / 227 / 229 - Cap. Fed. - (1078) - Buenos Aires - Argentina

```
Electrocomponentes S.A.
Solis 225 / 227 / 229 - Cap. Fed. - (1078) - Buenos Aires - Argentina
Tel: (5411) 4375- 3366 Fax: (5411) 4325-8076
* Start listing information strings
InfoDemo:
        LDHX #FeatureList
                             ;Load offset of desired string
MainLoop:
        JSR ShowString
        LDA #$FA
                           ;Number of mS delay between strings
                           F0 = 240 \text{mS } X \text{ 4 times} = 1 \text{S Aprox}
        JSR msDelay
        LDA #$FA
        JSR msDelay
        LDA #$FA
        JSR msDelay
        LDA #$FA
        JSR msDelay
NextMsg
            LDA .X
        CMP #EOT
        BEO GotNext
        AIX #1
        BRA NextMsg
GotNext
           AIX #1
        LDA.X
        CMP #TABLEEND
        BEQ InfoDemo
        BRA MainLoop
  "0123456789ABCDEF" Max Characters
FeatureList:
 FCB "BIENVENIDOS!!!"
 FCB EOT
 FCB "AL INTERESANTE "
 FCB EOT
 FCB "MUNDO....."
 FCB EOT
 FCB "DE LOS NUEVOS"
 FCB EOT
 FCB "DERIVATIVOS HC08"
 FCB EOT
 FCB "FLASH MOTOROLA"
 FCB EOT
```

FCB "MC68HC908GR8/4"

Tel: (5411) 4375- 3366 Fax: (5411) 4325-8076 FCB EOT FCB "MC68HC908MR32/16" FCB EOT FCB "MC68HC908SR12" FCB EOT FCB "MC68HC908KX8/2" FCB EOT FCB "MC68HC908RK2" FCB EOT FCB "MC68HC908JB8" FCB EOT FCB "Y AL PORTFOLIO" FCB EOT FCB "DE HERRAMIENTAS" FCB EOT FCB "PARA DESARROLLO" FCB EOT FCB "EVAL08GP / JL" FCB EOT FCB "E-FLASH08!!" FCB EOT FCB "Y MUCHO MAS !!" FCB EOT FCB "*** FIN ******" FCB EOT FCB TABLEEND * _____ * LCD INITIALIZATION * Called on startup to initialize the LCD into 4-bit mode * Don't use the LCDControl subroutine at first, because initially * the LCD is in 8-bit interface mode. * _____ LCDInit: ;8-bit interface at first LDA #\$0F ;Wait 15ms JSR msDelay LDA #\$30 ;Function set JSR LCD8Ctrl LDA #5 ;Wait 5ms JSR msDelay

Electrocomponentes S.A.

Solis 225 / 227 / 229 - Cap. Fed. - (1078) - Buenos Aires - Argentina

Electrocomponentes S.A.
Solis 225 / 227 / 229 - Cap. Fed. - (1078) - Buenos Aires - Argentina
Tel: (5411) 4375- 3366 Fax: (5411) 4325-8076

LDA #\$30 ;Function set

JSR LCD8Ctrl

LDA #1 ;Wait 1ms

JSR msDelay

LDA #\$30 ;Function set

JSR LCD8Ctrl

LDA #\$20 ;Function set first set up 4-bit

JSR LCD8Ctrl

;-----

;4-bit operation

·,-----

LDA #\$28 ;Second 4-bit function set

JSR LCDCtrl ;Also 2-line setup

LDA #\$06 ;Increment, no shift

JSR LCDCtrl

LDA #\$01 ;Clear display, cursor home

JSR LCDCtrl

LDA #\$0C ;Display on, cursor off, blink off

JSR LCDCtrl

RTS

* ______

LCD8Ctrl:

AND #\$F0 ;Mask out lower data bits PSHA ;Store value to send temporarily LDA PORTB ;Don't change other PORTB pins

AND #\$0F :Mask out UPPER nibble

ADD 1,SP ;Add value to send STA PORTB ;Store to PORTB

BSET E_LCD,PORTB ;Toggle enable line

^{*} If the LCD is in 8-bit mode, just send the upper data bits through

^{*} the lower port C bits

^{*} Acc contains control byte

^{*} _____

BCLR E_LCD,PORTB

JSR _40usDelay ;40us setup time **PULA** :Deallocate stack data RTS * _____ * Write LCD control byte in 4-bit mode * For 4-bit mode, need to send the nibbles one at a time, high nibble first * Acc contains control byte to send * This routine is also used for Address writes to LCD, when MSbit of * data byte is set. (i.e. \$80 for address 00) * ______ LCDCtrl: ;Upper nibble :-----PSHA ;Store data on stack AND #\$F0 ;Mask out lower nibble **PSHA** ;Store upper nibble on stack :Load PORTB contents LDA PORTB :Mask out UPPER nibble AND #\$0F ADD 1.SP ;Add the data nibble STA PORTB ;Present upper nibble to LCD BSET E LCD,PORTB ;Toggle Enable line BCLR E LCD,PORTB JSR _40usDelay ;40us setup time ;Lower nibble PULA ;Deallocate last temp storage PULA ;Get original data byte AND #\$0F ;Mask out upper nibble NSA ;Put LOWER nibble in UPPER nibble PSHA :Store onto stack LDA PORTB ;Get existing PORTB data AND #\$0F ;Mask out lower nibble ADD 1,SP ;Add lower nibble of data byte STA PORTB ;Store to PORTB

BSET E_LCD,PORTB ;Toggle Enable line BCLR E LCD,PORTB **PULA** ;Deallocate temp storage CMP #\$10 ;Longer delay for commands 1 or 2 BEQ LCLonger CMP #\$20 **BEQ LCLonger** JSR _40usDelay ;40us for any other command RTS :Return LCLonger: LDA #2 JSR msDelay **RTS** * _____ * Write data byte to LCD, using 4-bit mode * Acc contains data byte to send * _____ LCDData: :-----;First nibble PSHA ;Store data on stack temporarily ;Mask out lower nibble AND #\$F0 PSHA ;Store upper nibble on stack :Load PORTB contents LDA PORTB AND #\$0F :Mask out UPPER nibble ;Add the data nibble ADD 1,SP STA PORTB ;Store to PORTB BSET RS,PORTB :Set RS for control BSET E LCD,PORTB ;Toggle Enable line BCLR E LCD,PORTB :Second nibble

Tel: (5411) 4375- 3366 Fax: (5411) 4325-8076 PULA ;Deallocate temp storage **PULA** ;Get original data AND #\$0F ;Mask out upper nibble ;Put LOWER nibble in UPPER port pins NSA **PSHA** ;Store onto stack LDA PORTB AND #\$0F ADD 1.SP STA PORTB BSET E LCD,PORTB ;Toggle enable line BCLR E_LCD,PORTB JSR _40usDelay ;40us setup time ;40us setup time JSR _40usDelay ;Clear RS for data BCLR RS,PORTB JSR _40usDelay ;40us setup time JSR _40usDelay ;40us setup time PULA ;Deallocate temp storage RTS * Clear the LCD display by sending the appropriate command byte * ______ LCDClear: ;Clear display AND home cursor LDA #\$01 JSR LCDCtrl **RTS** LCDHome LDA #\$02 JSR LCDCtrl RTS

Solis 225 / 227 / 229 - Cap. Fed. - (1078) - Buenos Aires - Argentina


* -----

Electrocomponentes S.A.

^{*} DELAY ROUTINES

```
Electrocomponentes S.A.
Solis 225 / 227 / 229 - Cap. Fed. - (1078) - Buenos Aires - Argentina
Tel: (5411) 4375- 3366 Fax: (5411) 4325-8076
* 1ms delay loop, causes _roughly_ 1.3ms delay @ fop = 8MHz
* uses constant for loop control
* cycles = 4 + X(6+7+1275) + 3 + 6
* \text{ cycles} = 13 + X(1288)
* where X is value loaded into Acc
* Causes 1.3ms delay for BUSFREQ values of (1-8 integer values)
* _____
_1msDelay:
                   ;2 cycles
      PSHA
      LDA #BUSFREQ
         DBNZA DLSub
DLLoop
                          ;3
      BRA DLDone
DLSub
         MOV #$FF.Counter
                          ;4
      DBNZ Counter,*
      BRA DLLoop
                      :3
         PULA
                      ;2
DLDone
                  :4
      RTS
* _____
* Variable ms delay loop
* Calls DelayLoop Acc number of times
* _____
msDelay JSR _1msDelay
      DBNZA msDelay
      RTS
* ______
* 40usec delay routine. Important for LCD module, which requires 40us
* delay for many of its commands, including the "data setup time"
* 6+X(3)
* Where X = BUSFREQ*USCOUNT = USDELAY
* Provides _roughly_ 40us delay
* _____
40usDelay:
      LDA #BUSFREQ*USCOUNT ;2
      DBNZA *
                    ;3
      RTS
  _____
```

* Big delay loop



```
Electrocomponentes S.A.
Solis 225 / 227 / 229 - Cap. Fed. - (1078) - Buenos Aires - Argentina
Tel: (5411) 4375- 3366 Fax: (5411) 4325-8076
* Initialize the message variables for the desired output string
* Register A contains the offset of desired message.
            STHX MsgIndex
LoadMsg
                                ;Setup the message index
        STHX MsgStart
                       ;Store the start of the message
        RTS
*_____
* Update the LCD with current portion of string to be displayed
*_____
UpdateLCD:
        LDHX MsgIndex
                            ;Start at current index into message
                           ;Show current portion of string
        JSR ShowString
       LDHX MsgIndex
       CPHX MsgStart
       BNE ULgo
       LDA #$30
        JSR msDelay
ULgo
          AIX #1
       STHX MsgIndex
                            :Increment the index
                      :Return
* Show the current string portion on the display.
* When called, the X register contains the index offset.
*_____
ShowString:
        JSR LCDClear
                         ;Clear the counter variable
        CLR Count
       LDA #$80
                         :Starting address
       JSR LCDCtrl
NextByte:
       LDA ,X
                        ;Load ASCII byte of string
                          :Check for end of string
       CMP #EOT
        BEQ Padding
                          :Last character reached
        JSR LCDData
        AIX #1
                        ;Increment the index
       INC Count
                         :Increment the counter
       LDA Count
                         ;Check the counter
       CMP #MAXCHARS
                               ;for LCD display length
                         ;End of display line reached
        BEQ Done
       CMP #MAXLINE
       BNE SSCont
       LDA #$C0
                         :Set address for line 2
        JSR LCDCtrl
```

;Ready the next byte

SSCont

BRA NextByte

```
Solis 225 / 227 / 229 - Cap. Fed. - (1078) - Buenos Aires - Argentina
Tel: (5411) 4375- 3366 Fax: (5411) 4325-8076
Padding
          LDA Count
                          ;Pad the rest of the display with spaces
                       ;See if string has scrolled off display
       CMP #$00
                       ;Need to reset string
       BEQ Reset
                            ;Check for end of display
       CMP #MAXCHARS
                       ;Finished displaying padding spaces
       BEQ Done
       INC Count
                      ;Increment counter
       JSR BlankSpace
                        ;Put space in current display position
       BRA Padding
                        ;Repeat
Reset
         JSR BlankSpace
                          ;Show a final space in first position
       LDHX MsgStart
                         ;Load start of message index
                      ;Compensate for INCX in UpdateLCD after RTS
       AIX #-1
       STHX MsgIndex
                          Record new message index
Done
                       :Return
* Sends an ASCII space character to the LCD
* ______
BlankSpace:
       LDA #$20
       JSR LCDData
       RTS
* ______
* VECTOR ASSIGNMENTS
 _____
* Trap unused vectors to indicate errors
* ______
       ORG TBVEC
       FDB Trap
       ORG ADCVEC
       FDB Trap
       ORG KBIVEC
       FDB Trap
       ORG SCITXVEC
       FDB Trap
       ORG SCIRXVEC
       FDB Trap
       ORG SCIERVEC
       FDB Trap
       ORG SPITXVEC
       FDB Trap
       ORG SPIRXVEC
       FDB Trap
       ORG T2OFVEC
       FDB Trap
       ORG T2CH1VEC
```

Electrocomponentes S.A.

Electrocomponentes S.A.
Solis 225 / 227 / 229 - Cap. Fed. - (1078) - Buenos Aires - Argentina
Tel: (5411) 4375- 3366 Fax: (5411) 4325-8076

FDB Trap

ORG T2CH0VEC

FDB Trap

ORG T10FVEC

FDB Trap

ORG T1CH1VEC

FDB Trap

ORG T1CH0VEC

FDB Trap

ORG PLLVEC

FDB Trap

ORG IRQ1VEC

FDB Trap

ORG SWIVEC

FDB Trap

ORG RESETVEC

FDB Start