



Simulating AMPSE netlists & testbenches

1) Download desired netlist from GitHub

- "tb_xxx.scs" corresponds to test bench
- Use de-sanitizer to put all the PDK information back

2) Include model file

- Include tech file path
- E.g.: include "YOUR_LIBRARY_PATH/Techfile_45nm.scs"
- If the testbench netlist doesn't have the module netlist, download the module netlist and include it in your testbench
- E.g.: include "YOUR_WORKAREA/MODULE.scs"
- Module netlist is uploaded in the same directory as testbench in GitHub

3) Simulate

In the terminal, type: "spectre tb_xxx.scs"