


Code Issues Pull requests Actions Projects Wiki Security Insights Settings

ᢪ main → ···

Digital-electronics-2 / Labs / 04-interrupts / Assignment.md



Lab 4: Unai Telletxea

Link to your Digital-electronics-2 GitHub repository:

https://github.com/UTAN25/Digital-electronics-2

Overflow times

1. Complete table with overflow times.

Module	Number of bits	1	8	32	64	128	256
Timer/Counter0	8	16us	128us		1ms		4ms
Timer/Counter1	16	4ms	33ms		262ms		1s

Timer/Counter2	8	16us	128us	512us	1ms	2ms	4ms
4							


Timer library

1. In your words, describe the difference between common C function and interrupt service routine.

- Functions have to be called every time we need to use them in the program. In a secuential way, They have no special priority and some cases like checking a botton, depending on the timing the information might be lost (if the button is pressed when the program is not looking for it).
- Interrupt service routine, when activated, they can interrupt the execution of the code and start processing the routine. In this way It is possible to give priority to certain tasks and leave the others for later.
- 2. Part of the header file listing with syntax highlighting, which defines settings for Timer/Counter0:

```
/**
  * @name Definitions of Timer/Counter0
  * @note F_CPU = 16 MHz
  */
/** @brief Stop timer, prescaler 000 --> STOP */
                                                                          TCCR0B &= ~((1<<CS02) | (1<<CS01) | (1<<CS00));
#define TIMO_stop()
/** @brief Set overflow, prescaler 001 --> 1 */
/** @brief Set overflow, prescaler 010 --> 8 */
\#define TIMO_overflow_128us() TCCR0B \&= \sim((1<<CS02) | (1<<CS00)); TCCR0B |= (1<<CS02) | (1<<CS00) |= (1<<CS
/** @brief Set overflow, prescaler 011 --> 64 */
#define TIMO_overflow_1ms() TCCR0B &= ~(1<<CS02); TCCR0B |= (1<<CS01) | (1<<CS00)
/** @brief Set overflow, prescaler 100 --> 256 */
/** @brief Set overflow, prescaler // 101 --> 1024 */
/** @brief Enable overflow interrupt, 1 --> enable */
#define TIMO_overflow_interrupt_enable() TIMSK0 |= (1<<TOIE0);</pre>
/** @brief Disable overflow interrupt, 0 --> disable */
#define TIMO_overflow_interrupt_disable() TIMSK0 &= ~(1<<TOIE0);</pre>
```

3. Flowchart figure for function <code>main()</code> and interrupt service routine <code>ISR(TIMER1_OVF_vect)</code> of application that ensures the flashing of one LED in the timer interruption. When the button is pressed, the blinking is faster, when the button is released, it is slower. Use only a timer overflow and not a delay library.



Knight Rider

1. Scheme of Knight Rider application with four LEDs and a push button, connected according to Multi-function shield. Connect AVR device, LEDs, resistors, push button, and supply voltage. The image can be drawn on a computer or by hand. Always name all components and their values!

