Lecture 16: Dynamic ILP and real systems

Wednesday, February 13, 2019 8:17 AM



• Real in-order designs


Real out-of-order designs

Dynamic ILP


Issues = gressing Wrong


- One Step in Finding ILP in Ludwe

- register renaming Ly bollen a projecter is written we rename it to a temp register future reads of the "architectural registr" instead use the temp raisty



Why dynamie ILP? fastr because of perallelism, not we ting Lan find more ILP than Static techniques 6 Some things not known until runtime (addresses) We know exactly what the hudwore is Losearch for ILP around control 1) it an fail





An out-of-order design (AMD Ryzen)

