

# **Getting Started Guide**

## IAR KickStart Kit™ for TI MSP430FR5739

This getting started guide briefly describes how to get started using IAR Embedded Workbench® with the TI MSP-EXP430FR5739 Experimenter's Board.

For more detailed information, see the IAR Embedded Workbench IDE Project Management and Building Guide and C-SPY Debugging Guide. These documents are available from the Help menu and IAR Information Center in the IAR Embedded Workbench IDE.

#### Features of the MSP-EXP430FR5739 Experimenter's Board

- Integrated TI MSP430FR5739 device
- USB debugging and programming interface
- 3-axis accelerometer
- NTC thermistor for temperature sensing
- 2 user input switches and a reset switch
- 8 LEDs for output display
- Connectivity to the MSP-EXP430F5438 Experimenter Board
- Connectivity to CCxxx radio daughter cards
- Easily accessible device pins for debugging purposes
- Separate power jumpers to measure power to the MSP430 and the RF daughter card. High quality stereo audio output
- User experience: Demo code with 4 modes to test FRAM features





#### Software installation

- 1 Download the latest IAR Embedded Workbench for MSP430 from www.iar.com/kit\_updates.
- 2 Run the software installer. It may take several minutes for the installation files to unpack.



Figure 1 - Software installer

- 3 Click **Install IAR Embedded Workbench** and follow the prompt instructions to install the software. We recommend that you use the default directories on your installation.
- 4 When you start IAR Embedded Workbench for the first time, the License Wizard will open. Choose **Register with IAR Systems to get an evaluation license** (the internet access is needed).



 $Figure\ 2\ - Register\ to\ get\ an\ evaluation\ license$ 

- 5 Click **Register**, choose a time or code size limited evaluation license, and then register to get your license number, which will be delivered to you via e-mail within a few minutes.
- **6** Activate the license in the License Wizard window.

You may register both the kickstart and the evaluation license, activate and switch in between from the **License Manager**. For further information, see the *IAR Embedded Workbench*, *Licensing Guide*, under the **User Guide** section in the **Information Center** (Figure 2).

We assume that you have already installed Java software in your computer. A free version is available from **www.java.com**.



## Hardware configuration

1 Connect the MSP-EXP430FR5739 evaluation board to the PC using the enclosed USB cable. The driver files will be automatically located and installed. This also supplies power to the board.

For more details, please read the MSP-EXP430FR5739 FRAM Experimenter Board User's Guide.

## Running example application

To take the full advantage of the example application, some working knowledge of IAR Embedded Workbench IDE is preferred. For a quick introduction, see the **GETTING STARTED** and the **TUTORIALS** in the **IAR Information Center for MSP430.** 

The example application described here is MSP-EXP430FR5739 Experimenter's Board User Experience Demo.

- 1 From the Start menu, start the IAR Embedded Workbench IDE by choosing **All Programs> IAR Systems> IAR Embedded Workbench for MSP430 x.xx > IAR Embedded Workbench.** You will get straight into the **IAR Information Center for MSP430**.
- 2 Click EXAMPLE PROJECTS and select Hardware boards>MSP-EXP430FR5739.




Figure 3 - IAR Information Center for MSP430

- 3 Open project MSP-EXP430FR5739 (click the icon).
- 4 Click **Choose** to select a destination folder to save a copy of this project for testing, so that the original project will not be updated for any changes you made during testing.
- **5** Read the demo description and make sure that the compilation target, at the top of the workspace window is set to Debug.






Figure 4 - Example description and compilation target

- 6 Choose **Project>Make** or click the **Make** button on the toolbar (Figure 5). The project should be compiled and linked without any errors (you may ignore the warnings).
- 7 Click the **Download and Debug** button **b** to download your program to the evaluation board.
- 8 Click the **Go** button to start the application. The user LED on the board will blink.



Figure 5 - IAR Embedded Workbench IDE - Menu and Toolbar

**9** Start the PC GUI application by double clicking FRAM\_GUI.exe, which is located under the IAR Embedded Workbench installation path

IAR Systems\Embedded Workbench 6.5\430\examples\examples\Hardware boards\MSP-EXP430FR5739\MSP-EXP430FR5739\FRAM GUI

**Note:** The Java software must be installed on your computer when running this application.




Figure 6 - PC GUI for FRAM User Experience Demo



- **10** Press switch S1 and S2 on the board to select the demo mode:
  - Press switch S1 for mode selection. After you press S1, LED8 through LED5 light up to show the corresponding mode.
  - Press switch S2 when inside a mode to turn off the display (LED and UART output). This is useful when measuring power.
  - Press S1 to exit a mode and return to mode selection.
- 11 To stop C-SPY, click the **Break** button ...
- **12** To exit C-SPY, click the **Stop Debugging** button **X**.

## Learning more

You can find more information about TI FRAM technology and kit documentation at

http://www.ti.com/fram and http://www.ti.com/tool/msp-exp430fr5739

For the latest updates on the kit and IAR Embedded Workbench for MSP430, please check at <a href="http://www.iar.com/kit\_updates">http://www.iar.com/kit\_updates</a> and <a href="http://www.iar.com/ew430">http://www.iar.com/kit\_updates</a> and <a href="http://www.iar.com/ew430">http://www.iar.com/kit\_updates</a> and <a href="http://www.iar.com/ew430">http://www.iar.com/ew430</a>



## **Troubleshooting**

If you are unable to find the cause of a problem, try resetting the evaluation board by using the reset button on the board. Then restart the C-SPY Debugger in the IAR Embedded Workbench IDE. You can also try disconnecting and reconnecting the power to the evaluation board, pressing the reset button and then restarting C-SPY.

#### Disclaimer

Information given in this document is intended as a help for the user. IAR Systems shall not be held liable for any losses or problems arising from using the information given in this document. Neither whole nor any part of the information in this document may be adapted or reproduced.

IAR KickStart Kit content	Trademarks etc.
<ul> <li>TI MSP-EXP430FR5739         Experimenter's Board     </li> <li>USB cable</li> </ul>	IAR Systems, IAR Embedded Workbench, C-SPY, visualSTATE, IAR KickStart Kit, I-jet, IAR and the IAR Systems logotype are trademarks or registered trademarks owned by IAR Systems AB.
IAR Getting Started Guide	All other trademarks or registered trademarks mentioned in this document are the properties of their respective owners.  © Copyright 2014 IAR Systems AB
	Part number: GS-MSP-EXP430FR5739-4 The fourth edition: February 2014