

NX Post Configurator 013 – Access levels & Encryption

Unrestricted © Siemens AG 2020



Restrict and Protect the Post Processor

Overview





The post processor can be protected

- Limited it to certain users (Sold-To ID)
- Limited to a certain expiration date


The Tcl code files of the post processor can be encrypted

- Not human readable
- Cannot be changed
- The IP within is protected

Note: This feature is only available with *Full License*.

Overview






Note: This feature is only visible with *Full License*.

Overview






- 1: List of licened users (SoldTo ids)
- 2: Add a new licensed user (SoldTo id)
- 3: Add an expiration date (at which date is stops running)

Add a new licensed user






- 1. Click Add Sold-To ID
- 2. Enter the Sold-To ID which should be allowed to execute and open this post processor
- 3. Hit enter.

Note: The own SoldTo id needs to be added as well, otherwise the Post will not run anymore on the own system.

How to find the correct Sold-To ID of an user?






How to find the correct Sold-To ID of an user? It is shown in at the beginning of the log file

- 1. In NX: File → Help → Log File
- 2. It is logged after: Server ID:

```
Server ID: HERE_WOULD_BE_THE_SOLDTO
Webkey Access Code: server module
License File Issuer: Siemens PLM, Inc,
Flex Daemon Version: 11.10
Vendor Daemon Version String: 6.4
Toolkit Version: 6.4.4.1
```

Expiration Date





- 1. Select Specify in the Expiration Date menu
- 2. Select the desired date in the Date fields
- 3. Once you are done, click OK

This will...

- encrypt all open Tcl files
- lock the post processor to the specified settings


Note:



License the post processor & Ship to Customer

License the post processor & Ship to Customer





In order for the protection take effect:

1. Save and remove the original source Tcl file from the folder delivered to customers (Move in the example FanucTestPost3_service_fanuc.tcl)

Attention: Keep the original Tcl at a safe location for later reuse as there is no decryption functionality! All the remaining files in the folder are required.

Shipping the Post Processor - Remarks




- When shipping Post Processor to Customer the whole Post Processor needs to be shipped to Customer
- The Process Processor always needs all files, no files can be removed (besides the original Tcl files)
- Versioning of Post Processor needs to be done manually, a simple copy of the folder is sufficient

ē	
Customer	■ Bin
5	Controller
<u>S</u>	libraries
7	FanucTestPost3.cdl
	FanucTestPost3.def
9	FanucTestPost3.psc
end	FanucTestPost3.pui
	FanucTestPost3.tcl
Š	FanucTestPost3_custom.pce
	FanucTestPost3_mtb.pce
	FanucTestPost3_service_fanuc.pce
	machine_ootb_5ax_fanuc.pce
	oem_ootb_5ax_fanuc.def
	oem_ootb_5ax_fanuc.pce

Encryption





Encrypted PCE files


- are not human readable
- cannot be changed

Note: There is no way to decrypt PCE back to Tcl files.

Unrestricted © Siemens AG 2020
Siemens PLM Software


About the Protection and Encryption





Note: More information about the expired license is outputted to the syslog.

Post Configurator will prefer .pce over .tcl if both exist.



Note: If there are both file types with the same file name, Post Configurator will prefer the pce file and if license not valid you cannot open the post

How to revert the encryption:

- Remove encrypted layers (.pce)
- 2. Replace with the original source code file (.tcl)

Q&A





Thomas Jenensch

Product Portfolio Lead NX CAM Infrastructure Manufacturing Engineering Software

Nonnendammallee 101 5. OG, Bauteil C D-13629 Berlin, Germany Tel. :+49 (30) 46777 535

thomas.jenensch@siemens.com www.siemens.com/plm

Siemens Manufacturing Forum www.siemens.com/plm/nxmanufacturingforum

Realize Innovation