


NX Post Configurator 011 – Pretreatment

Unrestricted © Siemens AG 2020

Postprocessing






Unrestricted © Siemens AG 2020
Siemens PLM Software

Postprocessing with Pretreatment







Unrestricted © Siemens AG 2020
Siemens PLM Software

Collect variable of UDE







252 LIB_GE_command_buffer_edit_prepend LIB_CTRL_parameter_definition DEF_CAMTOL myProc _myTag
253

Collect variables



```
proc LIB_SPF_pt_additional_variables_WS {} {
  LIB_SPF_pretreatment_add_var MOM_myPT mom_myValue 0
}
```

- Add a procedure named LIB_SPF_pt_additional_variables_xxx to collect variables
- With the command LIB_SPF_pretreatment_add_var name the MOM-event in which the variable is set/ available

Collect variables from operations



- Cycle thru the operation list to get the values from each operation
- If no value is set the variable is string.empty

Collect variables before start of path



```
!62
!63 MOM_output_literal ";---> HeaderVar: [LIB_PT_get_header_var mom_myValue]"
!64
```

 Use LIB_PT_get_header_var instead to access variables that precede the first MOM_start_of_path.

Q&A





Thomas Jenensch

Product Portfolio Lead NX CAM Infrastructure Manufacturing Engineering Software

Nonnendammallee 101 5. OG, Bauteil C D-13629 Berlin, Germany Tel. :+49 (30) 46777 535

thomas.jenensch@siemens.com www.siemens.com/plm

Siemens Manufacturing Forum www.siemens.com/olm/nxmanufacturingforum

Realize Innovation