## First, make an implant:

https://knowledge.autodesk.com/community/screencast/e2d2ce50-7afa-4d00-a959-b472e75504fd Second, make a screw attachment arm:

https://knowledge.autodesk.com/community/screencast/f108f929-814f-4b80-88d4-f1173e3b126e (Optional) Third, make a hole through the attachment arm and sphere:

https://knowledge.autodesk.com/community/screencast/95b632af-a998-497e-ab5f-031518697e4e