



TrueFace6000 Back to Back (Connection Diagram)



TrueFace6000 with Push Button (Connection Diagram)



TrueFace6000 with any Wiegand Reader (Connection Diagram)

