



## Jaluino connectors










## Arduino connectors



RD6 <=> Digital 7
RB3/CCP2\* <=> Digital 6/PWM
RC1/CCP2\* <=> Digital 5/PWM
RC5 <=> Digital 4
RC2/CCP1 <=> Digital 3/PWM
RC4 <=> Digital 2
RC6/TX <=> Digital 1/TX
RC7/RX <=> Digital 1/RX

Mapping

RA3/AN3/VREF+ <=> AREF GND <=> GND RB6 <=> Digital 13 RB5 <=> Digital 12 RB4 <=> Digital 11 RB2 <=> Digital 10 RB1 <=> Digital 9 RB0 <=> Digital 8 Analog in RA0 1 RA1 2 RA2 3 RA2 3 RA5 4 RE0 5 RE1 6

RA0/AN0 <=> Analog 0 RA1/AN1 <=> Analog 1 RA2/AN2 <=> Analog 2 RA5/AN4 <=> Analog 3 RE0/AN5 <=> Analog 4 RE1/AN6 <=> Analog 5 POWER
RESET 1
3.3V 2
5V 3
GND 4
GND 5
VIN 6

RESET <=> RESET 3.3V <=> 3.3V 5V <=> 5V GND <=> GND GND <=> GND VIN <=> VIN