
URPEKARI PROIEKTUA, URPEKARI SQUIDWORKS & GALERNA UAS

TAP – Tiny Address Protocol

Started: 2025/07

Last revised: 2026/10
Link-layer detailing, routing.
Renewed explanations. Branding.





Authors

Authors	Affiliation	Sections
Erlantz Alonso	URPEKARI SQUIDWORKS, Galerna UAS	General TAP design
		Embedded implementation
Gaizka González	URPEKARI SQUIDWORKS	General TAP design
		Base station implementation
Unai Izaguirre	URPEKARI SQUIDWORKS	General TAP design

Index

URPEKARI PROIEKTUA, URPEKARI SQUIDWORKS & GALERNA UAS....1
TAP – Tiny Address Protocol....1
Authors....2
Index....3
Motivation....4
Design notes....5
TAP Signalling components....6
Address Header....6
Message trailer....6
Message types....7
ACK/NACK – 000....8
DIRECT_COMMAND – 001....9
Urpekari implementation of Direct_Command....9
INDIRECT_COMMAND - 002....10
Boolean arrays for DIRECT_COMMAND and INDIRECT_COMMAND....11
TELEMETRY - 016....12
NEGOTIATE_DATALINK- 254....13
LoRa....13
UART....14
Replies....14
TELEMETRY_DATALINK – 255....15
Specific feature implementations....16
Message serializer....16
COBS....16

Motivation

The Tiny Address Protocol (TAP) serves as a comfortable stop-gap between simplistic communication and high-level protocols like MavLink or LoRaWAN.

TAP is designed with simplistic datalinks, such as low-bandwidth radios and UART, in mind, but it may be implemented over higher quality datalinks too.

TAP shall handle everything from datalink quality communication to rudimentary networking functions. TAP devices shall interpret different TAP data depending on their role, for example: a repeater node shall be aware of datalink quality but a base station shall be aware of total RTT.

TAP may build its own mesh of nodes, with the right configuration on individual nodes in order to enable Tiny Address Routing (TAR), allowing for relay-style communication between devices. TAP may also be used as out-of-band signalling for higher bandwidth high cost radios, especially useful for devices such as gliders.

Design notes

- TAP packet payloads shall be 32-bit aligned.
- TAP shall be agnostic in datalink and direction.
- TAP may be used in Simplex and Duplex communications.
- TAP documentation shall be written in IEEE english.
- TAP is not a commercial product nor are we a standards committee. Check the license document for more information.
- The key words "MUST", "MUST NOT", "REQUIRED", "SHALL", "SHALL NOT", "SHOULD", "SHOULD NOT", "RECOMMENDED", "MAY", and "OPTIONAL" in this document are to be interpreted as described in RFC 2119.

TAP Signalling components

Both the address and header shall be a part of all messages sent using TAP.

Address Header

The TAP address header carries all the crucial information about the message at hand in a short-but-sweet structure:

Start Byte	Type	Field name	Description
0	uint16_t	SOF_WORD	Start of Frame indicator
2	uint8_t	TARGET_ID	Identifier for the receiving device.
3	uint8_t	SOURCE_ID	Identifier for the transmitting device.
4	uint8_t	MESSAGE_LENGTH	Payload length in bytes.
5	uint8_t	MESSAGE_TYPE	Message type indicator
6	uint16_t	COBS	

In 32 bit row format:

SOF_WORD		TARGET_ID	SOURCE_ID
MESSAGE_LENGTH	MESSAGE_TYPE	COBS	

Message trailer

The CRC of the header and the payload is calculated, but not the trailer.

Start Byte	Type	Field name	Description
m_len	uint16_t	CRC_16	Cyclic Redundancy Check
m_len + 2	uint16_t	SOF_WORD	End of Frame indicator

In 32 bit row format:

CRC_16	SOF_WORD

Message types

A number of message types have been reserved and used:

Value/Range	Name	Description
0	ACK/NACK	Positive or negative acknowledgement.
1	DIRECT_COMMAND	Traditional, direct RC control data.
2	INDIRECT_COMMAND	Waypoints.
3-15	Reserved	
16	TELEMETRY	Position and orientation information.
17-31	Reserved	
32-253	Available for mission-specific use-cases.	
254	NEGOTIATE_DATALINK	Datalink channel change command.
255	TELEMETRY_DATALINK	Datalink information.

ACK/NACK – 000

Specific message-types require an ACK or NACK message to confirm reception, particularly when modifying the underlying datalink.

Specific datalink negotiation practices are beyond the scope of this document at this time.

Start Byte	Type	Field name	Description
8	uint8_t	ACK_TYPE	Type of ACK message
9	*uint24_t*	TOKEN	Token for specific ACK uses

uint24_t is not a real type. Use a 3-length array of uint8_t instead.

The following ACK types are defined:

Value/Range	Name	Description
0	ACK	Positive acknowledgement.
1	NACK	Negative acknowledgement.
2-31	Reserved	
32-255	Available for mission-specific use-cases.	

DIRECT_COMMAND – 001

A direct command message carries two-byte groups. These can be interpreted as ranges for PWM signals (e.g.: the arduino map() function) or used for raw value transmission.

Start byte	Type	Field name	Description
8 + (2·n)	uint16_t	DATA_n	n^{th} pair of bytes

It is recommended to **reserve the first pair of bytes for up to 16 boolean values**, to operate lights, software-arming of motors and others.

Due to the Radiohead Library-established limit, a maximum of 251 bytes can be transmitted per packet. 123 signals can (in theory) be transmitted with this message type.

That limit is a lot higher than any real use-case is expected to reach, if more data needs to be transmitted, it should be split across multiple packets and the message types 2-15 should be used.

Urpekari implementation of Direct_Command

Urpekari has opted for a 16-bit 8-channel direct command payload. This should provide enough control for anything on board any ROV, USV or UAS planned at this time. Further controls shall be handled with additional message types.

Start Byte	Type	Field name	Description
8 + 0	**uint16_t**	**BOOLS**	**16 bit boolean-array**
8 + 2	uint16_t	Reserved	Reserved
8 + 4	uint16_t	Channel_0	Gradual control channel
8 + 6	uint16_t	Channel_1	Gradual control channel
...	...	...	...
8 + 18	uint16_t	Channel_7	Gradual control channel

In 32 bit row format:

BOOLS	Reserved
Channel_0	Channel_1
Channel_2	Channel_3
Channel_4	Channel_5
Channel_6	Channel_7

INDIRECT_COMMAND - 002

An indirect command carries waypoint information: GPS coordinates, altitude/depth information, and a radius indicating the required precission to "hit" the waypoint.

Start byte	Type	Field name	Description *[unit]*
8 + 0	**uint16_t**	**BOOLS**	**16 bit boolean-array**
8 + 2	uint16_t	Reserved	Reserved
8 + 4	float	GPS_LAT	Waypoint GPS Latitude. [DEC]
8 + 8	float	GPS_LON	Waypoint GPS Longitude. [DEC]
8 + 12	uint16_t	ALT-DEP	Waypoint altitude or depth. [*cm*]
8 + 14	uint16_t	RADIUS	Waypoint precission radius. [*m*]

In 32 bit row format:

BOOLS	Reserved
GPS_LAT	
GPS_LON	
ALT-DEP	RADIUS

Boolean arrays for DIRECT_COMMAND and INDIRECT_COMMAND

While only INDIRECT_COMMAND messages require the 2-Byte boolean array at the start of the payload, it is recommended to do so in DIRECT_COMMAND messages.

This example shows a simple and practical way to use them to aid the control of an autonomous vehicle. What is described in the following section is what is implemented in the flight controller for the Galerna UAS:

Bit	Name	Description when true (1)
0	ARM	Allow for software arming of the thrust systems.
1	AUTO	Fly autonomously folowing waypoints. (This is overriden by DIRECT_COMMAND messages, even when they have the AUTO bit enabled.)
2	STAB	Partial autopilot, the UAS will attempt level navigation and filter inputs.
3	NAVLIGHT	Turn on navigation lights.
4	STROBE	Turn on strobe lights.
5	LAND	Extend landing gear or other physical supports. (If applicable.)
6	*N/A*	*Free so far*
7	*N/A*	*Free so far*
8	*N/A*	*Free so far*
9	*N/A*	*Free so far*
10	*N/A*	*Free so far*
11	COMLOSSBY	Bypass mid-flight communications loss detection and reaction. (Use with caution.)
12	LOITER	Loiter next waypoint, requires an INDIRECT_COMMAND. (If off, any waypoint will be treated as a fly-through waypoint.)
13	RTH	Return to home directly. (Home may also be specified as the first GPS point registered.)
14	CHECKSUM	Checksum
15		

TELEMETRY - 016

A basic telemetry message carries information regarding the vehicle's current position.

Start byte	Type	Field name	Description *[unit]*
8 + 0	float	GPS_LAT	Current GPS Latitude. [DEC]
8 + 4	float	GPS_LON	Current GPS Longitude. [DEC]
8 + 8	uint16_t	ALT-DEP	Current altitude [m] or depth. [*cm*]
8 + 10	int16_t	HEADING	Heading. [°/10] (24.5° → 245 in this variable)
8 + 12	float	ROLL	Roll angle. [°]
8 + 16	float	PITCH	Pitch angle. [°]

In 32 bit row format:

GPS_LAT	
GPS_LON	
ALT-DEP	HEADING
ROLL	
PITCH	

NEGOTIATE_DATALINK- 254

A datalink control message, exclusively used by the radio ingest/digest device. A channel hop is used when a channel that is in use is of low quality.

The information provided by the DATALINK_TELEMETRY is used to determine the quality of the channel in use. A channel hop may also be purposefully triggered by the user.

NEGOTIATE_DATALINK is sent when a TAP device has determined that the datalink currently in use may be improved upon with different datalink parameters, either to improve data transmission speed or to improve reliability.

NEGOTIATE_DATALINK shall serve as an "invitation" to other TAP devices on the same datalink. All other TAP devices shall reply with ACK or NACK messages before changing datalink configuration.

ACK/NACK identification token values may be randomly generated, or incrementally generated.

LoRa

LoRa, through the RadioHead library, contains several configurable fields. NEGOTIATE_DATALINK may offer to modify:

Start Byte	Type	Field name	Description
8 + 0	uint16_t	Frequency	Frequency x10, in MHz (8630 = 863.0 MHz)
8 + 2	uint16_t	Spreading Factor	Spreading factor (6, 7, 8, 9, 10, 11, 12)
8 + 4	uint32_t	Bandwidth	Gradual control channel
8 + 8	int16_t	TX Power change	A bump up/down in dBm (+3 dBm, -6 dBm). Not the power to SET but the power CHANGE TO CREATE
8 + 10	uint16_t	Coding rate	Bits per symbol (5, 6, 7, 8)
8 + 12	uint16_t	Reserved	Reserved
8 + 14	uint24_t	Token	Used to identify ACK/NACK messages

uint24_t is not a real type. Use a 3-length array of uint8_t instead.

In 32 bit row format:

Frequency		Spreading Factor
Bandwidth		
TX Power change		Coding rate
Reserved	Token	

Implementers may limit these suggestions in software to more easily follow local laws and regulations. For instance, in the EU, it is not recommended to change frequency to anything other than 863 MHz.

UART

UART contains a single configurable field. Further fields have been reserved for future use, as more complex links may be implemented over UART which may be of interest to TAP users as well:

Start Byte	Type	Field name	Description
8 + 0	uint32_t	Baud rate	Symbols per second
8 + 2	uint32_t	Reserved	Reserved
8 + 4	uint32_t	Reserved	Reserved
8 + 6	uint16_t	Reserved	Reserved
8 + 10	uint24_t	Token	Used to identify ACK/NACK messages

uint24_t is not a real type. Use a 3-length array of uint8_t instead.

In 32 bit row format:

Baud rate	
Reserved	
Reserved	
	Token

Replies

A NEGOTIATE_DATALINK message shall be replied to with an ACK or NACK carrying the Token carried in the NEGOTIATE_DATALINK message.

A negative NACK message shall be used to signal inability or disposition to follow the suggestion in the original NEGOTIATE_DATALINK message. A device sending a NACK response may create an invite of its own, with a proposal it is able to fulfil.

A positive ACK message shall be used to signal ability and disposition to follow the suggestion in the original NEGOTIATE_DATALINK message.

Following a positive ACK message all devices shall change datalink configuration within a second. Afterwards, both devices shall exchange ACKs using the same Token once again. Failure to do so within another second shall cause all devices to roll back the newly negotiated configuration.

TELEMETRY_DATALINK – 255

A datalink telemetry message, exclusively used by the radio ingest device. It's main purpose is to keep both sides of the conversation informed of datalink quality.

Start byte	Type	Field name	Description *[unit]*
8 + 0	int16_t	RSSI	Received Signal Strength Indicator. [dB]
8 + 2	uint16_t	SNR	Signal to Noise Ratio [dB]
8 + 4	uint16_t	RTT	Return trip time [ms]
8 + 6	uint16_t	SENT_PKTS	Amount of messages sent since the previous TELEMETRY_DATALINK message
8 + 8	uint16_t	DELTA_T	Time elapsed since the previous TELEMETRY_DATALINK message [ms]
8 + 10	uint16_t	Reserved	Reserved

Message serializer

The TAP serializer works by receiving an incomplete header and a complete payload. The following table highlights the header fields the serializer requires:

SOF_WORD		TARGET_ID	SOURCE_ID
MESSAGE_LENGTH	MESSAGE_TYPE	COBS	

The raw payload will consist of arbitrary data, identified for the upper layers by the MESSAGE_TYPE field on the receiving end, and be of MESSAGE_LENGTH length.

Big endian byte orders have been used for all fields defined in this document.

COBS

Consistent Overhead Byte Stuffing (COBS) is a mechanism that protects the Start of Frame (SOF) word from appearing in illegal positions. It is necessary for unmanaged links such as UART and bit-banged radio links, where the start and end of a frame are up for us to manage.

COBS as implemented by TAP uses a 2-byte field in every Address Header. The serializer and deserializer must handle COBS in a completely transparent way. It must be the last step taken before transmission and the first step taken upon reception. COBS protects header, payload and trailer from illegal SOF word appearances.

Let's take the following example, with the header highlighted in yellow and the trailer highlighted in green.

SOF_WORD		TARGET_ID	SOURCE_ID
MESSAGE_LENGTH	MESSAGE_TYPE	COBS	
DATA	DATA	DATA	DATA
DATA	DATA	DATA	DATA
DATA	DATA	DATA	DATA
DATA	DATA	DATA	DATA
DATA	DATA	DATA	DATA
CRC_16		SOF_WORD	

In a case with no illegal SOF word placement, the COBS field will simply be set to 0x0000 and the message will be transmitted with no more complication.

However, were the SOF word to show up at any point in the message, the COBS field in the header will instead point to the first byte of the illegal appearance of the SOF word. The illegal appearance of the SOF word will then be replaced by either

0x0000, if it is the last illegal appearance of the SOF word, or the pointer to the following appearance of an illegal SOF word.

Following along with the example, given this message:

SOF_WORD		TARGET_ID	SOURCE_ID
MESSAGE_LENGTH	MESSAGE_TYPE	COBS	
DATA	DATA	DATA	DATA
DATA	ILLEGAL SOF_WORD		DATA
DATA	DATA	DATA	DATA
DATA	DATA	ILLEGAL SOF_WORD	
DATA	DATA	DATA	DATA
CRC_16		SOF_WORD	

The COBS algorithm must replace the mentioned fields like so:

SOF_WORD		TARGET_ID	SOURCE_ID
MESSAGE_LENGTH	MESSAGE_TYPE	13	
DATA	DATA	DATA	DATA
DATA	22		DATA
DATA	DATA	DATA	DATA
DATA	DATA	0	
DATA	DATA	DATA	DATA
CRC_16		SOF_WORD	