

1. Power

ESP32 D1 R32 connections

5V pin -> +5V supply rail (red wire)

GND pin -> common ground (black wire)

3V3 pin -> sensor/DS18B20 only (orange wire)

Important

Never connect external 5V to the board while USB is also powering it.

All GND points must be common.