DEPARTMENT OF TELECOMMUNICATION ENGINEERING
BACHELOR OF SCIENCE IN CYBER SECURITY
MEHRAN UNIVERSITY OF ENGINEERING & TECHNOLOGY, JAMSHORO
NETWORK SECURITY (CYS360)
(6TH SEMESTER, 3RD Year) LAB EXPERIMENT # 11

Name:	__Muhammad_Usman________________			Roll number:	__23BSCYS006__
Score:	___________	Date:	_____________	Instructor's Signature:	________________

Lab # 11: To configure Site-to-Site IPSec VPN Using Pre-shared Key Authentication

Objective: The objective of this lab is to configure Site-to-Site IPSec VPN Using Pre-shared Key Authentication **Duration: 3 Hours**

Expected Outcomes: By the end of this lab session, students will be able to:

1. To establish a secure communication tunnel between two remote network sites using IPsec VPN that ensures confidentiality, integrity, and authentication of data transmitted over the public network.
2. To configure and verify pre-shared key authentication on both VPN gateways, ensuring that only authorized devices can establish the VPN tunnel and exchange encrypted traffic successfully between the two sites.

Rubrics

LAB PERFORMANCE INDICATOR	SUBJECT KNOWLEDGE	DATA ANALYSIS AND INTERPRETATION	ABILITY TO CONDUCT EXPERIMENT
SCORE			

Note: Student performance will be assessed based on this rubric during lab sessions.

Networking Requirements

As shown in Figure 1, FW_A connects network A to the Internet and FW_B connects network B to the Internet. The networking requirements are as follows:

- Network A (10.1.1.0/24) is connected to GE1/0/3 of FW_A.
- Network B (10.1.2.0/24) is connected to GE1/0/3 of FW_B.
- FW_A and FW_B are reachable to each other.

The purpose of this networking is to set up an IPSec tunnel between FW_A and FW_B to enable communication between users on network A and network B.



Figure 1 Networking diagram for configuring IPSEC Tunnel



Figure 2 Networking Topology of IPSEC Tunnel

Item	**Data**
FW_A	Interface number: GE1/0/3 IP address: 10.1.1.1/24
	Interface number: GE1/0/1 IP address: 1.1.3.1/24
	IPSec configuration Peer IP address: 1.1.5.1 Authentication type: pre-shared key Pre-shared key: Test!1234 Local ID type: IP address Peer ID type: IP address

Item	Data
FW_B	Interface number: GE1/0/1 IP address: 1.1.5.1/24
	Interface number: GE1/0/3 IP address: 10.1.2.1/24
	IPSec configuration Peer IP address: 1.1.3.1 Authentication type: pre-shared key Pre-shared key: Test!1234 Local ID type: IP address Peer ID type: IP address

Configuration Roadmap

1. The roadmap for configuring FW_A is similar to that for configuring FW_B:
2. Configure interfaces.
3. Configure security policies to permit packets between specified subnets.
4. Create a static route to the peer end.
5. Configure the IPSec policy, including basic IPSec policy information, data flow to be protected by IPSec, and proposal parameters for security association (SA) negotiation.

Procedure

1. Perform basic configurations on FW_A, including setting the interface IP addresses, adding interfaces to security zones, and configuring interzone security policies and a static route.

a. Set interface IP addresses.

i. Set the IP address of GE1/0/3.

```
<sysname> system-view
[sysname] sysname FW_A
[FW_A] interface gigabitethernet 1/0/3
[FW_A-GigabitEthernet1/0/3] ip address 10.1.1.1 24
[FW_A-GigabitEthernet1/0/3] quit
```

ii. Set the IP address of GE1/0/1.

```
[FW_A] interface gigabitethernet 1/0/1
[FW_A-GigabitEthernet1/0/1] ip address 1.1.3.1 24
[FW_A-GigabitEthernet1/0/1] quit
```

b. Add interfaces to corresponding security zones.

i. Add GE1/0/3 to the Trust zone.

```
[FW_A] firewall zone trust
[FW_A-zone-trust] add interface gigabitethernet 1/0/3
[FW_A-zone-trust] quit
```

ii. Add GE1/0/1 to the Untrust zone.

```
[FW_A] firewall zone untrust
[FW_A-zone-untrust] add interface gigabitethernet 1/0/1
[FW_A-zone-untrust] quit
```

c. Configure interzone security policies.

i. Configure the security policies between the Trust and Untrust zones.

```
[FW_A] security-policy
[FW_A-policy-security] rule name policy1
[FW_A-policy-security-rule-policy1] source-zone trust
[FW_A-policy-security-rule-policy1] destination-zone untrust
[FW_A-policy-security-rule-policy1] source-address 10.1.1.0 24
[FW_A-policy-security-rule-policy1] destination-address 10.1.2.0 24
[FW_A-policy-security-rule-policy1] action permit
[FW_A-policy-security-rule-policy1] quit
[FW_A-policy-security] rule name policy2
[FW_A-policy-security-rule-policy2] source-zone untrust
[FW_A-policy-security-rule-policy2] destination-zone trust
[FW_A-policy-security-rule-policy2] source-address 10.1.2.0 24
[FW_A-policy-security-rule-policy2] destination-address 10.1.1.0 24
[FW_A-policy-security-rule-policy2] action permit
[FW_A-policy-security-rule-policy2] quit
```

ii. Configure the security policies between the Local and Untrust zones.
Configure the security policies between the Local and Untrust zones to permit the interzone traffic for the negotiation between the tunnel endpoints.

NOTE:
The Local-Untrust interzone policy controls whether IKE negotiation packets can pass through the FW. This policy can use the source and destination addresses, protocol, or port as the matching condition. In this example, the source and destination addresses are used as the matching condition. To use the protocol or port as the matching condition, you need to enable ESP and port 500 for UDP (port 4500 also in NAT traversal scenarios).

```
[FW_A-policy-security] rule name policy3
[FW_A-policy-security-rule-policy3] source-zone local
[FW_A-policy-security-rule-policy3] destination-zone untrust
[FW_A-policy-security-rule-policy3] source-address 1.1.3.1 32
[FW_A-policy-security-rule-policy3] destination-address 1.1.5.1 32
[FW_A-policy-security-rule-policy3] action permit
[FW_A-policy-security-rule-policy3] quit
[FW_A-policy-security] rule name policy4
[FW_A-policy-security-rule-policy4] source-zone untrust
[FW_A-policy-security-rule-policy4] destination-zone local
[FW_A-policy-security-rule-policy4] source-address 1.1.5.1 32
[FW_A-policy-security-rule-policy4] destination-address 1.1.3.1 32
[FW_A-policy-security-rule-policy4] action permit
[FW_A-policy-security-rule-policy4] quit
[FW_A-policy-security] quit
```

d. Configure a static route to network B. Assume that the next hop of the route is 1.1.3.2.

```
[FW_A] ip route-static 10.1.2.0 255.255.255.0 1.1.3.2
[FW_A] ip route-static 1.1.5.0 255.255.255.0 1.1.3.2
```

2. Configure an IPSec policy on FW_A and apply the policy to the corresponding interface.

a. Configure advanced ACL 3000 to permit the users on network segment 10.1.1.0/24 to access network segment 10.1.2.0/24.

```
[FW_A] acl 3000
[FW_A-acl-adv-3000] rule 5 permit ip source 10.1.1.0 0.0.0.255 destination 10.1.2.0
0.0.0.255
[FW_A-acl-adv-3000] quit
```

b. Configure an IPSec proposal using the default parameters.

```
[FW_A] ipsec proposal tran1
[FW_A-ipsec-proposal-tran1] esp authentication-algorithm sha2-256 [FW_A-ipsec-
proposal-tran1] esp encryption-algorithm aes-256
[FW_A-ipsec-proposal-tran1] quit
```

c. Configure an IKE proposal.

```
[FW_A] ike proposal 10
[FW_A-ike-proposal-10] authentication-method pre-share
[FW_A-ike-proposal-10] prf hmac-sha2-256
[FW_A-ike-proposal-10] encryption-algorithm aes-256
[FW_A-ike-proposal-10] dh group14
[FW_A-ike-proposal-10] integrity-algorithm hmac-sha2-256
[FW_A-ike-proposal-10] quit
```

d. Configure an IKE peer.

```
[FW_A] ike peer b
[FW_A-ike-peer-b] ike-proposal 10
[FW_A-ike-peer-b] remote-address 1.1.5.1
[FW_A-ike-peer-b] pre-shared-key Test!1234
[FW_A-ike-peer-b] quit
```

e. Configure an IPSec policy.

```
[FW_A] ipsec policy map1 10 isakmp
[FW_A-ipsec-policy-isakmp-map1-10] security acl 3000
[FW_A-ipsec-policy-isakmp-map1-10] proposal tran1
[FW_A-ipsec-policy-isakmp-map1-10] ike-peer b
[FW_A-ipsec-policy-isakmp-map1-10] quit
```

f. Apply IPSec policy **map1** to GE1/0/1.

```
[FW_A] interface gigabitethernet 1/0/1
[FW_A-GigabitEthernet1/0/1] ipsec policy map1
[FW_A-GigabitEthernet1/0/1] quit
```

3. Perform basic configurations on FW_B, including setting the interface IP addresses, adding interfaces to security zones, and configuring interzone security policies and a static route.

a. Set interface IP addresses.

i. Configure the IP address of GE1/0/3.

```
<sysname> system-view
[sysname] sysname FW_B
[FW_B] interface gigabitethernet 1/0/3
```

```
[FW_B-GigabitEthernet1/0/3] ip address 10.1.2.1 24
[FW_B-GigabitEthernet1/0/3] quit
```

ii. Configure the IP address of GE1/0/1.

```
[FW_B] interface gigabitethernet 1/0/1
[FW_B-GigabitEthernet1/0/1] ip address 1.1.5.1 24
[FW_B-GigabitEthernet1/0/1] quit
```

b. Add interfaces to corresponding zones.

i. Add GE1/0/3 to the Trust zone.

```
[FW_B] firewall zone trust
[FW_B-zone-trust] add interface gigabitethernet 1/0/3
[FW_B-zone-trust] quit
```

ii. Add GE1/0/1 to the Untrust zone.

```
[FW_B] firewall zone untrust
[FW_B-zone-untrust] add interface gigabitethernet 1/0/1
[FW_B-zone-untrust] quit
```

c. Configure interzone security policies.

i. Configure the security policies between the Trust and Untrust zones.

```
[FW_B] security-policy
[FW_B-policy-security] rule name policy1
[FW_B-policy-security-rule-policy1] source-zone trust
[FW_B-policy-security-rule-policy1] destination-zone untrust
[FW_B-policy-security-rule-policy1] source-address 10.1.2.0 24
[FW_B-policy-security-rule-policy1] destination-address 10.1.1.0 24
[FW_B-policy-security-rule-policy1] action permit
[FW_B-policy-security-rule-policy1] quit
[FW_B-policy-security] rule name policy2
[FW_B-policy-security-rule-policy2] source-zone untrust
[FW_B-policy-security-rule-policy2] destination-zone trust
[FW_B-policy-security-rule-policy2] source-address 10.1.1.0 24
[FW_B-policy-security-rule-policy2] destination-address 10.1.2.0 24
[FW_B-policy-security-rule-policy2] action permit
[FW_B-policy-security-rule-policy2] quit
```

ii. Configure the security policies between the Local and Untrust zones.

NOTE:

The Local-Untrust interzone policy controls whether IKE negotiation packets can pass through the FW. This policy can use the source and destination addresses, protocol, or port as the matching condition. In this example, the source and destination addresses are used as the matching condition. To use the protocol or port as the matching condition, you need to enable ESP and port 500 for UDP (port 4500 also in NAT traversal scenarios).

Configure the security policies between the Local and Untrust zones to permit the interzone traffic for the negotiation between the tunnel endpoints.

```
[FW_B-policy-security] rule name policy3
[FW_B-policy-security-rule-policy3] source-zone local
[FW_B-policy-security-rule-policy3] destination-zone untrust
[FW_B-policy-security-rule-policy3] source-address 1.1.5.1 32
[FW_B-policy-security-rule-policy3] destination-address 1.1.3.1 32
[FW_B-policy-security-rule-policy3] action permit
[FW_B-policy-security-rule-policy3] quit
[FW_B-policy-security] rule name policy4
[FW_B-policy-security-rule-policy4] source-zone untrust
[FW_B-policy-security-rule-policy4] destination-zone local
[FW_B-policy-security-rule-policy4] source-address 1.1.3.1 32
[FW_B-policy-security-rule-policy4] destination-address 1.1.5.1 32
[FW_B-policy-security-rule-policy4] action permit
[FW_B-policy-security-rule-policy4] quit
[FW_B-policy-security] quit
```

d. Configure a static route to network A. Assume that the next hop of the route is 1.1.5.2.

```
[FW_B] ip route-static 10.1.1.0 255.255.255.0 1.1.5.2
[FW_B] ip route-static 1.1.3.0 255.255.255.0 1.1.5.2
```

4. Configure an IPSec policy on FW_B and apply the policy to the corresponding interface.

a. Configure advanced ACL 3000 to permit the users on network segment 10.1.2.0/24 to access network segment 10.1.1.0/24.

```
[FW_B] acl 3000
[FW_B-acl-adv-3000] rule 5 permit ip source 10.1.2.0 0.0.0.255 destination 10.1.1.0
0.0.0.255
[FW_B-acl-adv-3000] quit
```

b. Configure an IPSec proposal using the default parameters.

```
[FW_B] ipsec proposal tran1
[FW_B-ipsec-proposal-tran1] esp authentication-algorithm sha2-256
[FW_B-ipsec-proposal-tran1] esp encryption-algorithm aes-256
[FW_B-ipsec-proposal-tran1] quit
```

c. Configure an IKE proposal using the default parameters.

```
[FW_B] ike proposal 10
[FW_B-ike-proposal-10] authentication-method pre-share
[FW_B-ike-proposal-10] prf hmac-sha2-256
[FW_B-ike-proposal-10] encryption-algorithm aes-256
[FW_B-ike-proposal-10] dh group14
[FW_B-ike-proposal-10] integrity-algorithm hmac-sha2-256
[FW_B-ike-proposal-10] quit
```

d. Configure an IKE peer.

```
[FW_B] ike peer a
[FW_B-ike-peer-a] ike-proposal 10
[FW_B-ike-peer-a] remote-address 1.1.3.1
[FW_B-ike-peer-a] pre-shared-key Test!1234
[FW_B-ike-peer-a] quit
```

e. Configure an IPSec policy.

```
[FW_B] ipsec policy map1 10 isakmp
[FW_B-ipsec-policy-isakmp-map1-10] security acl 3000
[FW_B-ipsec-policy-isakmp-map1-10] proposal tran1
[FW_B-ipsec-policy-isakmp-map1-10] ike-peer a
[FW_B-ipsec-policy-isakmp-map1-10] quit
```

f. Apply security policy **map1** to GE1/0/1.

```
[FW_B] interface gigabitethernet 1/0/1
[FW_B-GigabitEthernet1/0/1] ipsec policy map1
[FW_B-GigabitEthernet1/0/1] quit
```

Verification

1. Run the **display ike sa** and **display ipsec sa** commands on both FW_A and FW_B to check SA establishment.
   Take FW_B for example. If the following information is displayed, the IKE SA and IPSec SA are successfully established.

```
<FW_B> display ike sa
                                                                                  Ike
sa information :
    Conn-ID       Peer            VPN            Flag(s)                Phase
  ------------------------------------------------------------------------------
    16777239      1.1.3.1                        RD|ST|A                v2:2
    16777232      1.1.3.1                        RD|ST|A                v2:1

  Number of SA entries  : 2

  Number of SA entries of all cpu : 2
```

```
                                                                   Flag Description:
  RD--READY   ST--STAYALIVE   RL--REPLACED   FD--FADING   TO--TIMEOUT
  HRT--HEARTBEAT   LKG--LAST KNOWN GOOD SEQ NO.   BCK--BACKED UP
M--ACTIVE   S--STANDBY   A--ALONE  NEG--NEGOTIATING
```

```
<FW_B> display ipsec sa

                                                               ipsec sa information:
===============================
Interface: GigabitEthernet1/0/1
===============================

  -----------------------------
  IPSec policy name: "map1"
  Sequence number  : 10
  Acl group        : 3000
Acl rule         : 5
  Mode             : ISAKMP
  -----------------------------
    Connection ID     : 83903371
    Encapsulation mode: Tunnel
    Tunnel local      : 1.1.5.1
    Tunnel remote     : 1.1.3.1
    Flow source       : 10.1.2.2/255.255.255.255 0/0
    Flow destination  : 10.1.1.2/255.255.255.255 0/0

    [Outbound ESP SAs]
      SPI: 763065754 (0x2d7b759a)
      Proposal: ESP-ENCRYPT-AES-256 SHA2-256-128
      SA remaining key duration (kilobytes/sec): 0/3079
      Max sent sequence-number: 1
      UDP encapsulation used for NAT traversal: N
      SA encrypted packets (number/kilobytes): 4/0

    [Inbound ESP SAs]
      SPI: 163241969 (0x9badff1)
      Proposal: ESP-ENCRYPT-AES-256 SHA2-256-128
      SA remaining key duration (kilobytes/sec): 0/3079
      Max received sequence-number: 3203668
      UDP encapsulation used for NAT traversal: N
```

```
     SA decrypted packets (number/kilobytes): 4/0
     Anti-replay : Enable
Anti-replay window size: 1024
```

Task:

Attach Screenshots of all the topology and confinguration.

Note: Attach all the screenshots of the configuration. The Firewall name should be your roll number like FW1-22BSCYS001. Upload the .topo and .cfg files on MS Teams Assignment.

Questions:

1. What role does the pre-shared key play in IPsec VPN authentication?
The **pre-shared key (PSK)** is a shared password used by both VPN gateways to **authenticate each other during IKE negotiation** before creating the tunnel.

2. Which protocols are used for encryption and key exchange in IPsec VPN?

- **ESP (Encapsulating Security Payload)** – used for encryption and authentication of data.
- **IKE (Internet Key Exchange)** – used for **key exchange and tunnel negotiation**.

3. How does IPsec ensure data confidentiality and integrity?

- **Confidentiality:** achieved using encryption algorithms like **AES**.
- **Integrity:** ensured using authentication algorithms like **SHA or HMAC**, which verify that data was not modified.

4. What is the difference between IKE Phase 1 and IKE Phase 2?

- **Phase 1:** Establishes a **secure channel and authenticates the peers**.
- **Phase 2:** Negotiates the **IPsec tunnel and encryption parameters for actual data traffic**.

5. What parameters must match on both VPN gateways for successful tunnel establishment?

- Pre-shared key
- Encryption algorithm
- Authentication algorithm
- IKE version / DH group
- ACL (interesting traffic)
- Peer IP address

6. **Describe the function of the Security Association (SA) in IPsec.**
A **Security Association (SA)** defines the **security parameters (keys, algorithms, lifetime)** used to encrypt and decrypt traffic in the IPsec tunnel.


OSPF Area 0.0.0.0
OSPF Area 0.0.0.1
OSPF Area 0.0.0.2
Router ID 192.168.10.1
Router ID 1.1.5.1
10.1.2.254
10.1.2.1
1.1.3.1 24
1.1.3.254 24
1.1.5.254
1.1.5.1
10.1.1.1
10.1.1.254
GE 0/0/1
GE 1/0/1
GE 1/0/2
GE 0/0/1
GE 0/0/2
GE 1/0/1
GE 1/0/2
GE 0/0/1
AR1
FW2
192.168.10.1
GE 1/0/0
AR2
VLink Configured
FW3
GE 1/0/3
AR3
Ethernet 0/0/1
Ethernet 0/0/2
Cloud1
Cloud2


Huawei FW-1-23BSCYS006
NS - Lab 11.pdf
Huawei FW-2-23BSCYS00
192.168.20.1:8443/default.html#
Huawei
USG6000V1-ENSP
Dashboard
Monitor
Policy
Object
Network
System
Current User: admin
Commit
Save
Help
About
Interface
Link Interface
Link Interface Group
Interface Pair
Zone
VXLAN
DNS
DHCP Server
Route
IPSec
L2TP
L2TP over IPSec
GRE
SSL VPN
SACG
Interface List
Add
Delete
Refresh
Interface Name
Enter an interface name.
Search
Interface Name | Zone | IP Address | Connectio... | VLAN/VX... | Mode | State Physical IPv4 IPv6
GE0/0/0(GE0/METH) | trust(default) | 192.168.0.1 | Static IP (IPv4) Static IP (IPv6) | Routing
GE1/0/0 | -- NONE --(public) | Static IP (IPv4) Static IP (IPv6) | Routing
GE1/0/1 | untrust(public) | 1.1.5.1 | Static IP (IPv4) Static IP (IPv6) | Routing
GE1/0/2 | trust(public) | 10.1.1.1 | Static IP (IPv4) Static IP (IPv6) | Routing
GE1/0/3 | trust(public) | 192.168.20.1 | Static IP (IPv4) Static IP (IPv6) | Routing
GE1/0/4 | -- NONE --(public) | Static IP (IPv4) Static IP (IPv6) | Routing
GE1/0/5 | -- NONE --(public) | Static IP (IPv4) Static IP (IPv6) | Routing
GE1/0/6 | -- NONE --(public) | Static IP (IPv4) Static IP (IPv6) | Routing
Virtual-if0 | -- NONE --(public)

DEPARTMENT OF TELECOMMUNICATION ENGINEERING
BACHELOR OF SCIENCE IN CYBER SECURITY
MEHRAN UNIVERSITY OF ENGINEERING & TECHNOLOGY, JAMSHORO
NETWORK SECURITY (CYS360)
(6TH SEMESTER, 3RD Year) LAB EXPERIMENT # 11






Huawei FW-1-23BSCYS006
NS - Lab 11.pdf
Huawei FW-2-23BSCYS006
192.168.20.1:8443/default.html#
Huawei
USG6000V1-ENSP
Dashboard Monitor Policy Object Network System
Current User: admin Commit Save
Interface
Interface
Link Interface
Link Interface Group
Interface Pair
Zone
VXLAN
DNS
DHCP Server
Route
Intelligent Uplink Sel
Virtual Router
Static Route
RIP
OSPF
BGP
Dynamic Route Mon
Routing Table
Routing Table
Refresh public IPv4 Protocol All

Protocol	Destination/Mask	Priority	Cost	Next Hop
OSPF	1.1.3.0/24	10	2	1.1.5.254
Static	1.1.3.1/32	60	0	1.1.5.254
Direct	1.1.5.0/24	0	0	1.1.5.1
Direct	1.1.5.1/32	0	0	127.0.0.1
Direct	10.1.1.0/24	0	0	10.1.1.1
Direct	10.1.1.1/32	0	0	127.0.0.1
OSPF	10.1.2.0/24	10	3	1.1.5.254
Direct	127.0.0.0/8	0	0	127.0.0.1
Direct	127.0.0.1/32	0	0	127.0.0.1
Direct	192.168.20.0/24	0	0	192.168.20.1
Direct	192.168.20.1/32	0	0	127.0.0.1


Huawei FW-1-23BSCYS006
NS - Lab 11.pdf
Huawei FW-2-23BSCYS006
192.168.20.1:8443/default.html#
Huawei
USG6000V1-ENSP
Dashboard Monitor Policy Object Network System
Current User: admin Commit Save
Security Policy
Security Policy
NAT Policy
Server Load Balancing
Bandwidth Management
Quota Control Policy
Proxy Policy
Security Protection
ASPF Configuration
Security Policy List
Add Security Policy Add Security Policy Group Delete Copy Move Insert Export Reset All Statistics Enable Disab
Refresh
Enter a keyword.
Add Filter

Index	Name	Desc...	Tag	VLA...	Sour...	Desti...	Sour...	Desti...	User	Service	Appli...	Sche...	Action
1	Trust-to-unt...			any	trust	untrust	any	any	any	any	any	any	Permit
2	untrust-to-tr...			any	untrust	trust	any	any	any	any	any	any	Permit
3	Local-Untrust			any	local	untrust	F...	F...	any	any	any	any	Permit
4	default	This i...		any	any	any	any	any	any	any	any	any	Deny






Huawei FW-1-23BSCYS006
NS - Lab 11.pdf
Huawei FW-2-23BSCYS006
192.168.20.1:8443/default.html#
Huawei
USG6000V1-ENSP
Dashboard
Monitor
Policy
Object
Network
System
Interface
Interface
Link Interface
Link Interface Group
Interface Pair
Zone
VXLAN
DNS
DHCP Server
Route
IPSec
IPSec
Monitor
L2TP
L2TP over IPSec
GRE
SSL VPN
SACG
Option
IPSec Intelligent Link Selection
1 Virtual System Configuration
Virtual System
public
2 Basic Configuration
Policy Name
map1-10
Local Interface
GE1/0/1
[Configure]
Local Address
1.1.5.1
Peer Address
1.1.3.1
Note: To ensure that negotiation messages interoperate, enable the two-way security policy.
[Add Security Policy]
Authentication Type
Pre-shared key
RSA signature
RSA digital envelope
Pre-shared key
Local ID
IP Address
Peer ID
Any
3 Data Flow to Encrypt
Address Type
IPv4
IPv6
Add
Delete
Insert
Refresh
Enter content to be queried.
Search
Clear Search Condition
Source Address or Group
Destination Address or Group
Proto...
Source Port
Destin... Port
Action
Edit
10.1.1.0/255.255.255.0
10.1.2.0/255.255.255.0
any
any
any
Encrypt


Huawei FW-2-23BSCYS006
192.168.20.1:8443/default.html#
Dashboard
Monitor
Policy
Object
Network
System
Current User: admin
Commit
Save
Help
IPSec Policy List
IPSec Policy Monitoring List
Delete
Refresh
Polic...
IKE User...
Virtu...
Status
Local ...
Peer A...
Algorithm
Negotiated Data Flow
Durati...
Sending/R... Rate (...
Last Setu...
Last Teard...
Teardo...
Teardo...
map...
public
IKE neg...
IPSec n...
1.1.5.1
1.1.3.1
ESP-AES-2!
Source Address[Port]: ...
Destination Address[P...
Protocol: any
961
0/0
2026-03-0...
0
Records per page
Displaying 1 - 1 of 1
Close