

Salt Lake City, UT, USA



Ove	erview	3
Fun	nctionality	3
	Start Xippmex	3
	Help	4
	Close	4
	Time	4
	Priority	5
	AddOper	5
	Trial	
	Elec	7
	Adc2phys	7
	LowCorner	
	Signal	8
	Filter	
	List	
	Set	10
	Custom	10
	Cont	11
	Digin	12
	Bit-Change	13
	Digout	
	Examples	13
	Spike	13
	Spike-Thresh	14
	Stim	15
	Stimres	15
	Stimulation String	16
	StimSeq	
	Enable	
	Module Enable	
	Fast Settle	
	Stim	
	Digin	
	Impedance	
	Transceiver	
	Sensor	
	Ground	
_	Reference	
Der	mos	
	Walkthrough	
	Stimui GUI	
_	Real-time modulation of stimulation parameters	
Rev	vision History	29



# **Overview**

Ripple has developed a MATLAB interface to Trellis and the Grapevine Neural Interface Processor (NIP) called Xippmex. The name, Xippmex, is derived for the communication protocol used by the NIP and Trellis which is known as the eXensible Instrument Processing Protocol or XIPP. Xippmex facilitates data retrieval inside MATLAB, control of stimulation, control of signal streams, and recording. Using Xippmex, most of the functionality available in Trellis can be performed programmatically by writing simple MATLAB scripts. Xippmex allows for the creation of simple automation of experiments or building complex XIPP applications inside MATLAB.

This document describes the full functionality of the Xippmex package with basic usage statements as well as fully-featured examples. The Xippmex installation is provided with the Trellis software suite, available on the Ripple downloads <a href="webpage">webpage</a>. An example script that executes multiple Xippmex function calls in a sequence similar to common stimulation and recording scenarios is provided in the Trellis installation directory ('...\Trellis\Tools\xippmex\ xippmex\ walkthrough.m). In addition, the Xippmex package includes an open source MATLAB GUI application built on Xippmex (stimui), additional example scripts, and several utility scripts. These tools should get any experiment developer off the ground quickly. Please direct any Xippmex questions or issues to <a href="mailto:suppmex">support@rppl.com</a>.

**Installation Note**: Xippmex currently requires the installation of Visual C++ Redistributable for Visual Studio 2008, though this is generally included with Windows 7. However, this package can be downloaded in <u>x86</u> and <u>x64</u> versions.

# **Functionality**

Xippmex is a MEX based MATLAB interface to the NIP and provides access to data streams and control of stimulation. Xippmex is a MATLAB command that accepts the following command strings: 'tcp', 'help', 'close', 'time', 'priority', 'addoper', 'trial', 'elec', 'adc2phys', 'lowcorner', 'signal', 'filter', 'cont', 'spike', 'digin', 'digout', 'stim', and 'stimseq'. Each command is discussed in the following sections. Additionally, each command includes a usage string which can generally be found by executing the command with no additional parameters.

# Start Xippmex

Open Matlab and type 'xippmex' at the command prompt. A successful initialization returns 1. If the Grapevine processor is in TCP mode, type 'xippmex('tcp')' to enable xippmex TCP mode. The processor, Trellis, and Xippmex must be in the same network mode.

#### Examples

>> xippmex
ans = 1

Start Xippmex in UDP mode, the default mode for Trellis and the processor.



```
>> xippmex('tcp')
ans = 1
```

Start Xippmex in TCP mode.

## Help

'help' displays a list of possible Xippmex commands. Most commands contain a usage statement that is displayed when the command is run with no parameters.

## Usage

```
xippmex(cmdstr [, args])

Examples
>> xippmex('help')
    'close' - close UDP socket and delete cached data
    'time' - display latest NIP time
    'priority' - change xippmex thread priority
    'opers' - find Trellis operators on the network
    'trial' - control file save on Trellis operators
    'elec' - retrieve electrode numbers by type of headstage
```

## Close

The 'close' command stops the XIPP listening thread and closes the receiving and sending UDP sockets. In addition, all cached data and other buffers are cleared.

### Usage

```
xippmex('close');
```

Xippmex sockets are closed and buffered data is cleared.

#### Time

The 'time' command retrieves the most recently received NIP time, which is the number of clock cycles at 30 kHz (33.3 µs per cycle) that have occurred since the NIP was started.

## Usage

```
time = xippmex('time');
```

Output	time	Most recent NIP time. NIP time represents the number of 30 kHz clock ticks since
		the NIP has been turned on.

#### Examples

```
>> xippmex('time') / 30000 / 60 ans = 34.2841
```

In this example, the running time of the NIP is calculated in minutes.



## **Priority**

The 'priority' command displays and modifies the priority of the underlying Xippmex thread. Modifying the thread priority is generally not required and is considered an advanced feature. However, there may be cases where Xippmex's thread causes a system to stall or competes with other time sensitive processes. **Warning:** If Xippmex's underlying thread is set low, it is likely that data will be lost. **Note:** This command is only available on Windows machines.

## Usage

```
priority = xippmex('priority', [new priority]);
```

Input	new_priority	Optional. Desired thread priority. Must be one of 'time-critical', 'highest', 'above', 'normal', 'below', or 'lowest'. If specified, priority is set to a new priority; if left empty, current priority is returned.
Output	priority	If new_priority is not specified, the current thread priority is provided as a string. Will be one of the possible options found in the definition of the new_priority variable. If new_priority is provided, there is no returned value.

## Examples

This example shows the current priority, which is the default, time-critical.

```
>> xippmex('priority')
ans = time-critical
```

In this example, the thread priority is changed from time-critical to normal.

```
>> xippmex('priority')
ans = time-critical
>> xippmex('priority', 'normal')
```

# AddOper

Add a Trellis operator ID. This function must be called with a valid Trellis operator before the 'trial' function can be used if Xippmex is in TCP mode. Otherwise, 'addoper' does not need to be used.

## Usage

```
ans = xippmex('addoper', [operator_id]);
```

Input	operator_id	The last octet of the IPv4 address of the computer running Trellis, which can
		be read from the Network Info panel in the main Trellis window.
Output	output	Return operator(s) that have been set with this command, including previously set operators.

#### Example

```
>> xippmex('addoper', 139)
Ans = 139
```



#### **Trial**

The 'trial' command allows for the control of data recording through open instances of Trellis.

Note: 'Enable Remote Control' must be selected in Trellis File Save before Xippmex can control Trellis File Save options.

## Usage

_	_	
Input	status	Optional. Recording status, must be one of 'recording', 'stopped', or 'paused'. If not specified, this parameter will not be changed.
Input	file_name_base	Optional. Full path of base file name for recording. Recorded files will be
		named file_name_base.nev, file_name_base.ns2, etc. If not specified, this
		parameter will not be changed.
Input	auto_stop_time	Optional. Time to automatically stop recording(s) in seconds. If not specified,
		this parameter will not be changed. If set to 0, auto stop will be disabled.
Input	auto_incr	Optional. Boolean. If set to 1, output file name will be appended by a recording
		index. The appended string will always be four digits long, padded to the left
		with zeroes. If set to 0, auto increment will be disabled.
Input	incr_num	Optional. Current value of increment number. If not specified, this parameter will
		not be changed.
Input	operator	Optional. Not necessary if Xippmex is in UDP mode. Not necessary if Xippmex
		is in TCP mode and only one operator has been added with 'addoper'. If
		multiple operator IDs have been added with 'addoper', the first operator added
		will be used by default, otherwise one must specify the desired Trellis operator.
Output	trial_descriptor	Structure describing Trellis file recording, with fields 'status',
		'file_name_base', 'auto_stop_time', 'auto_incr', and 'incr_num'

## **Examples**

```
>> xippmex('trial', 205)
ans = status: 'stopped'
   filebase: 'C:\Users\Mitch\Trellis\dataFiles_20140106\datafile'
   auto_incr: 1
   stop_time: 0
   incr_num: 1
```

This example polls the current recording parameters of the Trellis instance with ID 205.

```
>> xippmex('trial', 205, 'recording', [], 30)
ans = status: 'recording'
   filebase: 'C:\Users\Mitch\Trellis\dataFiles_20140106\datafile'
   auto_incr: 1
   stop_time: 30
   incr_num: 2
```

This example starts a recording that will stop automatically after 30 seconds of without modifying any of the other recording parameters.



#### Elec

The 'elec' command returns a MATLAB array of electrode IDs for the current NIP setup. Channels of Front Ends attached to port A of the first NIP are numbered 1-128, then 129-256 for port B, etc. Front End channel numbers range from 1-5120 to allow for recording from multiple NIPs by one computer running Trellis, which will be enabled in a future software release. Analog input channels are numbered 10241-10270 in the following order: SMA inputs 1-4, micro-D grouped inputs 1-24, then the 2 line-level audio inputs.

## Usage

```
elecs = xippmex('elec', type);
```

Input	type	String corresponding to Front End type. Possible types are 'stim', 'micro', 'nano',
		'surf', 'EMG', 'analog', or 'all'. Note: 'micro' is used for Micro and Micro HV Front
		Ends, and 'surf' is used for Surf S and Surf D Front Ends.
Output	elecs	Array of 1-indexed electrodes IDs.

## Examples

```
>> elecs = xippmex('elec', 'stim');
```

This returns all the electrode IDs for all Micro+Stim Front Ends.

## Adc2phys

The 'adc2phys' command sets the recording resolution for the analog-to-digital converter of Nano2 and Micro2 style Front Ends. This command is applied on a per-Front End basis; i.e. all channels on a particular Front End are set to the 'bitres' recording resolution by setting any electrode on that Front End. The current 'bitres' setting will be returned if the 'bitres' parameter is not specified. Setting the recording resolution to 1 corresponds to  $0.125~\mu\text{V/bit}$  ( $\pm$  4 mV range), 2 corresponds to  $0.25~\mu\text{V/bit}$  ( $\pm$  8 mV range), and 3 corresponds  $0.50~\mu\text{V/bit}$  ( $\pm$  16 mV range). At the highest resolution,  $0.50~\mu\text{V/bit}$ , the linear range of recordings is  $\pm$  12 mV, where recordings above these levels will have nonlinear gains.

**Note**: When the Grapevine is initially powered on, the default setting of  $0.25 \,\mu\text{V/bit}$  will be set on all Nano2 and Micro2 style Front Ends.

#### Usage

```
output = xippmex('adc2phys', elecs, [bitres])
```

Input	elecs	1-indexed array of desired electrode(s).
Input	bitres	Optional. Scalar value representative of the desired recording resolution. $1 = 0.125$
		$\mu V/bit$ , $2 = 0.25 \mu V/bit$ , $3 = 0.50 \mu V/bit$ .
Output	output	If no bitres parameter is sent, the current bitres setting is returned.

## Examples

```
>> xippmex('adc2phys', 10, 1)
```

This sets the Front End associated with channel 10 (the first Front End on port A) to have recording resolution of  $0.125 \,\mu\text{V/bit}$ .



## LowCorner

The 'lowcorner' command sets the hardware high-pass filter on the Nano2 and Micro2 style Front Ends. This command is applied on a per-Front End basis; i.e. all channels on a particular Front End will have the same high-pass filter corner setting when the command is applied to any channel of that Front End. are set to the 'lowcorner' recording resolution by setting any electrode on that Front End. The current 'lowcorner' setting will be returned if the 'lc\_index' parameter is not specified. Setting the lc\_index parameter to 1 sets the low corner to 0.1 Hz  $\{2 = 0.5 \text{ Hz}, 3 = 1.0 \text{ Hz}, 4 = 2.0 \text{ Hz}, 5 = 10 \text{ Hz}, 6 = 20 \text{ Hz}, 7 = 50 \text{ Hz}, 8 = 100 \text{ Hz}\}$ . Note: The actual low corner on any specific Nano2 or Micro2 will be within  $\pm 25\%$  of these values.

**Note**: When the Grapevine is powered on, the hardware high-pass filter low corner on all Nano2 and Micro2 Front Ends will be initialized to 0.1 Hz.

## Usage

output = xippmex('lowcorner', elecs, [lc index])

Input	elecs	1-indexed array of desired electrode(s).
Input	lc_index	Index of low corner filter value desired. $[1 = 0.1 \text{ Hz}, 2 = 0.5 \text{ Hz}, 3 = 1.0 \text{ Hz},$
		4 = 2.0  Hz, 5 = 10  Hz, 6 = 20  Hz, 7 = 50  Hz, 8 = 100  Hz
Output	output	If no index parameter is sent, the current low corner index is returned.

## Examples

```
>> xippmex('lowcorner', 10, 3)
```

This sets the Front End associated with channel 10 (the first Front End on port A) to have a hardware filter low corner of 1 Hz.

## Signal

The 'signal' command enables and disables data streams on the NIP and retrieves information about which streams are available for a given electrode and which streams are enabled. Note: Only the 'stim' and 'spk' data streams can be enabled and disabled on a per-channel basis. All other data streams are enabled and disabled on a per-Front End basis when any channel is used for 'elecs' input.

#### Usage

```
output = xippmex('signal', elecs, [stream, [values]])
```

Input	elecs	1-indexed array of desired electrode(s).
Input	stream	Optional. Name of data stream. If empty, this command will return the names of all the possible streams for the requested electrodes.
Input	values	Optional. Binary values to enable or disable streams. If this is a scalar, this value will be used for all electrodes in 'elecs'. If an array, it must be the same length as 'elecs'. If values is not specified, the state of the stream specified in 'stream' is returned for each electrode.
Output	output	If all 'elecs', 'stream', and 'values' are specified, no output is provided. If only 'elecs' and 'stream' are provided, the state of each electrode in 'elecs' is returned. If only 'elecs' is specified, the string for each stream is provided for each electrode in cell arrays.



## Examples

```
>> xippmex('signal', 1)
ans = 'raw' 'stim' 'hi-res' 'lfp' 'spk'
```

Return the names of all data streams for electrode 1.

```
>> xippmex('signal', 1:2, 'spk', [0,0])
```

Turn off spike data streams for electrodes 1 and 2.

```
>> xippmex('signal', 1, 'raw')
ans = 0
```

Retrieve the state of the 'raw' data stream for electrode 1, which is off in this case.

## Filter

The 'filter' command displays the status of all the filtered streams and allows the selection of filters as well as the application of custom filters designed in MATLAB. Each data stream, aside from the 'raw' streams, is filtered online on the NIP before being published on the instrument network. Each filtered stream may have one band pass style filter as well as an independent notch or comb style to target 60 Hz noise and its harmonics (or 50 Hz for EU customers).

The filter command has three distinct subcommands, 'list', 'set', and 'custom'. Each of these is discussed in the following sections.

## List

The 'list' subcommand returns the types of filters available, the details of the preset filters for each type of filter, and which filter is currently selected by the NIP.

#### Usage

```
filter string = xippmex('filter', 'list', elec);
```

Input	elec	1-indexed desired electrode.
Output	filter_string	Cell array of stings returning possible filter types.

```
[selection, filters] = xippmex('filter', 'list', elec, filter type, [select]);
```

Input	elec	1-indexed desired electrode.
Input	filter_type	Optional. Name of filter to list. If not specified, a list of filter names is provided for
		the electrode.
Input	select	Optional. If provided, only information about the filter corresponding to 'select' is
		returned in filters.
Output	selection	A scalar indicating which possible filter for the specified 'filter_type' is selected.
Output	filters	An array of structures holding information about selectable filters. If 'select' is
		specified, only the requested filter data is returned.

#### Examples

```
>> xippmex('filter', 'list', 1)
ans = hires' 'hires notch' 'lfp' 'lfp notch' 'spike'
```

This example returns the possible filters for electrode 1.



```
>> [selection, filters] = xippmex('filter', 'list', 1, 'hires');
```

In this example, the list of available 'hires' filters are retrieved for electrode 1. 'selection' is a scalar that shows which filter is currently selected. The returned 'filters' is an array of MATLAB structures holding the filter parameters, including the filter coefficients.

#### Set

The 'set' subcommand allows the end user to choose among the preset filters on the NIP for each filter type.

## Usage

```
xippmex('filter', 'set', elec, filter type, value)
```

Input	elec	1-indexed desired electrode.
Input	filter_type	Name of filter type to modify
Input	value	Filter selection for given filter type

## Examples

```
>> xippmex('filter', 'set', 1, 'hires', 1)
```

In this example, the hires streams filter for electrode 1 is changed from 3 to 1.

#### Custom

The sub-command 'custom' allows for custom filters designed by an end user to be added to any of the currently available filters. The 'custom' filter is always the last filter of the selectable filters. To enable it, first the custom filter must be saved, with the 'custom' command, then selected, with the 'set' command. A filter structure must be created by the user that contains fields matching those returned in the filter structures returned from the 'list' subcommand. The actual filter coefficients must be specified using second order sections (SOS) matrices. See the below examples for more information.

## Usage

```
xippmex('filter', 'custom', elec, filter type, filter struct)
```

Input	elec	1-indexed desired electrode.
Input	filter_type	Name of filter type to modify.
Input	Filter_struct	Filter selection for given filter type. The filter_struct must have the following fields: 'label', 'lowCutoff', 'highCutoff', 'center', 'centerOrder', 'centerFlags', 'lowOrder', 'lowFlags', 'highOrder', 'highFlags', 'maxStages', 'numStages', 'sos'. NOTE: 'numStages' must match the rows in 'sos' and must not exceed 'maxStages'.

#### Examples

```
>> [~, filters] = xippmex('filter', 'list', 1, 'hires');
>> filters(6)
ans = label: 'Custom'
  lowCutoff: 0
highCutoff: 0
  center: 0
```



```
centerOrder: 0
centerFlags: 0
  lowOrder: 0
  lowFlags: 0
  highOrder: 0
  highFlags: 0
  maxStages: 4
  numStages: 0
        sos: [0x6 double]
>> xippmex('filter', 'custom', 1, 'hires', filters(3));
>> [~, filters] = xippmex('filter', 'list', 1, 'hires');
>> filters(6)
ans = label: '0.3-250 \text{ Hz'}
 lowCutoff: 0.3000
highCutoff: 250
     center: 0
centerOrder: 0
centerFlags: 0
   lowOrder: 1
   lowFlags: 0
 highOrder: 4
 highFlags: 0
 maxStages: 4
  numStages: 2
        sos: [2x6 double]
>> xippmex('filter', 'set', 1, 'hires', 6);
```

In this example, the third filter from the hires stream is taken and set as the custom filter. Then the custom filter is enabled.

```
>> [z, p, k] = butter(4, 125/(2000/2), 'low');
>> sos = zp2sos(z, p, k);
>> filter_struct = struct('label', 'myFilter', 'lowCutoff', 0.3, ...
    'highCutoff', 125, 'center', 0, 'centerOrder', 0, ...
    'centerFlags', 0', 'lowOrder', 1, 'lowFlags', 0, ...
    'highOrder', 4, 'highFlags', 0, 'maxStages', 4, ...
    'numStages', 2, 'sos', sos);
>> xippmex('filter', 'custom', 129, 'lfp', filter struct);
```

In this example, a filter is designed with MATLAB's butterworth function and the SOS coefficients are calculated. The required filter structure is built and then set with the 'custom' command.

## Cont

The 'cont' command returns the data from continuous data streams such as lfp, raw, or hi-res. To facilitate this, Xippmex maintains a five second circular buffer for all enabled streams. Continuous data may be retrieved directly off the top of the buffer or by a known NIP timestamp. Recording electrode channels are numbered 1-5120 (1-128 on port A, 129-256 on port B, etc.) and analog input channels are numbered 10241-10270.



## Usage

[data, timestamp] = xippmex('cont', elec, duration, stream type, [NIP timestamp])

Input	elec	1-indexed array of desired electrode(s).
Input	duration	Length of requested data (ms).
Input	stream_type	String defining data stream type. Generally, should be one of 'raw', 'lfp', and 'hi-res'. Possible streams can be found in the 'signal' command.
Input	NIP timestamp	Optional. If specified, 'cont' will return data starting from the given NIP timestamp. If empty, the most recent data will be retrieved. The timestamp is based on NIP 30 kHz clock ticks.
Output	data	MATLAB array containing requested data (µV for neural data, mV for analog I/O inputs). The returned dimensions will be (length of elec) x (sample frequency x duration). LFP streams sample at 1 kHz, hi-res streams sample at 2 kHz, and raw streams sample at 30 kHz.
Output	timestamp	Timestamp for first sample of retrieved data. The timestamp is based on NIP 30-kHz clock ticks.

## Examples

```
>> [data, ts] = xippmex('cont', 1, 100, 'lfp');
```

This returns 100 ms of lfp data for Front End channel 1, along with the NIP timestamp.

```
>> data = xippmex('cont', [1:3], 100, 'raw', 397881690);
```

In this example, 100 ms of raw data is retrieved simultaneously for electrodes 1, 2, and 3 beginning at NIP clock cycle 397881690.

# Digin

The 'digin' command returns events triggered on the Digital I/O Front End. Similar to spike data, xippmex maintains a circular buffer of 1024 digital events. This buffer is cleared when data is retrieved. If more than 1024 events are received by the NIP between 'digin' calls, only the most recent 1024 triggered digital events are returned, though the returned count will always reflect the current number of triggered events.

#### Usage

[count, timestamps, events] = xippmex('digin')

Output	count	The number of digital events received since the last 'digin' call.
Output	timestamps	Array of length 'count' or 1024, whichever is smaller, containing the NIP timestamps
		for each returned event. The timestamp is based on NIP 30-kHz clock ticks.
Output	events	Array of MATLAB structures containing digital event data. Fields are 'reason',
		'sma1', 'sma2', 'sma3', 'sma4', and 'parallel'. The fields 'sma1' through 'sma4' and
		'parallel' hold unsigned 16-bit integer values for the corresponding input. The 'reason'
		field is a bit mask showing which input triggered the digital event. 1 corresponds to
		the parallel port. 2, 4, 8, 16 refer to sma inputs 1, 2, 3, and 4 respectively. 32 refers to
		a digital output marker created when using the 'digout' command.



## Bit-Change

The 'digin' command has a subcommand, 'bit-change', that allows a user to toggle between capturing digital inputs from the parallel port either with the strobe pin or when any bit on parallel port changes. If this property is set to true, the digital parallel port input is captured anytime a bit changes. If the property is set to false, digital parallel port input is only captured if the strobe line is triggered.

## Usage

```
xippmex('digin', 'bit-change', 1);
```

This sets the Digital I/O to capture the state of the 16-bit parallel port anytime a bit changes on that port.

## **Digout**

The 'digout' command controls digital output ports on the Digital I/O Front End. The supply voltage for the digital output pins is 3.3 V. 16-bit unsigned integers may be set on the output parallel port.

## Usage

xippmex('digout', outputs, values)

	_	
Input	outputs	List of outputs to control. 1-4 control SMA outputs 1-4. Specifying output 5 controls
		the output parallel port.
Input	values	List of values to set at ports. 1-4 are binary. I.e., 0 will set them to 0, any positive
		value will set the port to the supply voltage. If the output parallel port is specified,
		the value may be a 16-bit unsigned integer. The length of values must equal the
		length of outputs.

## Examples

```
>> xippmex('digout', 1:2, [1, 1]); pause(0.001); xippmex('digout', 1:2, [0,0]);
```

Assuming that output 1 was initially low, this set of commands will approximate a TTL pulse. The width of the TTL will be determined by the resolution of the pause command and may be system dependent.

```
>> xippmex('digout', 5, hex2dec('CAFE'));
```

This example sets the parallel port output to 0xCAFE.

## Spike

The 'spike' command returns the count, timestamps, waveforms for spikes or stimulation events, and unit classifiers for the requested electrodes. For each electrode, data for up to 1024 spike and stim markers are stored in a circular buffer. When the spike command is called, the spike or stim marker data is retrieved and the buffers are flushed. If more than 1024 spike or stim markers are received between consecutive 'spike' calls, only the most recent 1024 spikes are returned. However, the returned spike counts will not be capped and will reflect the current number of triggered spike events. Spike and stim marker data can be retrieved for several electrodes at a time, and as such, data is returned in cell arrays.



#### Usage

[count, timestamps, waveforms, units] = xippmex('spike', elecs, use stim)

Input	elecs	1-indexed array of desired electrode(s).
Input	use_stim	0 for spike data, 1 for stim (0 is default).
Output	count	Array of same length as elecs, holding the number of spikes received since last call.
Output	timestamps	Cell array of size matching elec, holding arrays of NIP timestamps for each received spike. Each array will have 'count' timestamps. The timestamp is based on NIP 30-kHz clock ticks.
Output	waveforms	Cell array of size matching elec, holding arrays of length 'count' that contain 52-element arrays corresponding to spike or stim waveforms (µV or V).
Output	units	Cell array of size matching elec, holding arrays of unit classification based on unit sorting set in the Trellis Spike Scope application. Unit values are: 0 – unsorted, 1 – pink, 2 – yellow, 3 – green, 4 – purple.

## Examples

```
>> [count, timestamps, waveforms] = xippmex('spike', 5, 1);
```

Retrieves the number of data packets, timestamps, and stimulation data for electrode 5.

```
>> [count, timestamps, waveforms, units] = xippmex('spike', 1:10, 0);
```

Return the counts, timestamps, neural data waveforms, and unit classifiers for electrodes 1 through 10.

## Spike-Thresh

The 'spike-thresh' command can be used to return or set the low and high spike thresholds for the desired electrodes.

#### Usage

```
[low_thresh, high_thresh] = xippmex('spike-thresh', elecs, [lower, [upper]]);
```

Input	elecs	1-indexed array of desired electrode(s).
Input	lower	Optional. Array of same length as elecs, holding the desired 'low' spike thresholds for
		each electrode.
Input	upper	Optional. Array of same length as elecs, holding the desired 'high' spike thresholds for
		each electrode.
Output	low_thresh	Optional. Array of same length as elecs, holding the current 'low' spike thresholds for
		each electrode. This field must be negative.
Output	high_thresh	Optional. Array of same length as elecs, holding the current 'high' spike thresholds for
		each electrode. This field must be positive.

## Examples

```
>> [low thresh, high thresh] = xippmex('spike-thresh', 3);
```

Retrieves the current low and high spike thresholds for electrode 3.

```
>> xippmex('spike-thresh', [4 10], [-40 -50]);
```

Sets the low threshold on electrodes 4 and 10 to -40 and -50 respectively.

```
>> xippmex('spike-thresh', 2, -60, 90);
```

Sets the low and high thresholds on electrode 2 to -60 and 90 respectively.



## Stim

The 'stim' command creates biphasic stimulation trains of arbitrary length and frequency while using a Micro+Stim Front End. Though the basic structure of this command is very simple, relatively complex stimulation is possible including interleaving stimulation between multiple electrodes and bipolar stimulation.

The 'stim' command also includes a subcommand that allows for the control of the NIP's global stim enable property. This may be used to immediately stop stimulation. By default, the NIP's stimulation enable property will be set to false. In normal stimulation usage, xippmex will set the NIP's stimulation enable property to on and after the stimulation has finished will set the property back to off.

**Note:** The amplitude of stimulation is specified with unitless values between 0-100. The amount of current produced by step may vary for each Front End and is a value that must be specified by Ripple. If this parameter is not known, contact <a href="mailto:support@rppl.com">support@rppl.com</a> to obtain the value for your specific hardware.

#### **Stimres**

For Nano2+Stim and Micro2+Stim Front Ends, there is a 'stim' subcommand that sets the stimulation current step-size. This command is applied on a per-Front End basis; i.e. all channels on a particular Front End are set to the 'stimres' stimulation step-size by setting any electrode on that Front End. The current 'res' setting will be returned if the 'stimres' parameter is not specified. Setting the parameter to 1 corresponds to  $1 \mu A/\text{step}$ , 2 is  $2 \mu A/\text{step}$ , 3 is  $5 \mu A/\text{step}$ , 4 is  $10 \mu A/\text{step}$ , and 5 is  $20 \mu A/\text{step}$ .

**Note:** When using the highest step-size, 20  $\mu$ A/step, the range of stimulation output is only  $\pm 75$  steps.

**Note**: When the Grapevine is initially powered on, the default setting of 1 µA/step will be set.

#### Usage

```
output = xippmex('stim', 'res', elecs, [stimres])
```

Input	elecs	1-indexed array of desired electrode(s).
Input	stimres	Optional. Scalar value representative of the desired recording resolution.
		$1 = 1 \mu A/\text{step}, 2 = 2 \mu A/\text{step}, 3 = 5 \mu A/\text{step}, 4 = 10 \mu A/\text{step}, 5 = 20 \mu A/\text{step}.$
Output	output	If no stimres parameter is sent, the current stimres setting is returned.

## Examples

```
>> xippmex('stim', 'res', 10, 3)
```

This sets the Front End associated with channel 10 (the first Front End on port A) to have a stimulation step-size of  $5.0 \,\mu\text{A/step}$ .



## **Stimulation String**

If the second parameter is a valid stimulation string as defined below, xippmex will produce a biphasic pulse pair, with a fixed interphase interval of 66 µs (2 clock cycles).

## Usage

xippmex('stim', stim string);

Input	stim_string	String containing stimulation parameters. See below for detailed discussion.

## **Stimulation String Parameters**

A valid stimulation string is a list of parameters separated by semi-colons, with parameter values organized by electrode separated by commas. For example, the string:

```
'Elect=9,10,;TL=1000.0,1000.0,;Freq=30,30,;Dur=0.2,0.2,;Amp=10,20,;TD=0.0,0.0,;FS=0.0,0.0,;PL=1,1,;'
```

creates symmetric biphasic pulse pairs on electrodes 9 and 10 at 30 Hz. The phases are  $200 \,\mu s$  in duration and the train will run for 1 second. Electrode 9 will have amplitude of 10, and electrode 10 will have amplitude of 20. The following table has the details of each parameter.

"Electrodes." 1-indexed list of desired electrode(s). The length of this list must match the length of		
the lists for all other parameters.		
"Train Length." Length of train of pulse in (ms).		
"Frequency." Frequency of the resulting pulses (Hz).		
"Duration." Duration of both phases of a biphasic pulse (ms). Using "CathDur" and "AnodDur"		
in place of this parameter is valid.		
"Cathodic Duration." The duration of the cathodic phase only (ms). This parameter conflicts with		
Dur and must be used with AnodDur.		
"Anodic Duration." The duration of the anodic phase only (ms). This parameter conflicts with Dur		
and must be used with AnodDur.		
"Amplitude." The current amplitude of a symmetric biphasic pulse. Amplitude must be in the range		
0-100. The current output per step is set at the time of Front End production and will be in the range		
of 1-25 μA per step. Using "AnodAmp" and "CathAmp" in place of this parameter is valid.		
"Cathodic Amplitude." The current amplitude of the cathodic phase only. See "Amp" for more		
discussion of the value of this parameter. This parameter conflicts with Amp and must be used with		
AnodAmp.		
"Anodic Amplitude." The current amplitude of the anodic phase only. See "Amp" for more		
discussion of the value of this parameter. This parameter conflicts with Amp and must be used with		
AnodAmp.		
"Train Delay." Time to delay a stimulation pulse (ms). This parameter may be used for interleaving		
stimulation.		
"Fast Settle." Duration of time to fast settle after the full biphasic pulse (ms).		
"Polarity." In general, this command produces biphasic pulses. If polarity is set to 1, the stimulation		
will be cathodic first. If 0, the stimulation will be anodic first. This parameter is useful for creating		
bipolar stimulation of neighboring electrodes.		



## Examples

In addition to the following examples, the external function stim\_param\_to\_string.m and the xippmex application stimui.m can help to create useful stimulation parameter strings.

```
>>xippmex('stim','Elect=9,10,;TL=1000.0,1000.0,;Freq=30,30,;Dur=0.2,0.2,;Amp=20,20,;TD=0.0,0.0,;FS=0.0,0.0,;PL=1,0,;');
```

This command will produce bipolar stimulation between electrodes 9 and 10 with a frequency of 30 Hz and a train length of one second. In this case, electrode 9 will have the cathodic phase first and electrode 10 will have the anodic phase first. So for the first phase, current will flow from electrode 10 into electrode 9.

```
>>xippmex('stim','Elect=1,;TL=1000.0,;Freq=60,;CathDur=0.2,;AnodDur=0.4,;CathAmp=20,;AnodAmp=10,;TD=0.0,;FS=0.0,;PL=1,;');
```

In this example, an asymmetric biphasic pulse is charged balanced with a 2:1 ratio, where the anodic phase is twice as long as the cathodic phase, though with half the amplitude.

```
>>xippmex('stim','Elect=9,10,;TL=1000.0,1000.0,;Freq=30,30,;Dur=0.2,0.2,;Amp=20,20,;TD=0.0,15.0,;FS=0.0,0.0,;PL=1,1,;');
```

In this example, symmetric biphasic stimulation is produced on electrodes 9 and 10, though interleaved, with pulses on electrode 10 delayed by 15 ms.

## StimSeq

The 'stimseq' command is an advanced command that allows for low-level control of stimulation via the NIP and Stimulation Front Ends (e.g., Micro+Stim). Careful use of this command can produce almost any stimulation waveform, with a temporal resolution as small as  $1 \mu s$ .

The construction of stimulation trains includes two main control blocks. The overall control word specifies the electrode, period of stimulation, and the number of times that the stimulation waveform will be repeated. The second control word defines the repeated waveform. Figure 1 illustrates the breakdown of the overall language.

Stimulation will be executed by the NIP as soon as it is received. The handling of time critical pieces must be performed in MATLAB. Additionally, successive stimulation commands will clobber any existing stimulation and will also occur immediately, potentially disrupting charge balancing. As such care must be taken when sending a series of stimulation commands.






Figure 1. Control word and stimulation diagram

In MATLAB, the control word consists of four fields 'elec', 'repeats', 'period', and 'action', and is packed in a structure, along with the 'seq' field, that specifies the actual stimulation waveform. Each required field is defined in the following table.

elec	Scalar, 1-indexed electrode ID.
repeats	The number of repetitions of the stimulation. In order to perform stimulation this number must be
	at least 1. The number of repeats cannot be greater than 4095.
period	The period at which to repeat stimulation in units of 33.3 µs (one clock cycle at 30 kHz).
action	Optional. Command determining how the stimulation is processed on the NIP. Must be one of the
	following 'immed', 'curcyc', 'allcyc', or 'at-time'. See Section 'action' below. If not specified,
	'immed' is used.
seq	Array of structures that defines the stimulation waveform.

The 'action' field of the stimulation control word tells the NIP how to process the stimulation command. This allows a user to immediately begin stimulation, queue stimulation, or execute stimulation at a defined NIP time. These commands are passed to xippmex as a string and must be one of 'immed', 'curcyc', 'allcyc', or 'at-time'.

#### immed – Process the command immediately

This command will be processed as soon as the NIP receives the command. However, in the case that the new command would interrupt an ongoing stimulation waveform and disrupt charge balancing, the new stimulation train will be placed after the current waveform. Using this command could potentially put two stimulation pulses very close together causing an abrupt change in stimulation frequency. The 'immed' command will clear any stimulation that is currently queued.

#### curcyc – Process the command after current cycle

This command will interrupt any ongoing stimulation. However, instead of executing the new waveform immediately when it is received, the NIP attempts to blend the two frequencies. The new stimulation pulses will be placed such that the time between successive pulses is never less than the updated frequency. If there is no ongoing stimulation when this command is received, 'curcyc' acts identically to 'immed'.



#### allcyc – Queue stimulation after the current train

This command will queue the new stimulation pattern directly after the current pattern has run through its entire train. If consecutive patterns are sent to the NIP with 'alleyc' they will be queued as they are received. The max queue depth is eight patterns. If more than eight patterns are received for a given electrode, the NIP will disable stimulation on that entire Front End.

## at-time – Apply stimulation pattern at a specified NIP time

This command allows a user to specify a later NIP time for when a stimulation pattern will be executed. This command utilizes the 'period' field in the stimulation command word differently than the commands above. As such, only a 16-bit unsigned may be used with the 'period' field of this command. The 'repeats' filed of the command word is necessary but is ignored using 'at-time'; thus stimulation trains are not possible with this command outright, though they may be generated using multiple stimulation pulses and pauses in the command sequences or by sending regular 'at-time' commands and updating the time with regular intervals.

The incoming sequences will be executed when the value in the period field matches the lower 16-bits of the NIP time, or when  $t_{NIP} \& 0xFFFF == period$ .

**Note:** This requires that the NIP must receive 'at-time' commands no later than two seconds from the current NIP time (see 'time' command on page 1 for reference). As multiple commands are received they will be queued similar to using the 'curcyc' and 'allcyc' commands. Stimulation will be disabled on a Front End if a command is received too early to execute or if the queue depth is larger than eight.

The 'seq' field specifies the waveform itself with an array of MATLAB structures. Each element in the array specifies a period of the stimulation where the stimulation parameters are constant. The required fields for stimulation control are the fields 'length', 'ampl', 'pol', 'enable', 'fs', 'delay', and 'ampSelect'. The following table outlines all the required fields in the structure, and Figure 2 provides an example of constructing a simple biphasic pulse pair.


length	The number of 33.3 µs units for this command (cannot be 0).		
ampl	Amplitude of current stimulation. Must be 0-100. The amount of current per step varies across		
	Front Ends and is a number that is provided by Ripple with each Micro+Stim Front End.		
pol	Polarity of stimulation. If 0, the resulting current will be negative, if 1, the resulting current will		
	be positive.		
enable	Specifies whether the next transition is to zero output (interphase interval) or positive/negative		
	stimulation (anodic/cathodic). If there is not stimulation in this period, this should be 0. If current		
	output is wanted, positive or negative, this should be 1.		
fs	Enable fast settle during this stimulation period.		
delay	Time to delay this word to become active in units 33.3 $\mu$ s / 31 = 1.04 $\mu$ s. This number must be		
	between 0-31. This word allows for the control of stimulation at a temporal resolution of almost 1		
	μs but is only valid for particular waveforms.		
ampSelect	Choice of stimulation amp or neural amp. 0 for neural amp, 1 for stimulation amp.		

**Note:** The amplitude of stimulation is specified with unitless values between 0-100. The amount of current produced by step may vary for each Front End and is a value that must be specified by Ripple. If this parameter is not known, contact <a href="mailto:support@rppl.com">support@rppl.com</a> to obtain the value for your specific hardware.



## Examples

In this first example, the waveform described in Figure 2 is created with a frequency of 30 Hz and a train length of one second. A complex example is distributed with xippmex that produces sinusoidal stimulation of arbitrary frequencies and amplitudes. See the MATLAB function stim\_sin.m for more information.



- A. The first, cathodic phase of the waveform can be created with length set to 6, pol set to 0, and enable set to 1. All other fields may be set to zero.
- B. The interphase interval can be created using length of 3 and setting amplitude to zero. All other fields may be set to zero.
- C. The last, anodic phase can be produced by matching the word from 'A' only with the pol field set to 1.

Figure 2. A basic biphasic pulse pair can be constructed with three words, in this example: A, B, and C.

```
% create the overall header values defining electrode, frequency,
% and number of repeats. This will stimulate on electrode 1 at 30
% Hz for one second.
cmd = struct('elec', 1, 'period', 1000, 'repeats', 30);
% Create the first phase (cathodic) for stimulation. This has a
% duration of 200 us (6 clock cycles at 30 kHz), an amplitude of
% 10, and negative polarity.
cmd.seg(1) = struct('length', 6, 'ampl', 10, 'pol', 0, ...
    'fs', 0, 'enable', 1, 'delay', 0, 'ampSelect', 1);
% Create the inter-phase interval. This has a duration of 100 us
% (3 clock cycles at 30 kHz). The amplitude is zero. The
% stimulation amp is still used so that the stim markers sent by
% the NIP will properly contain this phase.
cmd.seq(2) = struct('length', 3, 'ampl', 0, 'pol', 0, 'fs', 0, ...
    'enable', 0, 'delay', 0, 'ampSelect', 1);
% Create the second, anodic phase. This has a duration of 200 us
% (6 cycles at 30 kHz), and amplitude of 10, and positive polarity.
cmd.seq(3) = struct('length', 6, 'ampl', 10, 'pol', 1, ...
    'fs', 0, 'enable', 1, 'delay', 0, 'ampSelect', 1);
% Send the stimulation
xippmex('stimseq', cmd);
```



In the second example, the use of the 'delay' field is demonstrated to produce a biphasic pulse with phases narrower than the 30 kHz clock cycles. Here, a symmetric biphasic pulse is created with 50 µs pulsewidth. Because this requires a temporal resolution less than 33.3 µs, the 'delay' parameter will need to be used. Figure 3 illustrates the needed words and boundaries on the 30 kHz clock.




Figure 3. Illustration of the required stimulation words needed to create a biphasic pulse with 50  $\mu$ s phases. As this requires a temporal resolution finer than 33.3  $\mu$ s, the delay parameter will be used. The dashed lines represent the 30 kHz clock. Each new color shows where a new stimulation word is used.

```
% xippmex('stimseq') example producing a symmetric biphasic pulse with
% phases of 50 us and an inter-phase interval of 100 us. This example
% makes use of the stimulation control word's 'delay' field.
% single clock cycle in microseconds
clock cycle = 1 / 30 * 1000;
% calculate the length of a single unit of delay in microseconds
delay length = 1 / 30 * 1000 / 32;
% Setup the basic header elements.
                                    This will produce stimulation at 30
% Hz for one second
cmd = struct('elec', 1, 'period', 1000, 'repeats', 30);
% first command word. Produce 1 clock cycle worth of stimulation, for
% 33.3 us of the first 50 us phase.
cmd.seq(1) = struct('length', 1, 'ampl', 10, 'pol', 0, 'fs', 0, ...
    'enable', 1, 'delay', 0, 'ampSelect', 1);
% calculate the remaining duration of the cathodic phase. Because
% this is less than one clock cycle period the delay field will need
% to be used
cath remaining = 50.0 - clock cycle;
% the actual delay parameter must be an integer between 0 and 31
cath delay = floor(cath remaining / delay length);
% This word will produce the full cathodic phase and a bit of the
% inter-phase interval. Here, the 'enable' field set to zero, sets
% the pulse to start high and transition to off.
cmd.seq(2) = struct('length', 1, 'ampl', 10, 'pol', 0, 'fs', 0, ...
    'enable', 0, 'delay', cath delay, 'ampSelect', 1);
% The inter-phase interval is 100 us, so add two more full clock
% cycles worth of stimulation for 66.6 us more.
cmd.seq(3) = struct('length', 2, 'ampl', 0, 'pol', 0, 'fs', 0, ...
    'enable', 0, 'delay', 0, 'ampSelect', 1);
% calculate how much more of the inter-phase interval is remaining
% being careful to account for the quantization of the delay at the
 end of the cathodic phase
```



```
ipi remaining = 100.0 - (clock cycle - cath delay * delay length) - ...
    2 * clock cycle;
ipi delay = floor(ipi remaining / delay length);
% add this to the sequence list. Here the enable field sets the
% pulse to start off and transition to on.
cmd.seq(4) = struct('length', 1, 'ampl', 10, 'pol', 1, 'fs', 0, ...
     'enable', 1, 'delay', ipi_delay, 'ampSelect', 1);
% At this point there is not a full clock cycle's worth of stim left,
% so the pulse will be finished with one use of the delay field
anod remaining = 50.0 - (clock cycle - ipi delay * delay length);
anod delay = floor(anod remaining / delay length);
% add the last command word
cmd.seq(5) = struct('length', 1, 'ampl', 10, 'pol', 1, 'fs', 0, ...
     'enable', 0, 'delay', anod delay, 'ampSelect', 1);
% fire off stimulation
xippmex('stimseq', cmd);
```

#### Enable

If the second parameter of the 'stim' command is 'enable', xippmex will return or control the global stimulation enable property of the NIP. This functionality can be important if there is ever a need to immediately halt stimulation.

#### Usage

```
>> xippmex('stim', 'enable')
ans = 0
```

Here, the NIP's global stimulation enable is returned. "False" is the default setting for this property.

```
>> xippmex('stim', 'enable', 0);
```

In this example, the stimulation enable property is set to false. This can be used to immediately halt stimulation.

#### Module Enable

If the second parameter is 'module-enable', xippmex will return or control the enable status for a given electrode. Though the parameter is for a given electrode, the control is actually for the entire Front End that includes the given electrode.

#### Usage

```
>> xippmex('stim', 'module-enable', electrode, [value]);
```

## Examples

```
>> xippmex('stim', 'module-enable', 1); ans = 0
```

This example returns the stim enable property of just the Front End associated with electrode 1, which is set to false.

```
>> xippmex('stim', 'module-enable', 1, 1);
```

This example sets the stim enable property of just the Front End associated with electrode 1 to be true (ON).



#### Fast Settle

Xippmex can control the NIP's fast settle capability, allowing for successful recordings within a millisecond of stimulation on neighboring electrodes. Fast settle may be set to occur directly after stimulation produced by the NIP or triggered off of digital events, useful if used with external stimulators. The fast settle period, or the length of time to settle the ADC, can also be set with this command.

#### Stim

The subcommand 'stim' sets fast settle triggering to occur from outgoing stimulation by the NIP. Fast settle may be triggered by any stim electrode on the NIP, by any stim electrode connected to the same front end port, or by a stim electrode on the same Front End. All Grapevine Front Ends support fast settle with the exception of the Surf D and EMG Front Ends.

## Usage

xippmex('fastsettle', 'stim', electrode, [source, [duration] ]);

Input	electrode	Scalar, 1-indexed electrode ID.
Input	source	Optional. Index of desired source. If not specified, the current source index is returned. These are 1-'none', 2-'any front end', 3-'same front end port', or 4-'same front end'.
Input	duration	Optional. Duration of fast settle in milliseconds.

## Examples

```
>> [index, source_list, duration] = xippmex('fastsettle', 'stim', 1, 2, 0.5);
This command will set fast settle for the Front End associated with electrode 1, to be triggered by
```

>> [index, source\_list, duration] = xippmex('fastsettle', 'stim', 1);

stimulation on any Front End with a fast settle duration of 0.5 ms.

This command will only return the electrode index, list of all available fast settle settings, and fast settle duration.

## Digin

The subcommand 'digin' sets fast settle triggering to occur from a specified digital input.

#### Usage

xippmex('fastsettle', 'digin', electrode, [source, [duration]]);

Input	electrode	Scalar, 1-indexed electrode ID.
Input	source	Index of digital input used to trigger fast settle. The choices here are 1-'none', 2-'Dig Input 1', 3-'Dig Input 2', 4-'Dig Input 3', and 5-'Dig Input 4'.
Input	duration	Duration of fast settle in ms.

## **Examples**

```
>> xippmex('fastsettle', 'digin', 1, 3, 1.5);
```

This command will set fast settle for the Front End associated with electrode 1, to be triggered by the Digital I/O Front End SMA input 2, with a fast settle duration of 1.5 ms.



## Impedance

The 'impedance' command can be used to return the magnitude of the Impedance (in Ohms).

**Note:** This command is currently only fully supported for the Link 32 but is functional for other Front Ends as well.

## Usage

```
output = xippmex('impedance', elecs);
```

Input	elecs	1-indexed array of desired electrode(s). Each electrode must be from the same Front End.
Output	output	Array of same length as elecs, holding the magnitude of the Impedance result (in Ohms)
		for each electrode.

## **Examples**

```
>> output = xippmex('impedance', [1 9]);
```

Retrieves the magnitude of the Impedance result in Ohms for channels 1 and 9.

#### **Transceiver**

The 'transceiver' command can be used to enable or disable a Link 32 transceiver.

## Usage

xippmex('transceiver', front end, enable);

Input	front_end	Front End location of the Link 32 transceiver. Position $A.1 = 1$ , $A.2 = 2$ ,, $D.4 = 16$
Input	enable	Binary value to enable (1) or disable (1) the Link 32 transceiver.

#### Examples

```
>> xippmex('transceiver', 7, 1);
```

Enables the transceiver in Port B, position 3 (B.3) and returns a value of '1' if the command was successful.

#### Sensor

The 'sensor' command can be used to query power usage statistics from Ripple processors with an internal battery such as the Grapevine Nomad or Explorer Quest HD.

#### Usage

```
output = xippmex('sensor', source, [value]);
```

Input	source	String associated with power source of interest. Options are 'battery', 'wall', or 'vdd'
Input	value	Optional: Value to return in output. Options for sources 'wall' and 'vdd' are 'current',
		'voltage', or 'power'

#### Examples

```
>> battery remaining = xippmex('sensor', 'battery');
```

Returns the remaining battery life in percent (0-100) of the internal battery.



```
>> [i,v,p] = xippmex('sensor', 'wall');
```

Returns the wall current in amps as the variable 'i', the wall voltage in volts as the variable 'v', and the wall power in watts as the variable 'p'.

## Ground

The 'ground' command can be used to tie channels of an Explorer EEG or ECoG Front End to the ground channel.

## Usage

xippmex('ground', elecs, enable);

Input	elecs	1-indexed array of desired electrode(s).
Input	enable	Binary value to enable this connection (1) or disable this connection (0).

## Examples

```
>> xippmex('ground', 16:32, 1);
Grounds channels 16 through 32.
```

```
>> xippmex('ground', 1:32, 0);
```

Disables ground ties on channels 1 through 32.

## Reference

The 'reference' command can be used to tie channels of an Explorer EEG or ECoG Front End to the reference channel.

#### Usage

```
xippmex('reference', elecs, enable);
```

Input	elecs	1-indexed array of desired electrode(s).
Input	enable	Binary value to enable this connection (1) or disable this connection (0).

## Examples

```
>> xippmex('reference', 1:2, 1);
```

Ties channels 1 and 2 to reference.

```
>> xippmex('reference', 2, 0);
```

Disables reference tie on channel 2.



This section contains demonstration programs built on the Xippmex interface that are included with xippmex. These are all open source and are great examples for a user developing custom MATLAB programs using xippmex.

## Walkthrough

A xippmex walkthrough is included in the installation that demonstrates many of the functionality described earlier in this document. The walkthrough will demonstrate the following functionality:

- Initialize and close xippmex
- Find electrodes corresponding to different Front End types (Micro, Nano, Stim)
- Enable and Disable data streams
- Modify filters on the NIP data streams
- Configure Trellis data taking
- Create simple stimulation pattern
- Retrieve data and make a simple plot

## Stimui GUI

The stimui MATLAB GUI allows for basic control of biphasic stimulation with symmetric anodic and cathodic phases with a constant 67-µs inter-phase interval. Provided here is a basic description of the functionality. Figure 4 shows the stimui window and may be used as reference for all of the following element descriptions.

This application provides similar functionality, though with significantly less features, to the Trellis Stim application. In general, there is no reason to do stimulation with stimui rather than with Trellis, however it provides a fully functional example that could help in the development of future MATLAB applications based on Xippmex.




Figure 4. stimui GUI



- **Stim Electrodes**: Displays the 1-indexed electrode ID for all the Micro+Stim Front End stimulation electrodes connected to the NIP.
- Saved Electrodes: Lists all the stimulation parameters for saved electrodes. Add electrodes to this list using the "Save" button. Saving electrodes is required to stimulate on multiple electrodes at once. Each electrode may have independent stimulation parameters.
- Save: The "Save" button adds the selected electrode to the "Saved Stim" list or replaces the previously selected parameters with the current parameters. This button must be selected every time that a user wants to change the saved parameters. Selection of multiple electrodes is allowed.
- **Remove**: Remove the selected electrodes from the "Saved Stim" list.
- **Bipolar**: Bipolar stimulation is executed by stimulating on two electrodes with identical parameters, though with opposite polarities. The "Bipolar" button saves stimulation on two electrodes; however, one will have the "Cathodic First" check box selected and the other will not. See the discussion of this checkbox below.
- **Channel Parameters**: stimui always produces symmetric biphasic pulse pairs with a 67-µs interphase interval. The channel parameters are:
  - o <u>Amplitude</u> The current amplitude of each phase in microamperes.
  - Phase Duration The duration of each phase in milliseconds. If this number is 200 microseconds, the entire stimulation waveform will be 467 microseconds, as each pulse corresponds to two equal phases and an interphase interval.
  - o Frequency Frequency of pulses in Hertz.
  - Train Length The length of stimulation burst in milliseconds. The total number of pulses will be "Train Length" times "Frequency".
  - o Train Delay Delay of the stimulation for interleaving in milliseconds.
  - o <u>Fast Settle Time</u> Add fast settle period after stimulation pulse in milliseconds, if the "Fast Settle" checkbox is selected. This value will be added after the complete stimulation pulse.
  - <u>Enable</u> Enabling or disabling of stimulation of this channel in "Saved Stim" list. This allows for the stopping of stimulation of a given channel without having to erase saved stimulation parameters.
  - O Cathodic First If selected (by default), the first phase will be cathodic, otherwise the first phase will be anodic. Bipolar stimulation is done using nearby electrodes with identical parameters, but with one having the "Cathodic First" selected and one without, producing identical waveforms with opposite polarity.
- **Fast Settle**: If selected, electrodes in the fast settle list will have a fast settle period until after the stimulation pulse.



- **Single Pulse**: This checkbox forces the "Train Length" to be one period as determined by the "Freq" setting so that there will always be a single pulse.
- **Stim Single**: Sends stimulation commands on the selected electrode in the "Saved Stim" list. This command only works for single electrodes.
- Stim Saved: Sends stim commands for all the electrodes in the "Saved Stim" list.
- **Fast Settle**: Add electrodes to the list of fast settle electrodes.
- **Print Stim String:** Display the stimulation string for the xippmex 'stim' command. The stimular application makes use of the xippmex command 'stim' and the interface can quickly allow for the creation of fairly complex stimulation waveforms. Sometimes displaying this string can help in the development of new applications or to learn the stimulation string syntax.

## Real-time modulation of stimulation parameters

There are three demos included in xippmex that make use of the 'stimseq' command to facilate real-time control of stimulation parameters. These demos are CLstim\_AmplitudeModulation\_32ch.m, CLstim\_FrequencyModulation\_32ch.m, and CLstim\_PulsewidthModulation\_32ch.m. All of these examples take an analog input and modulate a stimulation parameter based on that input, either amplitude, frequency, or the pulsewidth of the outgoing stimulation. These demos were developed and tested using FlexiForce sensors available at <a href="https://www.tekscan.com">https://www.tekscan.com</a> and are relatively cheap. However, they will work with any analog input and could be quickly modified for any style sensors.



# **Revision History**

Version 01

Initial release

Version 02

• Clarifications made to the 'elec' and 'signal' commands

Version 03

• Unit Classification added to the 'spike' command

• Note added for interphase interval when using stimString command

• Added the 'fastsettle' command

• Added 'bit-change' to the 'digin' command

• Included explanation of the 'action' field to the 'stimseq' section

• Included xippmex walkthrough and real-time demos to the Demos section

Version 04

 Added the 'adc2phys', 'lowcorner', and 'stimres' commands for new Nano2 and Micro2 style Front Ends

Version 05/06

• Cleanup of all function descriptions

Version 07

• Add section for starting xippmex in UDP and TCP mode

• Add 'addoper' function and description

• Modify 'trial' function usage

• Remove 'opers' function

Version 08

• Correct 'fastsettle', 'stim' command return values

Updated 'spike' command units description to reflect latest Trellis sorted unit colors

Version 09

• Added 'spike-thresh' function and description

Version 10

• Added 'impedance' and 'transceiver' commands for the Link 32 Front End

Version 11

• Added 'sensor' command for Nomad and Quest HD processors

• Added 'ground' and 'reference' commands for Explorer EEG and ECoG Front Ends