Sma Institute of Engineering & Jachnoo

PRACTICAL MANUAL

Control System Lab

EXPERIMENT NO. 10

To study the Linear System Simulator

# **EXPERIMENT: - 10**

**OBJECT**: - To determine the response of first order and second order systems for step input for various values of 'K' using Linear System Simulator and compare theoretical and practical results.

# **APPARATUS REQUIRED: -**

Experimental Kit having following components

- 1. Error detector with gain.
- 2. Integrators.
- 3. Time constant.
- 4. The disturbance.
- 5. Amplifiers
- 6. Signal source (i) square wave. (ii) Triangular wave (iii) Sine wave. (iv)Trigger 7 CRO

### THEORY: -

## A) Time response of a first order system

Time response of a first order control system subjected to unit impulse input function The output for the system is expressed as

$$C(s) = R(s) \times \frac{1}{sT + 1}$$

As the input to the system is a unit impulse function, its Laplace transform is 1, *i.e.* R(s) =1, therefore, substituting in equation

$$C(s) = 1 \times \frac{1}{sT+1}$$

Taking inverse Laplace transfer on both side of equation

$$\pounds^{-1}C(s) = \pounds^{-1}\frac{1}{sT+1}$$

$$\pounds^{-1}C(s) = \pounds^{-1} \frac{1/T}{s + \frac{1}{T}}$$

$$C(t) = \frac{1}{T} e^{-t/T}$$

The time response in relation to equation is shown. Laplace transforms function and corresponding time response of a first order control system subjected to these input function is given.

It is observed that step function is the first derivative of the ramp function and impulse function is first derivative of a step function. From the derived time response expression it is concluded that the output time response also follows the sequence as that of input functions.

**B)** Time response of a second order control system: A second order control system is one wherein the highest power of *s* in the denominator of its transfer function equals 2. A general expression for the transfer function of a control system given by

$$\frac{C(s)}{R(s)} = \frac{\omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2}$$

The parameter  $\zeta$  and  $\omega_n$  will be explained later. The block diagram representation of the transfer function given by above equation is shown in figure-1

# (i) Time response of a second order control system subjected to unit step input function:

The output for the system is given by

$$C(s) = R(s) \times \frac{\omega_n^2}{s^2 + 2\zeta \omega_n s + \omega_n^2}$$

As the input is a unit step function

$$r(t) = 1$$
 and

$$R(s) = 1/s$$

Therefore substituting in equation

$$C(s) = \frac{1}{s} \times \frac{\omega_n^2}{s^2 + 2\zeta \omega_n s + \omega_n^2}$$

In equation rewriting the term ( $S^2 + 2\zeta\omega_n s + \omega_n^2$ )

As  $(s + \zeta \omega_n)^2 + \omega_n^2 (1 - \zeta^2)$  and breaking R.H.S. in to partial fractions

$$C(s) = \frac{1}{s} \times \frac{s + 2\zeta\omega_n}{((s + 2\zeta\omega_n)^2 + \omega_n^2(1 - \zeta^2))}$$
$$\omega_d = \omega\sqrt{1 - \zeta^2}$$
$$C(s) = \frac{1}{s} - \frac{s + 2\zeta\omega_n}{(s + \zeta\omega_n)^2 + \omega_d^2}$$

Taking inverse Laplace transfer on both sides of equation

$$\mathcal{L}^{-1}C(s) = \mathcal{L}^{-1}\left\{\frac{1}{s} - \frac{s + \zeta\omega_n}{(s + \zeta\omega_n)^2 + \omega_d^2} - \frac{\zeta\omega_n}{\omega_d} \times \frac{\omega_d}{(s + \zeta\omega_n)^2 + \omega_d^2}\right\}$$

Therefore

$$C(t) = 1 - e^{-\zeta \omega_n t} \cdot \cos \omega_d t - \frac{\zeta \omega_n}{\omega_d} \cdot e^{-\zeta \omega_n t} \cdot \sin \omega_d t$$

$$C(t) = 1 - \frac{e^{-\zeta \omega_n t}}{\sqrt{1 - \zeta^2}} \sin\left[\left(\omega \sqrt{1 - \zeta^2}\right)t + tan^{-1}\left\{\frac{\sqrt{(1 - \zeta^2)}}{\zeta}\right\}\right]$$

**Time constant**: Next to integrator these blocks simulates type 0, system and its transfer function is in the form of  $-K_1/(sT+1)$ . The next time constant block is similar to the first except it has one other input x10, which result in 10 times higher gains necessary to form second order system order system simulating .It transfer function is in the form of  $-K_2/(sT+1)$ .

#### **PROCEDURE:-**

- **a) First order close loop system**: Two types of first order system can be configured as shown in fig.1 Make connection as shown and follows.
  - 1. Apply 1 Vpp 40 Hz square wave signal to the input and note the response curve on tracing papers setting gains at 1, 2, and 3 and so on.
  - 2. Calculate the time constant (for type 0 system) in each case and verify the result from theoretical as given before.
  - 3. Calculate the steady state error from above cases.
  - 4. In case of type –1, system particularly it is difficult to find out the steady state error. Switch CRO to XY mode and connect its X input with the triangular wave input, keeping triangular output equal to square.
  - 5. Write the result from the experiment and compare it with the theory.

There may some imperfection since there is a tolerance between practical and theory.

- **b)** The second order system: Connect the circuit in proper manner and proceed as follows.
  - 1. Apply 1 Vpp 40Hz square wave signal to the input and trace the output waveforms for different setting of error gain K upon paper.
  - 2. From the trace find out the value of  $t_d$ ,  $t_r$ ,  $t_p$ ,  $M_p$ ,  $t_s$  and  $e_{ss}$ . Calculate the theoretical values and compare it with practical results.
  - 3. In case of type- 1, system use XY mode stated as before for e<sub>ss</sub> evaluations.

For type one system starts K from 10.0 and then decrease it for type 0, start from lower side setting and then increase.

#### **Disturbance rejection:-**

Other apparatus required, low freq.

- 1. Connect the circuit as shown in fig.2
- 2. Feed low frequency sine wave signal (20 Hz) of 1Vpp at input of error detector. Observe the effect of disturbance upon the system.
- 3. Disconnect the sine wave signal from the input and connect it with output disturbance adder. Observe the effect.

It is observed that when the disturbance signal added at input it becomes added at output the error detector rejects it effectively.

# **CIRCUIT DIAGRAM:-**




Figure-1 Connection Diagram for Open Loop Responses




Figure-2 Connection Diagram for Close Loop Responses

# **CALCULATION:-**

# **RESULT:-**

# **PRECAUTIONS:-**

- 1) Read operating manual before working on the kit.
- 2) Check the connection before switching power supply.
- 3) Don't change the connection without switching off the supply of the experiment kit.
- 4) Draw the traces from CRO properly.
- 5) Keep the connecting lead and ancillary equipment at proper.

# **VIVA QUESTIONS:-**

- 1) What do you mean by Linear System simulator?
- 2) What is the difference between Open Loop and Closed Loop system?
- 3) Differentiate the type and order of systems.
- 4) Give an example of a close loop system.
- 5) Explain damping ratio and damping frequency.

# **INDUSTRIAL APPLICATIONS:-**

Linear System Simulator is used for time Domain studies of the Open Loop and Closed Loop performance of 1st order and 2nd order systems of Type-0 and Type-I.

It is also used for low frequency, square, triangular and sine wave generators.