How can we help?

Enter question or keyword. Example: Order Search Help

Back
My Orders
My Account
Balance & Coupons
Shipping & Delivery
Service & Refunds
Payments
Technical Support
Generate Gerber
Design Instruction
Ordering Parameter Instruction
Production Issues
Process Introduction
PCB Engineering Questions
PCB Assembly FAQ
Certification
3D Printing
CNC Machining
Sheet Metal
Injection Molding & Vacuum Casting
Design Service

Common Rules for PCB Routing

1. Length Control in Routing

Length controlling is very important in PCB design. The traces should be kept as short as possible to avoid introd unnecessary interference due to excessive length. For important signal traces, such as clock signal traces, be su place its oscillator very close to the device.



2. Direction Control in Routing

The routing directions of adjacent layers should be orthogonal to avoid the signal traces of adjacent layers runnir same direction, thus reducing unnecessary crosstalk between layers.



3. Rules for Chamfer

Sharp angles and right angles should be avoided in PCB design, otherwise, unnecessary radiation will be generate the process performance will be poor.



4. Open Loop Detection in Routing

Generally, dangling lines are not allowed. This is mainly to avoid the "antenna effect" and reduce unnecessary int radiation and reception. Otherwise, serious consequences may occur.



5. Try to Avoid Self-loop Routing

When designing PCB, we should pay attention to the situation where signal traces form self-loops between differ layers. Especially when routing multi-layer boards, signal traces are routed between layers, which has a greater ch forming self-loops. Self-loops can cause radiation interference.



6. Rules for Ground Loop

The minimal loop rule states that the loop area formed by a signal trace and its return path should be as small as
The smaller the loop area, the less external radiation it emits and the less interference it receives from the outsid



7. Rules for the Integrity of Power and Ground Layers

For areas with dense vias, care should be taken to avoid the holes connecting to each other in the hollowed-out a
the power and ground layers, which would segment the plane layer.

This may destroy the integrity of the plane layer and further increase the loop area of the signal trace in the groun



8. 3W Rule

In order to reduce crosstalk between traces, the trace spacing should be large enough. When the center-to-center
between traces is at least three times the space width, 70% of the electric field will not interfere with each other, k
the 3W rule. To achieve 98% of the electric field not interfering with each other, a 10W spacing can be used.



9. Shielding Protection

Shielding protection corresponds to the ground loop rule, which is actually to minimize the loop area of the signal more common in some important signals, such as clock signals and synchronization signals. For some particula important, high-frequency signals, a coaxial cable shielding design should be considered. This involves isolating t traces with ground traces on all sides (top, bottom, left, and right). Additionally, careful consideration must be giv effectively to connect the shield ground to the actual ground plane.



10. Rules for Impedance Matching Check

The routing width in the same network should be kept consistent. Changes in trace width can cause non-uniform characteristic impedance of the circuit, leading to reflections when the transmission speed is high. This should b in the design whenever possible. Under certain conditions, such as structures similar to lead-out traces of connec the lead-out traces of BGA packages, changes in trace width may be unavoidable, so the effective length of the inconsistent sections should be minimized.



11. Rules for Overlapping Power and Ground Layers

Different power layers should avoid overlapping in space to reduce interference between different power supplies especially important for power supplies with significantly different voltages. If it is difficult to avoid, consider plac ground plane in between.



12. 20H Principle

To prevent board edge radiation, the power plane should be retracted during design. Using H (the dielectric thickn between the power and ground) as a unit, a retraction of 20H can confine 70% of the electric field within the edge ground layer, while a retraction of 100H can confine 98% of the electric field within it.



Last updated on 13/09/2024

Related articles

- Refuse conductive adhesive technology in pcb manufacture
- What a PCB Is Made Of
- What is your factory's standard of panel by tab-route?
- What is your requirements of V-cut?
- How to make my silkscreen clear and beautiful on PCB ?
- What diameter of via is better to have soldermask covering ?
- What is not correct for bottom text ?
- How to design the half (castellated) holes for PCB?
- PCB Manufacturing Terms Glossary
- Electronic Terms Glossary
- How to create a Centroid File(pick place) from Eagle, Altium,Sprint Layout and ORCAD?
- Generate Position File Centroid File(pick place) in Kicad
- How to generate BOM and Pick and Place File in Proteus 8.13
- How to Create a SMD footprint using the Allegro PCB Editor?
- How to Create a SMD pad using the Allegro Padstack Editor?
- How to Generate a Pick and Place File in .csv Format from Fusion 360?
- How to add a Board Outline to my Gerber Plots in DesignSpark PCB V11.0.0?
- PCB Panelization, Breakaway Rails, Fiducial Marks, Tooling Holes
- PCBWay Custom Design Rules
- Printed Circuit Board Terminology

Comments (**0**)

This message here is only a suggestion supplement to the above content, and does not for trading operations su
orders. If you have any urgent questions or order issues, please contact your sales rep.

Log in to post comments.

Upload photo

You can only upload 5 files in total. Each file cannot exceed 2MB. Supports JPG, JPEG, GIF, PNG, BMP

Post Comment

© 2024 PCBWay. All rights reserved.