- of gas in the lungs, reduce dead space, and increase oxygenation by increasing mean and plateau airway pressures.
- PSV is used to support spontaneous breaths in a patient with an artificial airway when the IMV or spontaneous/CPAP modes are used.
- PRVC provides closed-loop pressure breaths and targets the pressure to achieve the set volume.
- In volume support, the set  $V_T$  is the minimum  $V_T$ . A patient can obtain a higher  $V_T$  if desired.

#### **REVIEW QUESTIONS** (See Appendix A for answers.)

- A respiratory therapist is determining the tubing compliance of a ventilator before use. A volume of 100 mL delivers a pressure of 33 cm H<sub>2</sub>O. What is the compliance of the circuit?
- 2. After initiation of ventilation using the circuit described in Question 1, the PIP is 15 cm  $H_2O$  and the  $V_T$  set is 250 mL. What is the approximate volume actually reaching the patient?
- **3.** A patient receiving ventilation with a CareFusion AVEA has a set  $V_T$  of 700 mL, and f is at 12 breaths/min on the VC-CMV mode. The patient is initiating another 3 breaths/min so that the total f is 15 breaths/min. What is the patient's actual  $\dot{V}_E$ ? Also answer the following questions.
  - A. If the flow is set at 30 L/min using a constant flow pattern, what is the flow in L/s?
  - B. What is the TCT based on the set machine f of 12 breaths/ min?
  - C. What is the TCT based on the actual machine f of 15 breaths/min?
  - D. What is the  $T_I$  based on the set f, flow, and  $V_T$ ?
  - E. What is the  $T_E$  when the f is 12?
  - F. What is the  $T_E$  when the f is 15?
- **4.** A therapist wants to select a flow waveform and flow setting for a patient with severe asthma. Which of the following is a good initial setting?
  - A. Constant flow, 60 L/min
  - B. Ascending flow, 80 L/min
  - C. Descending flow, 70 L/min
  - D. Sine flow, 40 L/min
- **5.** A practitioner sets an inspiratory pause of 0.5 seconds to obtain a P<sub>plat</sub> reading and calculate the patient's static compliance. During the measurement, a stable plateau is not seen on the pressure-time graph. What could be the problem?
- 6. A post—coronary artery bypass graph (CABG) surgery patient is still intubated and under the effects of anesthesia. He is being transferred from the operating suite to the recovery unit. The surgeon wants to keep ventilation pressures to a minimum and is less concerned about ventilation. The patient's body temperature is 35° C. He is 5-ft, 9-in tall and weighs 210 lb.
  - A. What is the patient's BSA?
  - B. What is his IBW?
  - C. What is an appropriate initial  $\dot{V}_E$ ?
  - D. Would you use PC-CMV or VC-CMV and why?
  - E. What V<sub>T</sub> would be an appropriate target?
  - F. Based on the V<sub>T</sub> you selected, what would be an appropriate rate?
  - G. What PEEP would you set?

- 7. A patient with ARDS is to be changed from a CPAP of +10 cm  $H_2O$  to VC-CMV. She is 5-ft, 4-in tall and weighs 195 lb. What tidal volume and rate would you set and why? Would pressure control ventilation be appropriate for this patient?
- 8. NIV is being initiated on a 54-year-old man with a history of COPD. He has an IBW of 70 kg. The initial settings are IPAP = 8 cm  $H_2O$  and PEEP = 3 cm  $H_2O$ . The patient's  $V_T$  on these settings is 280 mL and f is 27 breaths/min. What change would you recommend?
- 9. A patient with right lower lobe pneumonia and a temperature of 100° F needs mechanical ventilation. How should the initial  $\dot{V}_E$  be adjusted? (HINT: See Box 6.1.)
- 10. A physician requested that her patient be switched from PCCMV to VC-CMV to guarantee volume delivery. Ventilator parameters are VC-CMV + PSV;  $V_T=0.6$ ; f=20 breaths/min, flow = 60 L/min (using constant flow waveform); PSV = 27 cm  $H_2O$ ; PEEP = +8 cm  $H_2O$ ; PIP = 56 cm  $H_2O$ ; and  $P_{plat}=43$  cm  $H_2O$ . The physician asked the respiratory therapist to find a way to reduce pressures without changing  $\dot{V}_E$ . What is a possible solution?
- 11. A ventilator is set with PRVC with a PEEP = +5 cm  $H_2O$ , a set  $V_T$  of 650 mL, and an upper pressure limit of 30 cm  $H_2O$ . Initially the pressure required to deliver the  $V_T$  was 20 cm  $H_2O$ . After 24 hours, the pressure required to deliver the set  $V_T$  increases to 24 cm  $H_2O$ . What changes have probably occurred in the patient's lung characteristics?
- **12.** What ventilator mode is patient triggered, pressure targeted, and flow cycled and also targets a set tidal volume?
- 13. The pressure-time and flow-time curves above are viewed during PC-CMV ventilation with an apneic patient. What is the P<sub>plat</sub>?
- **14.** The pressure-time curve above is observed during PSV. Which of the following would you suspect on the basis of the ventilator graphic recording?
  - A. Active exhalation
  - B. No sloping in the presence of increased airway resistance
  - C. A leak in the circuit
  - D. Active inhalation

### References

- Harris JA, Benedict FG: A biometric study of human basal metabolism, Proc Natl Acad Sci USA 4(12):370-373, 1918.
- Boothby WM, Sandiford RB: Nomographic charts for the calculation of the metabolic rate by the gasometry method, *Boston Med Surg J* 185:337–354, 1921.
- Slutsky AS, Ranieri M: Ventilator-induced lung injury, N Engl J Med 369:2126—2136, 2013.
- Serpa NA, Cardoso SO, Manetta JA, et al.: Association between use of lung-protective ventilation with lower tidal volumes and clinical outcomes among patients without acute respiratory distress syndrome: a meta-analysis, *JAMA* 308:1651–1659, 2012.
- Spieth PM, Carvalho AR, Pelosi P, et al.: Variable tidal volumes improve lung protective ventilation strategies in experimental lung injury, Am J Respir Crit Care Med 179:684

  –693, 2009.
- Malhostra A: Low tidal volume ventilation in the acute respiratory distress syndrome, N Engl J Med 357:1113—1120, 2007.
- Brower RG, Matthay MA, Morris A, et al.: Acute respiratory distress syndrome network: ventilation with lower tidal volume as compared with traditional tidal volumes for acute lung injury and the acute respiratory distress syndrome, N Engl J Med 342:1301—1308, 2000.
- Radford EP, Ferris BG, Kriete BC: Clinical use of a nomogram to estimate proper ventilation during artificial respirations, N Engl J Med 251:877–884, 1954.
- Egan DF: Fundamentals of inhalation therapy, St. Louis, MO, 1969, Mosby.
- 10. Young J, Crocker R: Principles and practices of inhalation therapy, Chicago, IL, 1970, Year Book Medical.
- Bendixen HH, Bullwinkel B, Hedley-Whyte J, et al.: Atelectasis and shunting during spontaneous ventilation in anesthetized patients, Anesthesiology 25:297—301, 1964.
- Hess DR, Branson RD: Mechanical ventilation. In Hess DR, MacIntyre NR, Mishoe SC, et al., editors: Respiratory care principles and practice, Philadelphia, PA, 2011, WB Saunders, pp 462-500.
- Amato MBP, Meade MO, Slutsky AS, Brochard L, et al.: Driving pressure and survival in acute respiratory distress syndrome, N Engl J Med 372(8):747-755, 2015.
- Pelosi P, Brusasco C, Gama de Abreu M: Mechanical ventilation during general anesthesia. In Tobin MJ, editor: *Principles and practice of mechanical ventilation*, ed 2, New York, NY, 2013, McGraw-Hill, pp 597–627.
- Thorevska NY, Manthous CA: Determinants of dynamic hyperinflation in a bench model, Respir Care 49:1326—1334, 2004.
- 16. Quan SF: A ghost from the past: low tidal volume mechanical ventilation revisited [editorial], *Chest* 97:261–262, 1990.
- Chiumello D, Carlesso E, Cadringher, et al.: Lung stress and strain during mechanical ventilation for acute respiratory distress syndrome, Am J Respir Crit Care Med 178:346—355, 2008.
- Holets SR, Hubmayr RD: Setting the ventilator. In Tobin MJ, editor: Principles and practice of mechanical ventilation, ed 3, New York, NY, 2013, McGraw-Hill, pp 101–135.
- Jubran A: Inspiratory flow rate: more may not be better, Crit Care Med 27:670-671, 1999.
- Laghi F, Karamchandani K, Tobin MJ: Influence of ventilator settings in determining respiratory frequency during mechanical ventilation, Am J Respir Crit Care Med 160:1766–1770, 1999.
- Banner MJ, Boysen PG, Lampotang S, et al.: End-tidal CO<sub>2</sub> affected by inspiratory time and flow waveform: time for a change [abstract], Crit Care Med 14:374, 1986.
- 22. Tobin MJ: Mechanical ventilation, N Engl J Med 330:1056-1061, 1994.
- Tobin MJ: Advances in mechanical ventilation, N Engl J Med 344:1986–1996, 2001.
- 24. Dammann JF, McAslan TC, Maffeo CJ: Optimal flow for mechanical ventilation of the lungs. Part 2: the effect of a sine versus square wave flow pattern with and without an end-inspiratory pause on patients, *Crit Care Med* 6:293–310, 1978.
- Rau JJ, Shelledy DC: The effect of varying inspiratory flow waveforms on peak and mean airway pressures with a time-cycled volume ventilator: a bench study, Respir Care 36:347—356, 1991.

- Al-Saady N, Bennett ED: Decelerating inspiratory flow waveform improves lung mechanics and gas exchange in patients on intermittent positive-pressure ventilation, *Intensive Care Med* 11:68–75, 1985.
- Rau JL: Inspiratory flow patterns: the shape of ventilation, Respir Care 38:132–140, 1993.
- Kallet R: The effects of flow patterns on pulmonary gas exchange, lung-thorax mechanics and circulation, Respir Care 41:611

  –624, 1996.
- 29. Owen-Thomas JB, Ulan OA, Swyer PR: The effect of varying inspiratory gas flow rate on arterial oxygenation during IPPV in the respiratory distress syndrome, *Br J Anaesth* 40:493–502, 1968.
- Dammann JF, McAslan TC: Optimal flow pattern for mechanical ventilation of the lungs: evaluation with a model lung, Crit Care Med 5:128–136, 1977.
- Marini J, Crooke P, Truwit J: Determinants and limits of pressurepreset ventilation: a mathematical model of pressure control, *J Appl Physiol* 67:1081–1092, 1989.
- Uttman L, Jonson G: A prolonged postinspiratory pause enhances CO<sub>2</sub> elimination by reducing airway dead space, Clin Physiol Funct Imaging 23:252–256, 2003.
- Kacmarek RM: Initiating and adjusting invasive ventilatory support. In Kacmarek RM, Stoller JK, Heuer AJ, editors: Egan's fundamentals of respiratory care, ed 12, St. Louis, MO, 2021, Elsevier, pp 1072–1104.
- 34. Campbell RS, Davis BR: Pressure controlled versus volume-controlled ventilation: does it matter? *Respir Care* 47:416—424, 2002.
- Shapiro BA, Cane RD, Harrison RA, et al.: Changes in intrapulmonary shunting with administration of 100% oxygen, Chest 77:138-141, 1980.
- Marini JJ: Weaning techniques and protocols, Respir Care 40:233–238, 1995.
- MacIntyre NR: Pressure-limited versus volume-cycled breath delivery strategies [editorial], Crit Care Med 22:4–5, 1994.
- 38. Hill NS, Brennan J, Garpestad E, et al.: Noninvasive ventilation in acute respiratory failure, *Crit Care Med* 35:2402–2407, 2007.
- Kacmarek RM, McMahon K, Staneck K: Pressure support level required to overcome work of breathing imposed by endotracheal tubes at various peak inspiratory flowrates [abstract], Respir Care 33:933, 1988.
- Heulitt MJ, Holt SJ, Thurman TL, et al.: Effects of continuous positive airway pressure/positive end-expiratory pressure and pressure-support ventilation on work of breathing, using an animal model, *Respir Care* 48:689–696, 2003.
- Nilsestuen JO, Hargett KD: Using ventilator graphics to identify patient-ventilator asynchrony, Respir Care 50(2):202–234, 2005.
- Parthasarathy S, Jubran A, Tobin MJ: Cycling of inspiratory and expiratory muscle groups with the ventilator in airflow limitation, Am J Respir Crit Care Med 158:1471—1478, 1998.
- 43. Böhm S, Lachmann B: Pressure-control ventilation: putting a mode into perspective, *Int J Intensive Care* 3:12–27, 1996.
- Abraham E, Yoshihara G: Cardiorespiratory effects of pressure controlled inverse ratio ventilation in severe respiratory failure, *Chest* 96:1356—1359, 1989.
- Lain DC, DiBenedetto R, Morris SL, et al.: Pressure control inverse ratio ventilation as a method to reduce peak inspiratory pressure and provide adequate ventilation and oxygenation, *Chest* 95:1081–1088, 1080
- Guervitch MJ, Van Dyke J, Young ES, et al.: Improved oxygenation and lower peak airway pressure in severe adult respiratory distress syndrome: treatment with inverse ratio ventilation, *Chest* 89:211–213, 1986.
- 47. Tharratt RS, Allen RP, Albertson TE: Pressure controlled inverse ratio ventilation in severe adult respiratory failure, *Chest* 94:755-762, 1989.
- 48. Rappaport SH, Shpiner R, Yoshihara G, et al.: Randomized, prospective trial of pressure-limited versus volume-controlled ventilation in severe respiratory failure, *Crit Care Med* 22:22–32, 1994.
- Branson RD, MacIntyre NR: Dual-control modes of mechanical ventilation, Respir Care 41:294

  –305, 1996.

# Final Considerations in Ventilator Setup

#### **OUTLINE**

SELECTION OF ADDITIONAL PARAMETERS AND FINAL VENTILATOR SETUP, 103

Selection of Fractional Concentration of Inspired Oxygen, 103 SENSITIVITY SETTING, 104

Humidification, 106

Heated Humidifiers, 106 Heat-Moisture Exchangers, 107

ALARMS, 107

Action During Ventilator Alarm Situations, 109
PERIODIC HYPERINFLATION OR SIGHING, 109

FINAL CONSIDERATIONS IN VENTILATOR EQUIPMENT SETUP, 110

Preparing the Patient, 110
Establishing an Interface, 110
Manual Ventilation, 110
Cardiovascular Stabilization, 110
Ventilator Needs, 110
Treating the Cause of Respiratory

Treating the Cause of Respiratory Failure, 110 SELECTING THE APPROPRIATE VENTILATOR, 110

**EVALUATION OF VENTILATOR PERFORMANCE, 111** 

Initial Ventilator Settings for Specific Patient Situations, 111
CHRONIC OBSTRUCTIVE PULMONARY DISEASE, 111
Guidelines for Patients With Chronic Obstructive Pulmonary Disease, 111

ASTHMA, 113

Guidelines for Patients With Asthma, 114
NEUROMUSCULAR DISORDERS, 114

Guidelines for Patients With Neuromuscular Disorders, 115 CLOSED HEAD INJURY, 115

Guidelines for Patients With a Closed Head Injury, 116
ACUTE RESPIRATORY DISTRESS SYNDROME, 117

Guidelines for Patients With ARDS, 117

ACUTE CARDIOGENIC PULMONARY EDEMA AND CONGESTIVE HEART FAILURE, 119

Guidelines for Patients With Congestive Heart Failure, 119 SUMMARY, 120

#### **KEY TERMS**

- Acute severe asthma
- Barotrauma
- Cushing response

- Humidity deficit
- Isothermic saturation boundary
- Pulsus paradoxus

Relative humidity

#### **LEARNING OBJECTIVES**

On completion of this chapter, the reader will be able to do the following:

- Recommend fractional inspired oxygen concentration (F<sub>i</sub>O<sub>2</sub>) settings when initiating mechanical ventilation.
- Discuss the pros and cons of using the sigh function during mechanical ventilation.
   Compare the use of sigh with the concept of a recruitment
- Compare the use of sigh with the concept of a recruitment maneuver in acute respiratory distress syndrome.
- 4. List the actions necessary for final ventilator setup.
- Explain the concept of using extrinsic positive end-expiratory pressure in patients with airflow obstruction and air trapping who have trouble triggering a breath during mechanical ventilation.
- 6. Calculate the desired  $F_1O_2$  setting given the current partial pressure of arterial oxygen ( $P_aO_2$ ) and  $F_1O_2$  values.
- List the essential capabilities of an adult intensive care unit ventilator.
- 8. Provide initial ventilator settings from the guidelines for patient management for any of the following patient conditions: chronic obstructive pulmonary disease, acute asthma exacerbation, neuromuscular disorders, closed head injuries, acute respiratory distress syndrome, and acute cardiogenic pulmonary edema.

everal issues must be considered after decisions about the type of ventilator to be used, mode selection, and settings for pressure and volume have been made. These issues include selecting appropriate ventilator settings for the *fractional concentration of inspired oxygen* (F<sub>1</sub>O<sub>2</sub>), sensitivity, sigh breaths, alarms, and monitors, in addition to concerns regarding humidification of inspired gases. Only after these issues have been addressed can mechanical ventilation be initiated.

This chapter provides a summary of these issues and also addresses the initial settings for patients with specific pathological conditions, such as chronic obstructive pulmonary disease

(COPD), asthma, neuromuscular diseases, and acute respiratory distress syndrome (ARDS).

# SELECTION OF ADDITIONAL PARAMETERS AND FINAL VENTILATOR SETUP

# Selection of Fractional Concentration of Inspired Oxygen

The goal of selecting a specific  $F_1O_2$  for a patient is to achieve a clinically acceptable arterial  $O_2$  tension (e.g., 60–100 mm Hg). To accomplish this goal, a baseline arterial blood gas (ABG) should be

performed. If the patient's partial pressure of arterial  $O_2$  ( $P_aO_2$ ) is within the desired range before beginning ventilatory support, the  $F_IO_2$  that the patient is receiving at the time of the baseline ABG can be used when mechanical ventilation is initiated. If the  $P_aO_2$  is not within the desired range, the following equation can be used to estimate  $F_IO_2$ :

Desired 
$$F_1O_2 = \frac{[P_aO_2(desired) \times F_1O_2(known)]}{P_aO_2(known)}$$

This relationship is based on the assumption that the patient's cardiopulmonary function will not radically change from the time of the baseline ABG to the time when mechanical ventilation is initiated. <sup>1,2</sup> Some changes will obviously occur because the application of positive pressure ventilation can affect a patient's cardiopulmonary status.

If a baseline ABG is not available, it is advisable to select a high initial  $F_1O_2$  setting ( $\geq 0.50$ ) for patients with presumed severe hypoxemia. This can provide a way of restoring normal oxygenation and replacing tissue  $O_2$  storage when  $O_2$  debt and lactic acid accumulation have occurred. Clinicians often start with an  $F_1O_2$  of 1.0 and then reduce it as quickly as possible. Extended use of 100%  $O_2$  is not recommended because it can quickly result in absorption atelectasis and, in the long term, can lead to  $O_2$  toxicity. It is important to state, however, that 100%  $O_2$  should not be withheld if the patient is seriously ill and requires a high  $F_1O_2$ . Indeed, any procedure that places the patient at risk for developing hypoxemia should be performed with the patient breathing 100%  $O_2$ . For example, administering 100%  $O_2$  before and after suctioning and also during bronchoscopy is a common practice.

Titrating the  $F_IO_2$  using pulse oximetry and ABG findings can minimize the risk for administering too much  $O_2$ .  $^{3-5}$  The  $F_IO_2$  can be adjusted after ventilation is started, based initially on the pulse oximetry saturation  $(S_pO_2)$ .  $^6$  An  $S_pO_2$  greater than 92%  $(P_aO_2\geq\!60$  mm Hg) is a common and acceptable goal. Within 10 to 20 minutes of beginning ventilation, an ABG sample should be collected to assess the adequacy of ventilation and oxygenation. Appropriate ventilator changes based on ABG results are reviewed in Chapters 12 and 13.

The equation for obtaining a desired  $F_1O_2$  previously shown in this section can also be used to adjust the  $F_1O_2$ . In cases in which an  $F_1O_2$  greater than 0.50 is required to maintain oxygenation, positive end-expiratory pressure (PEEP) may be indicated (see Chapter 13). It is important to emphasize that an  $F_1O_2$  of 0.50 or greater increases the risk for  $O_2$  toxicity and intrapulmonary shunting that occurs with  $O_2$  induced atelectasis.

#### **SENSITIVITY SETTING**

Ventilator sensitivity is normally set at a level that the patient can easily flow-trigger or pressure-trigger a breath (see Chapter 3). Flow triggering is set in a range of 1 to 10 L/min below the base flow, depending on the selected ventilator. Pressure sensitivity is commonly set between -1 and -2 cm  $H_2O$ .

Many clinicians prefer using flow triggering because it provides a slightly faster response time compared with pressure triggering, for two main reasons. First, the exhalation valve does not have to close during flow triggering. With pressure triggering, the exhalation valve must close and the patient's inspiratory effort has to be sufficient to reduce the circuit pressure to the trigger setting. Second, during pressure triggering, the circuit pressure must drop **Key Point** 7.1 Flow triggering has a slightly faster response time compared with pressure triggering.

### BOX **7.1**

#### **Definitions of Positive End-Expiratory Pressure (PEEP)**

PEEP: Positive end-expiratory pressure; airway pressure greater than zero at the end of exhalation

Extrinsic PEEP (PEEP $_{\rm E}$ ): The level of PEEP set by the operator on the ventilator

Auto-PEEP (intrinsic PEEP, or PEEP<sub>v</sub>): The amount of pressure in the lungs at the end of exhalation when expiration is incomplete (i.e., expiratory flow is still occurring) and no PEEP<sub>E</sub> is present (PEEP<sub>E</sub> is excluded from this value)

Intrinsic PEEP can occur in three situations: (1) Strong active expiration, often with normal or even with low lung volumes (e.g., Valsalva maneuver); (2) high minute ventilation (>20 L/min), where expiratory time (T<sub>E</sub>) is too short to allow exhalation to functional residual capacity; or (3) expiratory flow limitation as a result of increased airway resistance, as may occur in patients with chronic obstructive pulmonary disease on mechanical ventilation or with small endotracheal tubes or obstructed (clogged) expiratory filters.

 $Total PEEP = PEEP_F + auto-PEEP$ 

before the inspiratory valve opens and flow goes to the patient.<sup>7</sup> In contrast, with flow triggering, the pressure does not need to drop because the inspiratory valve remains open and the patient receives almost immediate support (Key Point 7.1).

If auto-PEEP (intrinsic PEEP [PEEP<sub>I</sub>]) is present, patients often have difficulty triggering a breath. Indeed, in cases in which auto-PEEP is high, patients may be unable to trigger a breath. A relatively simple method of assessing if auto-PEEP if present is to palpate the accessory muscles of inspiration (e.g., sternocleido-mastoid muscles). Therefore it can be particularly difficult when a high level of auto-PEEP is present to adjust the ventilator sensitivity so that it senses patient effort. Furthermore, the cause of the problem often goes unsolved unless auto-PEEP is detected and measured (Box 7.1).

When auto-PEEP occurs in mechanically ventilated, spontaneously breathing patients with airflow obstruction (e.g., in COPD), setting the extrinsic PEEP (PEEP<sub>E</sub>) level to equal about 80% of the patient's auto-PEEP level may improve the ventilator's response (i.e., sensitivity) to the patient's inspiratory efforts. Fig. 7.1A and B helps illustrate this problem. Imagine that you are trying to sip water through a straw from a glass in which the water level is 10 cm below your mouth. You would have to generate at least -10 cm H<sub>2</sub>O to draw the water into your mouth. A similar situation occurs in patients on ventilation with air trapping who are trying to trigger a breath. The patient must create a pressure gradient between the alveolus and mouth by decreasing alveolar pressure (Palv) to zero or lower so that mouth pressure (PM) is greater than Paly. This gradient allows air to flow into the lungs. For example, if +10 cm H<sub>2</sub>O of auto-PEEP was present, the patient would have to generate an effort equal to −10 cm H<sub>2</sub>O to achieve a Palv of zero. Then the patient must generate an additional -1 to -2 cm  $H_2O$  to trigger inspiratory flow.




Fig. 7.1 Representation of a patient with air trapping (auto-PEEP) and airway collapse trying to trigger a ventilator breath. (A) 10 cm  $H_2O$  of auto-PEEP at end exhalation. (B) The patient's alveolar pressure ( $P_{alv}$ ) must drop to -1 cm  $H_2O$  to trigger a ventilator breath. The effort required is the sum of the auto-PEEP level plus the trigger sensitivity setting of the ventilator, +10 cm  $H_2O$  (auto-PEEP) plus 1 cm  $H_2O$  (sensitivity), equals 11 cm  $H_2O$  of effort. (C) Extrinsic PEEP (PEEP<sub>E</sub>) set to +10 cm  $H_2O$  helps open airways and, for this example, did not increase peak inspiratory pressure. (D) Triggering is accomplished with only -1 cm  $H_2O$  of effort.

Another approach to solving the straw-sipping problem is to fill the glass with more water, which in turn would bring the water level closer to the mouth. Similarly, the problem that patients with auto-PEEP have with triggering a breath can be solved by increasing pressure at the mouth (PEEP) until it equals P<sub>alv</sub> (i.e., the pressure gradient between the mouth and the alveolus is reduced). This reduction is accomplished by applying PEEP with the ventilator (see Fig. 7.1C). PEEP can be added until most of the airways are no longer collapsed, and the patient only has to generate enough pressure to trigger the ventilator based on the sensitivity setting. Note that this technique will not be effective if

the auto-PEEP is the result of a high minute ventilation ( $\dot{V}_E$ ) and if there is insufficient expiratory time ( $T_E$ ).<sup>4</sup>

There are several relatively easy ways to estimate the amount of  $PEEP_E$  to add, if auto-PEEP cannot be measured. The clinician can increase  $PEEP_E$  until peak inspiratory pressure (PIP) begins to increase. This increase in PIP is an indication that more pressure and volume have been added to the lung. Another technique of estimating the amount of  $PEEP_E$  to add is to observe whether activity of the accessory muscles of breathing (e.g., sternocleidomastoids) decreases as  $PEEP_E$  is added (Case Study 7.1). Still another technique involves comparing the number of triggered

#### Case Study 7.1

#### **Auto-PEEP and Triggering**

A 60-year-old man with COPD is receiving pressure-supported ventilation (PSV). He appears to be having difficulty triggering ventilator breaths. Auto-PEEP is measured at +8 cm  $H_2O$ , and no PEEP<sub>E</sub> is being used. Sensitivity is set at -1 cm  $H_2O$ . How much of an effort (in cm  $H_2O$ ) must the patient generate to trigger a breath?

breaths with the number of patient efforts. As the level of set PEEP is increased, the number of triggered breaths should match the patient's efforts. Chapters 13 and 17 provide additional information about the complications associated with auto-PEEP, its causes, and methods to reduce auto-PEEP.

It is important to mention that the type of humidifier system being used can also influence the sensitivity. If the humidifier is located between the patient and the point at which the ventilator detects triggering, the patient has to work harder to trigger a breath. When the trigger device is located proximal to the patient's airway, this is less of a problem.<sup>3</sup>

#### **Humidification**

A spontaneously breathing individual's inspired air is typically conditioned down to the fourth or fifth generation of subsegmental bronchi (i.e., the **isothermic saturation boundary**) (Fig. 7.2). Under normal circumstances, conditioning of inspired air occurs as air passes through the nose and upper airway. Because these are bypassed during invasive ventilation, a humidity source must be added to the ventilator circuit.


The humidification system used during mechanical ventilation should provide at least 30 mg  $H_2O/L$  of absolute humidity at a temperature range of about 33° to 37° C for all available flows up to a  $\dot{V}_E$  of 20 to 30 L/min.  $^{9,10}$  Some clinicians prefer a delivered temperature range of 35° to 37° C.  $^5$ 

#### **Heated Humidifiers**

Humidity can be provided by a variety of heated humidification systems. Devices in this category include the following types of humidifiers: pass-over, vapor phase, wick, and active heat and moisture exchanger. Refilling heated humidifiers is best accomplished by using a closed-feed system. With a closed-feed system, the water level in the reservoir is maintained manually by adding water from a bag through a fill port or by a float-feed system that maintains a relatively constant water level. (Notice that another advantage of the closed-feed system is that the water temperature can be better regulated.) Both types avoid the need to open the ventilator circuit to refill the device and thus reduce the risk for potential contamination.

Heated humidifiers typically include a servo-controlled heater with a temperature probe that is placed close to the patient's airway. These devices are typically equipped with a temperature display and temperature alarm. The high-temperature alarm is set at 37° C. A minimum alarm setting of 30° C is appropriate. 8,9,13

Whenever the temperature in the patient circuit is less than the temperature of the gas leaving the humidifier, condensate accumulates in the circuit. Notice that condensate accumulation (rainout) increases as the room temperature becomes cooler.<sup>14,15</sup>



**Fig. 7.2** Position of the isothermic saturation boundary (ISB) during normal nose breathing and during inhalation of dry gases (during intubation). (Redrawn from Branson RD, Campbell RS, Johannigman JA, et al.: Comparison of conventional heated humidification with a new active hygroscopic heat and moisture exchanger in mechanically ventilated patients, *Respir Care* 44:912—917, 1999.)

### 8

#### **CRITICAL CARE CONCEPT 7.1**

#### **Changes in Relative Humidity**

Gas leaves a heated humidifier at a temperature of 34° C and 100% relative humidity. The absolute humidity is 37 mg/L. The gas enters a heated wire circuit that is heated to 37° C at the proximal airway. What is the absolute humidity of the gas that is 100% saturated at normal body temperature? What is the humidity deficit (i.e., the difference between what is provided by the humidifier and the amount of humidity required by the patient)? What happens to the relative humidity of the gas as it leaves the humidifier and enters the circuit?

(Using heated wire circuits on the inspiratory and expiratory lines of the circuit can significantly reduce the amount of rain-out.)

It is important to understand that if the temperature of the gas in the patient circuit is higher than in the humidifier, the **relative humidity** in the circuit decreases (Critical Care Concept 7.1).<sup>8</sup> (This can occur when using heated wire circuits.) Drying of secretions can occur if a deficit exists between the amount of

humidity provided and the amount needed by the patient. Assessing whether a **humidity deficit** is present can be easily determined by examining the patient's secretions. For example, thick secretions that are difficult to suction or the presence of bronchial casts and mucous plugs are signs of drying of the airways.

Without a heated wire circuit, the humidifier may need to be heated to as much as 50° C for the gas temperature to come near to body temperature (37° C) by the time it reaches the patient's upper airway. As the highly saturated and warm gas passes through the ventilator circuit, ambient air surrounding the circuit tubing cools this gas and condensate forms in the circuit. Placing water traps at gravity-dependent parts of the circuit to capture excessive rain-out can help alleviate this problem. Water traps should be emptied regularly in a manner that protects the practitioner from any aerosolized spray that may be produced when the trap is opened. Some water traps have spring-loaded caps that seal the circuit when they are unscrewed. Others have suction ports from which excess water can be suctioned. Water traps that remain sealed during emptying help avoid interruption in ventilation during the process (Key Point 7.2). Maintaining a seal prevents breaking the circuit and thus reduces the risk for introducing contaminants.

**Key Point 7.2** Condensate in the circuit tubing can potentially be a source of accidental lavage when the patient is turned. This water should be directed away from the patient and never allowed to enter the patient's airway.

#### **Heat-Moisture Exchangers**

Heat-moisture exchangers (HMEs), or artificial noses, can also be used for humidification in patients receiving mechanical ventilation. However, there are some circumstances in which HMEs should *not* be used (Box 7.2).  $^{9,13,16}$  HMEs can provide 10 to 14 mg/L of water at tidal volumes (V<sub>T</sub>s) of 500 to 1000 mL. More efficient hygroscopic heat and moisture exchangers (HHMEs) can provide

### BOX **7.2**

#### Contraindications for Heat-Moisture Exchangers

- The presence of thick, copious, or bloody secretions. These secretions can accumulate on the heat-moisture exchanger (HME) and increase both inspiratory and expiratory resistance.
- 2. The patient's exhaled tidal volume  $(V_T)$  is less than 70% of inhaled  $V_T$  (e.g., in bronchopleural fistulas or when endotracheal tube cuffs are absent).
- 3. Body temperatures below 32° C (hypothermia).
- 4. Spontaneous high minute ventilation  $(\dot{V}_E)$  is greater than 10 L/min.
- 5. An aerosolized medication must be given.
- 6. Very small  $V_T$  must be delivered (lung protective ventilation), in which case the HME may significantly increase mechanical dead space ( $V_{Dmech}$ ) and compromise  $CO_2$  clearance. Notice that large  $V_T$  delivery may compromise the ability of the HME to humidify inspired gases.

22 to 34 mg/L at similar volumes.<sup>8</sup> Because a net heat and water loss occurs when HMEs are used for extended periods, the patient should be assessed for signs of drying secretions.

Most HMEs have a resistance to flow between 2.5 and 3.5 cm  $\rm H_2O/L/min.^8$  During extended use, HMEs can accumulate moisture and secretions, resulting in an increased resistance to flow. This increased resistance can cause gas trapping (i.e., auto-PEEP) and increase expiratory work of breathing (WOB). If more than four HMEs are used during a 24-hour period because of secretion buildup, it is probably advisable to change to a heated humidifier that provides 100% relative humidity at 31° to 35° C. $^{17}$ 

It is also important to recognize that HMEs add mechanical dead space ( $V_{\rm Dmech}$ ) to the ventilator circuit. The dead space for most HMEs ranges from about 50 to 100 mL. This is an important consideration when HMEs are used on patients with low  $V_T$ , such as infants, children, and adult patients with  $V_T$  of 400 mL or less (Key Point 7.3).

**Key Point 7.3** Passive humidifiers (heat-moisture exchangers) placed at the endotracheal tube should not be used simultaneously with heated humidifiers. Water produced by the heated humidifier can occlude the filter and significantly reduce airflow to the patient.<sup>8</sup>

HMEs should be taken out of line during delivery of an aero-solized medication. It should be kept in mind, however, that circuit disconnection increases the risk for circuit contamination. An alternative approach is to use a metered-dose inhaler (MDI) with an MDI adapter placed between the HME and endotracheal tube (ET). If a spacer is used with the MDI on the inspiratory line, the HME must still be removed. Another solution is to use a circuit adapter that does not require the HME to be removed during aerosol treatments (Fig. 7.3).

Although some manufacturers recommend changing HMEs every 24 hours, replacement may be required only every 2 to 3 days if the HME is not partially obstructed with secretions. 3,8,18 Clinicians have reported using HMEs for up to 5 days without difficulties. However, if secretions appear thick after two consecutive suctioning procedures, the HME should be removed and the patient switched to a heated humidification system. For critically ill patients requiring more than 5 days of ventilation, it is probably better to use a heated humidification system that will optimize humidification and help prevent secretion retention. Long-term use (longer than 7 days) of HMEs for the critically ill patient can increase the rate of ET occlusion. On the other hand, patients in long-term care facilities with tracheostomy tubes in place can use artificial noses for more extended periods without difficulty, as long as secretions do not present a problem. 19

#### **ALARMS**

Audible and visible alarm systems are designed to alert the clinician of potential dangers related to the patient-ventilator interaction. This section reviews the most commonly used ventilator alarms and how they are set by most clinicians. Box 7.3 shows the various levels of alarms and gives some examples of what causes them to become activated.




Fig. 7.3 The CircuVent ventilator circuit adapter. Aerosol delivery can be accomplished with a heat-moisture exchanger (HME) in line without breaking (disconnecting) the circuit. The practitioner turns the dial to redirect flow during medication delivery. Hygroscopic condenser humidifier (HCH). (From DHD Healthcare, Wampsville, N.Y.)

### BOX **7.3**

## Levels of Alarm and Example Events During Mechanical Ventilation

#### **Level 1: Immediately Life-Threatening**

Example events:

- · Electrical power failure
- No gas delivery to patient
- Exhalation valve failure
- · Excessive gas delivery to patient
- · Timing failure

#### **Level 2: Potentially Life-Threatening**

Example events:

- Circuit leak
- Circuit partially obstructed
- Heater/humidifier malfunction
- · Inspiratory-to-expiratory (I/E) ratio inappropriate
- Inappropriate O<sub>2</sub> level (gas/blender failure)
- Autocycling
- Inappropriate PEEP/CPAP level (too low/too high)

## Level 3: Not Life-Threatening but a Potential Source of Patient Harm

Example events:

- Changes in lung characteristics (compliance/resistance)
- High respiratory rates
- Auto-PEEP
- Changes in ventilatory drive (e.g., central nervous system or muscle function)

Sources: Hess D: Noninvasive monitoring in respiratory care—present, past and future: an overview, *Respir Care* 35:482–499, 1990; and MacIntyre NR, Day S: Essentials for ventilator-alarm systems, *Respir Care* 37:1108–1112, 1992.

Low-pressure alarms are usually set about 5 to 10 cm  $H_2O$  below PIP. These alarms are useful for detecting patient disconnections and leaks in the system. High-pressure alarms are set

about 10 cm  $\rm H_2O$  above PIP. High-pressure alarms can be activated when the patient coughs and if secretions increase, compliance drops, or there are kinks in the ET or circuit tubing. Low PEEP/continuous positive airway pressure (CPAP) alarms are usually set about 2 to 5 cm  $\rm H_2O$  below the PEEP level. Activation of these latter alarms usually indicates the presence of a leak in the patient-ventilator circuit.

Apnea alarms are used to monitor mandatory or spontaneous breaths. An apnea period of 20 seconds is the highest accepted maximum. In some situations, apnea alarms are set so that the patient will not miss two consecutive machine breaths (apnea time > total cycle time [TCT] and < [TCT  $\times$  2]). Apnea settings provide full ventilatory support for the patient if apnea occurs and should be set appropriately (e.g.,  $V_T 6-8$  mL/kg ideal body weight [IBW], rate 10-20 breaths/min with a high percentage of  $O_2$  [80%-100%]).

Most ventilators also have an alarm or indicator that alerts the operator when the inspiratory time  $(T_{\rm I})$  is more than half the set TCT. Some ventilators, such as the Servo-i will automatically end inspiration if the  $T_{\rm E}$  is so short that the patient does not have time to exhale. The shortest possible  $T_{\rm E}$  is 20% of any cycle time unless the patient is receiving bilevel positive airway pressure (bilevel PAP) and can be activated or inactivated.

Low-source gas alarms alert the operator that the available high-pressure gas source is not functioning. This alarm is critical for microprocessor ventilators that rely on high-pressure gas to function, particularly for ventilators that do not have a built-in compressor (Key Point 7.4).

Most ventilators also include alarms for low  $V_T$ , low and high  $\dot{V}_E$ , low and high respiratory rates (f), and low and high  $O_2$   $F_1O_2$ . Alarms should not be set so sensitively that they are constantly being triggered. The following suggestions can be used as a guide:

Low exhaled V<sub>T</sub>: 10% to 15% below set V<sub>T</sub>

**Key Point 7.4** Low-source gas alarms cannot be silenced if gas is critical to ventilator operation.

### BOX 7.4 Alarm Failure?

An intensive care unit (ICU) patient receiving mechanical ventilatory support is on an air-filled mattress, and there is a fan in his room to help cool him. He has a pleural drainage system with suction in place.

A nurse at the ICU station hears the ECG monitor alarm, which shows a pattern of asystole. She goes to the patient's bedside, begins cardiopulmonary resuscitation, and a normal sinus rhythm is quickly restored.

The nurse notes that the patient had been disconnected from the ventilator and attributed the life-threatening event to this occurrence. The nurse also notes that when the ventilator alarm was sounding, it could barely be heard. When confronted with the nurse's concerns about alarm failure, the respiratory therapist notices that the alarm's volume adjustment is on the lowest setting and resets it to a higher volume.

This scenario occurs all too frequently in the clinical setting and represents a critical medical error that can be avoided. What would you suggest to prevent a recurrence of this situation?

- Low exhaled minute volume: 10% to 15% below-average minute volume
- F<sub>I</sub>O<sub>2</sub>: 5% above and below set O<sub>2</sub> percentage

Other alarms are available for detecting low battery levels, if the ventilator is inoperative, ventilator circuit malfunction, exhalation valve leaks, and inappropriately set parameters. For example, a set parameter (e.g.,  $V_T$ ) may be outside the range of the ventilator.

Unfortunately, because there are so many alarms and warning indicators on intensive care unit (ICU) equipment, many clinicians can become desensitized to audible alarms, causing the clinicians to respond slowly or not at all to these alerts.<sup>21</sup>

#### **Action During Ventilator Alarm Situations**

When a ventilator malfunction occurs during use, the clinician must first ensure that the patient is receiving ventilation. When in doubt, the practitioner should disconnect the patient from the ventilator and begin manual ventilation using a manual resuscitation bag, silence the alarms, and call for help. If the practitioner cannot immediately correct the problem, it may be necessary to replace the ventilator (Box 7.4). The operating manuals provided with ventilators usually have troubleshooting sections to solve most problems and can be consulted when time permits. If a ventilator problem cannot be resolved by the in-house biomedical technician support team, it will be necessary to call the local maintenance representative for the company.

#### PERIODIC HYPERINFLATION OR SIGHING

A *sigh* is a deep breath that occurs regularly as part of a normal breathing pattern. It is used occasionally during mechanical ventilation and related maneuvers (e.g., deep breaths or sighs are used before and after suctioning a patient) (Box 7.5).<sup>22-30</sup>

The sigh or deep breath was a popular idea that was introduced during the 1960s. Ventilators developed in the 1970s and 1980s incorporated sigh breaths into their designs, although traditional sigh breaths had not been shown to be clinically beneficial. These ventilators were capable of providing one or more deep breaths at periodic

#### BOX **7.5**

#### **History of Sighs and Mechanical Ventilation**

Bendixen and colleagues demonstrated that anesthetized and intubated surgical patients developed increased intrapulmonary shunting, decreased PaO2 values, and reduced compliance after mechanical ventilation. They attributed these findings to microatelectasis from constant low tidal volumes.<sup>22</sup> When patients were given periodic deep breaths (sighs), these changes were reversed. Unfortunately, the effectiveness of periodic hyperinflation (sighing) continues to be debated because subsequent studies did not entirely support Bendixen's findings.  $^{23-29}$  The decrease in lung compliance (C<sub>1</sub>) and in PaO2 values seen in surgical patients may actually be a result of a loss of functional residual capacity in the supine position and the effects of anesthetics, muscle relaxants, and similar medications on diaphragm and intercostal muscle function. It has been suggested that this decrease in C<sub>1</sub> and P<sub>a</sub>O<sub>2</sub> can often be improved by the addition of low levels of PEEP.<sup>29,3</sup>

timed intervals (i.e., three or four times per hour or once every 10 minutes), depending on the ventilator. Because a normal sigh in a spontaneously breathing, nonintubated person occurs about every 6 minutes, ventilator manufacturers designed their machines to deliver sighs at a similar frequency. Sigh volumes were set at 1.5 to 2 times the regular low  $V_T$  setting. (Interestingly, low  $V_T$  settings [e.g., 5–7 mL/kg IBW] were popular at the time.)

Other investigators found that large  $V_T$  (10–15 mL/kg) in anesthetized patients reduced atelectasis. As already discussed, using these higher volumes for patients with acute respiratory failure can cause alveolar overdistention and increase the risk for ventilator-induced lung injury. Mechanical ventilator sigh breaths are therefore *not* recommended in the presence of  $P_{plat}$  pressures greater than 30 cm  $H_2O$ .

Mild hypoxemia sometimes occurs in patients receiving pressure support ventilation (PSV) with low volumes (4–6 mL/kg). Studies of the use of sigh breaths in these patients may be worth examining.<sup>29</sup> However, sigh breaths are not indicated for these patients and may be harmful to spontaneously breathing patients receiving CPAP for the treatment of hypoxemia.<sup>33</sup>

With the advent of low  $V_T$  strategy in patients with ARDS, another ventilator strategy called *lung recruitment* has been successfully used in selected patients. <sup>34,35</sup> The recruitment maneuver is not unlike sigh breaths. The recruitment maneuver, which is used to expand collapsed areas of the lung, involves using a sustained high pressure of 35 to 45 cm  $H_2O$  for 40 to 60 seconds. <sup>35-37</sup> Interestingly, the sigh breaths used by Bendixen and colleagues in 1963, <sup>22</sup> more than 50 years ago, were as follows:

- One breath at 20 cm H<sub>2</sub>O for 10 seconds
- A second breath at 30 cm H<sub>2</sub>O for 15 seconds
- A third breath at 40 cm H<sub>2</sub>O for 15 seconds

These sustained high-pressure maneuvers are not unlike the recruitment maneuvers that are used in the management of patients with ARDS (Key Point 7.5).

**Key Point 7.5** When low tidal volumes are used, such as in patients with acute respiratory distress syndrome, a recruitment maneuver may be an effective method to avoid atelectasis.

Sighs or deep breaths may be appropriate in the following situations:

- Before and after suctioning
- Before and after bronchoscopy
- During an extubation procedure
- During chest physiotherapy
- During low V<sub>T</sub> ventilation
- As a recruitment maneuver in some patients with ARDS

### **FINAL CONSIDERATIONS IN VENTILATOR EQUIPMENT SETUP**

Before initiating mechanical ventilation, the respiratory therapist should perform a final check of the equipment to be used. This check should include the following steps:

- Check ventilator and circuit function to ensure the ventilator is functioning properly and no significant leaks are present.
- Ensure the humidifier is filled with sterile water and set the humidifier temperature so that the final gas temperature at the airway will be approximately 31° to 35° C or place an HME in line.
- Place a temperature-monitoring device near the patient connector when heated humidification is used.
- Check the F<sub>I</sub>O<sub>2</sub>, set V<sub>T</sub> (or inspiratory pressure) and f.
- Adjust the alarms.
- Ensure the patient is connected to an electrocardiographic
- Have an emergency airway tray available at the bedside in case the patient's airway is removed or damaged.
- Check that suctioning equipment is available and functioning.
- Select a volume-monitoring device and an O<sub>2</sub> analyzer if one is not available with the ventilator.
- Ensure that a manual resuscitation bag is available and easily accessible.

Once the decision has been made to connect the patient to a ventilator, several steps should be taken, including the following:

- Preparing the patient
- Establishing an airway interface
- Providing manual ventilation to the patient
- Ensuring the patient's cardiovascular status is stable
- Meeting ventilation needs
- Treating the cause of respiratory failure

#### **Preparing the Patient**

Mental preparation of a patient who will require mechanical ventilation is an obvious part of preoperative planning for patients who will likely need short-term postoperative ventilatory support. It is an important part of patient preparation because it can significantly reduce the patient's anxiety and discomfort.

Before initiating mechanical ventilation, conscious patients must be prepared for what to expect once they are connected to the ventilator. The clinician should give a brief explanation about how the ventilator works and why it is being used. The patient also must be informed that the use of an artificial airway will inhibit verbal communication.

Unconscious patients should be informed about their situation as soon as they regain consciousness. This is crucial because these patients will be unable to speak and may be completely unaware of what has occurred. Often the explanation will need to be repeated because sedatives and similar agents can alter a patient's mental

#### **Establishing an Interface**

For noninvasive ventilation, a face or nasal mask is properly fitted (see Chapter 19). During invasive ventilation, the three most commonly used artificial airways are orotracheal, nasotracheal, and tracheostomy tubes. Orotracheal tubes are used for emergencies and are generally kept in place for several days. Nasotracheal tubes provide better patient comfort but may require more insertion time. Nasotracheal tubes usually have smaller diameters than orotracheal tubes and are associated with increased incidence of sinus infections. Tracheostomy tubes must be inserted surgically, but these tubes can be used for extended periods. They also allow for easier pulmonary hygiene and are apparently most comfortable for the patient, even allowing the patient to talk in some cases.

#### **Manual Ventilation**

Before initiating mechanical ventilation, the patient's ventilatory requirements can be supported by using a manual resuscitation bag. These devices are easy to operate and allow the clinician to monitor closely the patient's breathing efforts and changes in airway resistance (R<sub>aw</sub>) or lung compliance (C<sub>L</sub>).

#### Cardiovascular Stabilization

The combined stress of acute or impending respiratory failure and endotracheal intubation can reveal undiagnosed cardiovascular complications that may already be present. For example, patients with existing or borderline myocardial ischemia may develop cardiac dysrhythmias. The effects of any of the pharmacological agents used during intubation (e.g., topical anesthetics, sedatives, narcotics, and muscle-paralyzing agents) can lead to hypotension and relative hypovolemia, resulting in reduced venous return and cardiac output. Appropriate cardiovascular support is therefore essential to a successful outcome.

#### **Ventilator Needs**

After the patient's cardiovascular status is stabilized and primary ventilatory needs are being met, the clinician can then select the appropriate mechanical ventilator mode and appropriate ventilator settings (see Chapter 6).

#### **Treating the Cause of Respiratory Failure**

Once a life-threatening situation no longer exists, attention can be turned to treating the initial problems that caused the patient to require ventilation. Mechanical ventilation is not curative; the underlying problem must be resolved regardless of whether it is the result of central nervous system or neuromuscular problems or increased WOB caused by trauma, ARDS, or COPD with complications. It makes little sense to be overly aggressive with palliative methods if the underlying pathologic process is irreversible.

#### SELECTING THE APPROPRIATE VENTILATOR

Specific ventilator selection depends on not only theoretical but also practical considerations. The ventilators available at an institution and the familiarity of personnel with this equipment usually determine ventilator choice. Detailed descriptions of many available ventilators and their features are available from other sources.38

The selected ventilator should offer a variety of modes of ventilation, including volume-controlled or pressure-controlled

continuous mandatory ventilation (VC-CMV or PC-CMV), volume-controlled or pressure-controlled intermittent mandatory ventilation (VC-IMV or PC-IMV), and spontaneous CPAP/PSV.

Adult ventilators are typically capable of delivering  $V_T$  in the range of 100 to 2000 mL and respiratory rate from 1 to 60 breaths/min. Pressures from 0 to 100 cm  $H_2O$  are adequate, and the driving pressure must be high enough to maintain the gas flow pattern throughout inspiration regardless of how high peak pressures may rise. PEEP/CPAP should be in the range of 0 to 30 cm  $H_2O$ . Flow rates should range from 10 to 180 L/min. Constant (square/rectangular) flow or descending flow patterns probably have more clinical benefit than others and should be included. An inspiratory-to-expiratory (I/E) ratio display may be useful in the management of patients who are difficult to oxygenate.

Response time, patient circuits, exhalation valves, PEEP, and demand valves should be designed to reduce WOB and patient resistance to inspiration and expiration. Two important ventilatory adjuncts are inflation hold and expiratory pause. Inflation hold is used to measure  $P_{\text{plat}}$ , which is used to calculate static compliance. Expiratory pause is used for auto-PEEP measurements.

The mechanical ventilator should be able to deliver  $F_1O_2$  values from 21% to 100% in increments of 1% to 2%. Alarms should include apnea, pressure limit, power failure, gas source, and lowand high-pressure alarms. If available, high f, low  $V_T$ , and high and low  $\dot{V}_E$  alarms are particularly important for monitoring pressure-targeted ventilation and spontaneous modes such as PC-CMV, PC-IMV, CPAP, and PSV.

It is important to recognize that these are the fundamental features of adult ventilators, not a description of an ideal ventilator. In fact, most microprocessor ventilators may be equipped with additional modes and features.

#### **EVALUATION OF VENTILATOR PERFORMANCE**

The cost of purchasing a particular ventilator and the specific needs of the patients served by the institution should be considered before purchasing a new ventilator—specifically, whether these patients will require short- or long-term ventilation. The needs of the medical staff should also warrant consideration. For example, the amount of in-service training that will be required to ensure that the respiratory therapy staff is proficient in the use of the equipment should be part of the selection process.

A performance evaluation, or bench test, must be conducted on every ventilator brand before purchase and certainly before patient connection. Forms for conducting these tests are available from the Joint Commission and American National Standards Institute. A bench test requires the use of a lung analog, which can simulate alterations in respiratory system function. Instruments for measuring volume, pressure, flow, and time are also needed. Bench tests examine ventilator performance during changes in compliance and resistance and leak conditions and check general features, parameter ranges, and alarm systems. These tests must also account for various simulated conditions, such as very low and very high  $\dot{V}_{\rm E}$  values, air trapping (auto-PEEP), function during added nebulization, and CPAP function.

Once purchased, ventilators must be checked regularly with maintenance, testing, and calibration programs. Records must be maintained for each ventilator, as well as documentation of personnel training for ventilator use.

# Initial Ventilator Settings for Specific Patient Situations

The following cases offer the reader some guidance for making initial ventilator settings. The study questions at the end of the chapter provide additional practice in this area.

A number of published reviews along with several other text-books provide information about currently accepted practices for managing various pulmonary disorders requiring mechanical ventilation. The settings recommended in the following cases reflect the standard of practice suggested by these sources.

#### **CHRONIC OBSTRUCTIVE PULMONARY DISEASE**

Patients with COPD have increased  $R_{\rm aw}$  and may also have increased  $C_L$ , which, when combined, cause significant expiratory obstruction, lengthen the time constant, and lead to air trapping. When patients with COPD require mechanical ventilation, it is often because their chronic disease has been coupled with another problem, such as a respiratory infection, leading to acute-on-chronic respiratory failure.

Mechanical ventilation in COPD is associated with increased morbidity because of air trapping, nosocomial infections, barotrauma and volutrauma, cardiac problems, aspiration, and difficulty weaning. The goals of mechanical ventilation are to maximize patient-ventilator synchrony, reduce WOB and patient anxiety, and avoid the complications associated with mechanical ventilation, such as ventilator-associated pneumonia and ventilator-induced lung injury.

# Guidelines for Patients With Chronic Obstructive Pulmonary Disease

Basic guidelines for mechanically ventilating patients with COPD have been established. 3-5,40-45 These guidelines include the following:

- If possible, use noninvasive ventilation to avoid problems associated with artificial airways. Bilevel positive airway pressure (bilevel PAP) is ideal for patients with chronic pulmonary disorders (see Chapter 19).
- If intubation is necessary, an orotracheal intubation is recommended.
- The clinician can select a ventilator mode that he or she thinks is most familiar. It has been noted, however, that VC-CMV or PC-CMV may unload the work of the respiratory muscles more than IMV.<sup>44</sup> Using patient-triggered CMV in an alert patient with COPD may increase the risk for hyperinflation and elevated lung pressures. This mode should be monitored carefully.<sup>44</sup>
- Adjust the peak inspiratory flow to meet the patient's demand in VC-CMV using the descending flow pattern: flow greater than 60 L/min.
- In patients with COPD and asthma, in whom airway obstruction and resistance are high, an initial  $V_T$  of 6 to 8 mL/kg with a rate of 8 to 16 breaths/min and  $T_I$  0.6 to 1.2 seconds is acceptable.
- PEEP of 5 cm H<sub>2</sub>O or lower, or about 50% of auto-PEEP, should be used initially.
- Monitor for and minimize dynamic hyperinflation (auto-PEEP) by setting the lowest possible V

  E that produces acceptable gas exchange, targeting the patient's baseline PaCO2 and pHa.

- Provide the longest expiratory time ( $T_E$ ) possible. This may include decreasing  $T_I$ , increasing  $T_E$ , reducing f or  $V_T$ , and accepting hypercapnia ( $P_aCO_2$  higher than the patient's normal). (NOTE: Patients with COPD usually receive ventilation in their normal  $P_aCO_2$  range [e.g.,  $P_aCO_2 = 50-60$  mm Hg; pH 7.3–7.4].)
- If the patient is initiating inspiration once ventilation has started and auto-PEEP is present, set PEEP near 80% of the auto-PEEP level but do not exceed it (3–5 cm H<sub>2</sub>O is often adequate). If PIP begins to rise because PEEP is increased, the safe PEEP level has probably been exceeded and will result in lung overinflation. Several other strategies that may be used to address the issue of auto-PEEP include decreasing the inspiratory time, increasing the peak flow, and administering a bronchodilator.
- P<sub>plat</sub> should be monitored and maintained below 30 cm H<sub>2</sub>O to avoid alveolar overdistention and, consequently, lung injury. Accurate measurement of P<sub>plat</sub> may require sedation and paralysis. The decision to medicate patients is generally based on physician preference and institutional policy.
- Maintain P<sub>a</sub>O<sub>2</sub> at 55 to 75 mm Hg or near the patient's normal P<sub>a</sub>O<sub>2</sub>, with F<sub>1</sub>O<sub>2</sub> less than 0.5, unless the patient's condition worsens and he or she requires more O<sub>2</sub>.

PC-CMV may be ideal for this group of patients for several reasons. PC-CMV provides flow on demand to meet the patient's needs. T<sub>I</sub> can be set along with a backup rate, but patient triggering is still permitted. PC-CMV has a distinct advantage over PSV for this patient population because inspiration during PSV can be too long or too short, depending on the patient's active breathing patterns. This can result in increased WOB and poor patient-ventilator synchrony. Auto-PEEP can be a lethal complication. Current ventilators that allow an adjustable expiratory flow cycle may allow for the use of PSV in COPD.

Volume-assured pressure support or volume support (Servo-i) can also provide pressure ventilation with a set targeted volume delivery. Although these modes are also well suited for patients with COPD, clinicians must be familiar with their use.

An important part of patient care is providing adequate hydration and pharmacological therapy (i.e., bronchodilators and corticosteroids) to reverse airflow limitation. Secretions must be mobilized and removed, and if infections are present, appropriate antibiotic therapy must be administered. The primary problem necessitating ventilation must be corrected to ensure weaning will be successful. Because many of these patients are malnourished, an evaluation of their nutritional needs must be part of any follow-up program.

#### 🚫 Clinical Scenario: Chronic Obstructive Pulmonary Disease

A 65-year-old man with a history of COPD is brought to the emergency department (ED) complaining of severe shortness of breath. The following information was obtained during an initial patient assessment. The  $\rm S_pO_2$  of 75% obtained while he was breathing room air is low. Because pulse oximetry may be inaccurate in this range, an ABG was obtained. A 28% airentrainment mask was placed on the patient.

# Initial Patient Assessment on Admission: History of COPD

The patient is a retired salesman and lives at home with his wife. He has a 40-pack-year history of cigarette smoking.

#### **Mental Status**

- · Alert and oriented but shows signs of fatigue
- Speaks in halting sentences and appears to be catching his breath between efforts to talk

#### **Physical Appearance**

- Tall and thin
- Barrel chest
- Pale skin
- Pitting edema of the ankles
- Prolonged expiration through pursed lips with labored breathing
- Sitting in a chair, leaning forward with his arms on the chair arms
- Active use of the sternocleidomastoid muscles

#### **Vital Signs**

- f = 35 to 40 breaths/min
- Heart rate = 135 beats/min
- Blood pressure = 185/110 mm Hg
- Temperature = 37° C

#### **Breath Sounds**

 Bilateral wheezes, crackles in the bases, hyperresonance to percussion bilaterally

#### Cough

Weak, producing a moderate amount of thick, yellow secretions

### $S_pO_2$

75% on room air

#### **Chest Radiograph**

Increased bilateral radiolucency, flattened diaphragm, widened rib spaces; scattered infiltrates in both bases.

The patient is given an aerosol treatment with albuterol by small-volume nebulizer followed by an aerosolized mucolytic. He does not tolerate the treatment well and is unable to take a deep breath or perform a breath-hold maneuver. His dyspnea persists. ABGs on an  $F_1O_2$  of 0.28 are  $pH_a = 7.24$ ;  $P_aCO_2 = 97$  mm Hg;  $P_aO_2 = 38$  mm Hg; and  $HCO_3 - 41$  mEq/L.

The ABGs indicate chronic CO<sub>2</sub> retention (elevated HCO<sub>3</sub>—) that has now progressed to an acute-on-chronic phase (elevated P<sub>a</sub>CO<sub>2</sub> and low pH<sub>a</sub>). His ABG results indicate severe hypoxemia. The infiltrates in the lower lung fields and the production of thick yellow sputum suggest the presence of a respiratory infection, but the absence of an elevated temperature is confusing. (NOTE: Elderly patients, particularly those with chronic health problems, do not always develop a fever. If patients take aspirin or nonsteroidal or steroidal antiinflammatory medications, an elevated temperature may be masked.) A sputum specimen is sent to the laboratory for culture and sensitivity testing.

On the basis of the assessment, a decision is made to begin mechanical ventilatory support. The patient is 5-ft, 10-in tall and weighs 148 lb. What are his body surface area (BSA) and IBW? What initial settings for  $\dot{V}_E$ , f,  $T_I$ , and flow would be appropriate? Would you use pressure or volume ventilation?

The following section answers these questions and provides the initial settings selected in this case.  $^{45}$ 

#### Initial Ventilator Settings: COPD Patient

- BSA =  $1.85 \text{ m}^2$
- IBW = 106 + 6 (10) = 166 lb (75.5 kg)
- Initial  $\dot{V}_F = 4 \times 1.85 = 7.4 \text{ L/min}$
- Because of concern for air trapping, consider a lower set V<sub>E</sub>.
- Attempt to synchronize the ventilator with the patient.
- Noninvasive ventilation is appropriate.

A Philips Respironics BiPAP ventilator is selected. With this ventilator, a low level of CPAP/PEEP (2 cm  $H_2O$ ) is maintained in the airway even when the expiratory positive airway pressure (EPAP) control is minimal.

- Rate is set at 8 breaths/min, TCT = 60/8 = 7.5 seconds, and  $T_I = 13\%$  of TCT
- I/E ratio = 1:6.5,  $T_I = 1.0$  seconds, and  $T_E = 6.5$  seconds
- Inspiratory positive airway pressure (IPAP) = 10 cm H<sub>2</sub>O initially and is titrated to obtain an exhaled V<sub>T</sub> of 600 mL (0.6 L).
- Final IPAP is 14 cm H<sub>2</sub>O.
- EPAP = set at 4 cm H<sub>2</sub>O
- Spontaneous/timed setting is selected, providing a backup rate, at which point time-triggered breaths are modified pressure control (PC) breaths; spontaneous breaths are pressure support (PS) breaths.
- O<sub>2</sub> is titrated to ≥90% O<sub>2</sub> saturation measured by pulse oximetry (S<sub>p</sub>O<sub>2</sub>).

The patient is transferred to the ICU, and the settings are maintained for 2 hours. It becomes increasingly difficult for the patient to clear secretions, and he continues to try to remove the mask. He eventually consents to intubation and is intubated using a size 8-Fr orotracheal ET. The physician asks the respiratory therapist to maintain similar settings but wants to use Dräger Evita Infinity V500 in the VC-CMV

mode. The following section shows the selected ventilator settings.

#### VC-CMV Settings: Patient With COPD

- Pressure required during inspiration was 14 cm H<sub>2</sub>O
- PEEP at 4 cm H<sub>2</sub>O, as previously present
- Set rate at 8 breaths/min
- V<sub>T</sub> (set) of 600 mL (0.6 L) to match previous setting
- Flow at 80 L/min to start
- Flow waveform is constant (the current recommended setting for this mode)
- F<sub>1</sub>O<sub>2</sub> at 0.3 to 0.5, because exact setting is unknown; titrate to achieve SpO<sub>2</sub> of ≥90%
- The following information is noted after assessment:
  - The patient triggers every breath but at a rate above 8 breaths/min. TCT is about 2.5 seconds.
  - T<sub>I</sub> is about 1 second and T<sub>F</sub> is about 1.5 seconds.
  - Expiratory flow does not return to zero before the next breath, indicating the presence of auto-PEEP.
  - During inspiration, following an initial high flow, flow drops to 80 L/min and stays there until  $V_{T}$  is delivered.
- This flow may not be adequate to keep T<sub>1</sub> short.
- · Possible solutions to minimize air trapping may include:
  - Switching to PC-CMV with a short T<sub>I</sub>.
  - Setting a lower V<sub>T</sub>.
  - Checking the patient's airway to be sure it is clear of secretions and possibly administering a bronchodilator.
  - · Increasing inspiratory flow.

Appropriate adjustments are made, and the patient is successfully managed using PC-CMV. The respiratory infection is resolved 5 days later. Secretion clearance is improved. Occasional scattered crackles are heard on auscultation, but otherwise breath sounds have cleared. Infiltrates are no longer present on chest radiographs. Weaning should now be considered for this patient.

#### **ASTHMA**

Patients presenting an exacerbation of acute severe asthma that requires mechanical ventilation are among the most difficult to manage. Increased  $R_{\rm aw}$  from bronchospasm, increased secretions, and mucosal edema increase the incidence of air trapping. Trapped air can cause uneven hyperexpansion of various lung units, which can rupture or compress other areas of the lungs, leading to pneumothorax, pneumomediastinum, subcutaneous emphysema, and other forms of barotrauma.

During an asthma exacerbation, the patient struggles to breathe while trying to move air against increasing airway resistance. The result is dramatic changes in intrapleural pressures  $(P_{pl})$  during inspiration and expiration that affect gas distribution in the lungs and also alter cardiac function, resulting in **pulsus paradoxus**. Progressive hypoxemia further enhances the patient's drive to breathe and compounds anxiety. Even aggressive treatment with bronchodilators and steroids might not be enough to reverse the course of an acute asthma exacerbation.

Box 7.6 lists indications for mechanical ventilation for this group of patients. The primary goal during mechanical ventilation of these patients is to focus on reversing the high  $R_{\rm aw}$  while avoiding or reducing air trapping. If the patient has anxiety and the drive to breathe produces patient-ventilator asynchrony during

### BOX **7.6**

# Indications for Mechanical Ventilation in Acute Exacerbation of Asthma

- Exhaustion (e.g., respiratory rate progressively decreases and level of consciousness is altered), with developing metabolic acidosis and decreasing pH in the presence of a normal or rising CO<sub>2</sub> pressure (P<sub>a</sub>CO<sub>2</sub>).
- 2. If audible, bilateral wheezes become distant as air trapping increases (e.g., breath sounds absent, chest hyperresonant to percussion or fixed on palpation).
- Severe hypoxemia while receiving O<sub>2</sub> (e.g., inability to oxygenate with supplemental O<sub>2</sub>).
- Chest radiograph with depression of the hemidiaphragms and increased radiolucency, suggestive of air trapping.
- Altered mental status, confusion, or decreased level of consciousness.
- 6. Life-threatening dysrhythmias.
- P<sub>a</sub>CO<sub>2</sub> rises while pH declines (e.g., ≥40 mm Hg; pH ≤7.25 [progressive respiratory acidosis superimposed on metabolic acidosis]).
- 8. Cardiac or respiratory arrest.

mechanical ventilation, sedation and possibly paralysis may be required. (NOTE: The use of certain paralytics may result in a neuropathy that can produce prolonged paralysis, which can hinder weaning from ventilatory support. Indeed, prolonged paralysis can have long-term effects, such as reducing a patient's ability to ambulate for several weeks or months. [This can be a particularly serious complication in patients with renal insufficiency or hepatic disease, particularly when paralytic agents and corticosteroids are used in combination for extended periods.])

#### **Guidelines for Patients With Asthma**

The following guidelines provide suggestions for mechanically ventilating patients with asthma. 3-5,41-43,45-50

- VC-CMV and PC-CMV are acceptable modes immediately after intubation. It is easier to control airway pressure with PC-CMV.
- Maintain peak and plateau pressures at minimal levels. PIP may be high because of the high R<sub>aw</sub> and the use of high inspiratory gas flows. Alveolar (plateau) pressures must still be maintained at less than 30 cm H<sub>2</sub>O despite the high PIP.
- Ensure that the patient's oxygenation status is adequate by using an  $F_1O_2$  as needed to achieve a  $P_aO_2$  from 60 to 100 mm Hg (usually  $F_1O_2 \ge 0.5$ ). Monitor hemodynamic status to ensure cardiac output is stable.
- Permissive hypercapnia ( $P_aCO_2$  45–80 mm Hg) is acceptable as long as pH is acceptable (i.e.,  $\geq$ 7.2). (NOTE: Trishydroxymethyl-aminomethane or bicarbonate is administered by some physicians to keep pH >7.2. The preference between these agents varies among physicians.)
- If the ventilator settings cannot accommodate the patient's needs, the use of sedatives and paralytics may be necessary.
   The use of sedation and paralysis may permit resting of fatigued respiratory muscles, particularly during the first 24 hours.
- When patients are spontaneously breathing and having trouble triggering breaths, setting the PEEP<sub>E</sub> at about 80% of intrinsic PEEP may allow for easier triggering of ventilator breaths. (NOTE: PEEP<sub>E</sub> is indicated in only a few situations, because these patients already have an increased functional residual capacity.) In some cases, applied PEEP may recruit lung units that are collapsed (even in the presence of auto-PEEP) and may also assist with expired gas flows.<sup>51</sup> In other cases it may worsen the patient's condition. If PIP increases with the application of PEEP<sub>E</sub>, decrease the level of PEEP<sub>E</sub>.
- Reduce the incidence of air trapping by providing long expiratory times:
  - f = <8 breaths/min;  $V_T$  = 6 to 8 mL/kg;  $T_I$  =  $\leq$ 1 sec; inspiratory gas flow = 80 to 100 L/min descending flow waveform.
- The occurrence of barotrauma in the form of pneumothorax, for example, is not uncommon in these patients. Regular assessment of breath sounds and diagnostic chest percussion, along with chest radiographs, can help guide therapy to avoid this potential problem.

### 🚫 Clinical Scenario: Patient With Asthma

A 13-year-old girl with a history of severe persistent asthma is brought to the ED at 2:30 a.m. Wheezing is audible without the use of a stethoscope. Auscultation of the chest confirms that the wheezing is bilateral. The patient has used

her albuterol MDI 10 times (20 puffs) in the past 4 hours. Current peak expiratory flow rate (PEFR) is 150 L/min. A chest radiograph shows increased radiolucency and depressed hemidiaphragms. ABGs on a 2-L/min nasal cannula are pH = 7.43;  $P_aCO_2 = 25$  mm Hg;  $P_aO_2 = 43$  mm Hg;  $HCO_3 - = 17$  mEq/L. Her  $S_pO_2$  is 73%. She is started on bronchodilators (albuterol and Atrovent) via continuous aerosol and intravenous corticosteroids (Solu-Medrol).

The patient's condition does not improve over the next 5 hours, in spite of therapy. Her breath sounds are more distant, and there is hyperresonance to percussion of the chest wall. She is cyanotic and anxious, and her breaths are labored. On a 4-L/min  $O_2$  nasal cannula, ABGs are pH = 7.25;  $P_aCO_2 = 59$  mm Hg;  $P_aO_2 = 53$  mm Hg;  $P_aCO_3 = 25$  mEq/L.  $P_aCO_3 = 25$  mEq/L.  $P_aCO_3 = 25$  mEq/L.  $P_aCO_3 = 25$  mEq/L.  $P_aCO_3 = 25$  min (down from 30 breaths/min on admission). Blood pressure is 160/100 and heart rate is 175 beats/min. She is transferred to the ICU, and the decision is made to intubate her and begin mechanical ventilatory support. To calculate initial settings, see the following section.

# Initial Ventilator Settings: Patient With Acute Asthma

On the basis of this patient's history and size (5 ft, 3 in [63 in], 108 lb [49 kg]):

- IBW = 105 + 5(3) = 120 lb (54.5 kg)
- BSA =  $1.5 \text{ m}^2$
- Initial  $\dot{V}$  E = 1.50 × 3.5 = 5.25 L/min
- Targeted V<sub>T</sub> (6-8 mL/kg); 327 to 435 mL
- $f = \dot{V} E/V_T = (5.25 L/min)/0.435 L = 12 breaths/min.$

#### **NEUROMUSCULAR DISORDERS**

It is not unusual for patients with neuromuscular disorders to require ventilatory support. Examples of disorders that are included in this category are myasthenia gravis, amyotrophic lateral sclerosis, muscular dystrophy, Guillain-Barré syndrome, tetanus, cervical spinal cord injury, postpolio syndrome, and botulism. Patients with ventilatory failure because of a neuromuscular disorder usually have a normal ventilatory drive and normal or near-normal lung function. Most of the neuromuscular disorders cited cause respiratory muscle weakness, which can limit these patients' abilities to cough and clear secretions. As a result, they tend to develop atelectasis and pneumonia. If the glottic response is weak, they may also have an increased risk for aspiration. Mechanical ventilation is most often required if progressive respiratory muscle weakness will eventually lead to respiratory failure.

Patients with neuromuscular problems can be effectively ventilated with either positive or negative pressure ventilation. In the hospital environment, positive pressure ventilation is most often selected and can be either noninvasive or invasive. Negative pressure ventilation is rarely used.

The patients most often seen in hospitals are those with a rapid onset of their disease that requires admission (e.g., Guillain-Barré syndrome, myasthenia gravis). Because these patients often have normal lung function, they are at low risk for barotrauma and are most comfortable when ventilated with higher V<sub>T</sub> values (i.e., 6–8 mL/kg) and high inspiratory flow rates greater than 60

L/min using a constant flow or descending flow pattern when VC-CMV is used. (NOTE: Some clinicians prefer starting with a lower  $V_{\rm T}$  and adjusting the volume as needed.) Patients with spinal cord injuries resulting in quadriplegia require full ventilatory support. Patients with myasthenia gravis usually require only partial support until their own breathing capacity returns.

# **Guidelines for Patients With Neuromuscular Disorders**

The following guidelines are recommended for mechanically ventilating patients with neuromuscular disorders<sup>3-5</sup>/<sub>4</sub>1-42:

- Full or partial support
- · Positive or negative pressure ventilation
- Noninvasive or invasive ventilation
- VC-CMV
- $V_T$  (6–8 mL/kg) while maintaining the Pplat at less than 30 cm  $_{\mathrm{H_2O}}$
- f = 8 to 16 breaths/min
- Inspiratory flow rates  $\geq$ 60 L/min to meet patient need ( $T_{\rm I} \sim$ 1 second to start)
- Flow waveform: Constant or descending flow pattern
- PEEP = 5 cm H<sub>2</sub>O may be needed to relieve dyspnea
- $F_1O_2 = 0.21$

#### Clinical Scenario: Neuromuscular Disorder

A 5-ft, 2-in, 115-lb, 67-year-old woman with a history of myasthenia gravis was brought to her physician's office by her daughter. She complained of progressive muscle weakness. Physical examination revealed that she demonstrated drooping eyelids and difficulty talking and swallowing. She was unable to walk more than a step or two. She was transferred to the hospital, where she was given edrophonium (Tensilon), which improved her muscle function for 10 to 15 minutes. On admission, her vital signs were unremarkable. Her maximum inspiratory pressure (MIP) was  $-35~{\rm cm}~{\rm H}_2{\rm O}$ , and her vital capacity (VC) was 1.8 L (predicted was 3.3 L). Her  ${\rm S}_{\rm D}{\rm O}_2$  on room air was 96%.

Anticholinesterase therapy was administered, and MIP and VC were monitored every 8 hours. The nursing staff reported that the patient was having trouble swallowing when she ate and they feared that she would aspirate. MIP and VC values progressively declined. After being hospitalized for 24 hours, her MIP was -25 cm  $H_2O$  and VC was 1.0 L. ABGs on room air were pH = 7.36;  $P_aCO_2 = 48$  mm Hg;  $P_aO_2 = 62$  mm Hg;  $HCO_3 - 27$  mEq/L. The following section provides a summary of the therapeutic intervention used for this patient. Could noninvasive positive pressure ventilation (NIV) be used in this situation?

### Initial Ventilator Settings: Patient With Neuromuscular Disorder (Myasthenia Gravis)

The patient was intubated because of increased risk for aspiration. (Invasive mechanical ventilation was initiated rather than NIV because her ability to swallow was compromised and she showed signs of acute respiratory failure despite anticholinesterase therapy.)

The patient is 5-ft, 2-in tall and weighs 115 lb, so:

• IBW = 105 + 5(2) = 115 lb (52 kg)

- BSA is 1.5 m<sup>2</sup>
- Estimated  $\dot{V}$  E is 3.5  $\times$  1.5 = 5.25 L
- $V_T = 420 \text{ mL} (8 \text{ mL/kg}) (VC\text{-CMV})$
- Rate = 13 breaths/min
- Flow = 60 L/min using a constant waveform
- PEEP = 2 cm  $H_2O$  and  $F_1O_2 = 0.21$
- Calculate T<sub>I</sub> and T<sub>F</sub>
- $T_1 = VT/flow (L/s) = 0.420 L/(1 L/s) = 0.42 second$
- TCT = 60 s/12 = 5.0 seconds
- $T_E = 6.0 0.42 = 5.58$  seconds
- $PIP = 20 \text{ cm H}_2O$
- Pplat = 12 cm  $H_2O$
- What is the transairway pressure?  $20 12 = 8 \text{ cm H}_2\text{O}$
- What is the patient's  $C_L$  and is it normal?
  - $C_L = V_T/(P_{plat} PEEP) = 0.420/(12 3) = 0.046 L/cm H_2O$ or 46 mL/cm  $H_2O$
  - C<sub>L</sub> is normal

Ventilatory support was maintained for a total of 10 days, with one occurrence of a respiratory infection that responded to antibiotic therapy. She was successfully weaned and extubated on the 10th day.

#### **CLOSED HEAD INJURY**

Closed head injury is an injury to the brain in which the skull remains intact. It is most commonly caused by trauma to the head from falls, automobile accidents, and blows to the head. Because the skull is a closed container, bruising the brain tissue can result in swelling (edema) and increased intracranial pressure (ICP). Similar effects may occur after surgery (postcraniotomy), medical accidents (i.e., cerebrovascular accident [stroke], and post-resuscitation hypoxemia.)<sup>3,37,41,42</sup>

The cranial vault contains the brain, blood, and cerebrospinal fluid. Assessment of cerebral blood flow is important because the brain relies on steady blood flow to provide  $O_2$ . Maintaining sufficient cerebral blood flow requires an adequate cerebral perfusion pressure (CPP). CPP is defined by this equation: CPP = mean arterial pressure (MAP) — ICP. Normal values for MAP are 90 to 95 mm Hg and ICP less than 10 mm Hg. Normal CPP is 80 to 85 mm Hg. Values of CPP lower than 60 mm Hg indicate poor cerebral perfusion.

Clinically, it is important to keep ICP low and MAP in the normal range to maintain CPP in brain-injured patients. Several techniques can be used to accomplish this goal. Mannitol infusion can be used to increase osmotic pressures and reduce ICP in acute situations; diuretics can reduce fluid volume (may reduce MAP, which may reduce CPP); and barbiturates can be used to reduce cerebral O<sub>2</sub> demand and lower ICP when conventional therapy fails. Patients should be maintained with their head in a neutral position and the head of the bed elevated by 30 degrees.

Iatrogenic hyperventilation, or the deliberate lowering of  $P_aCO_2$ , is sometimes used to reduce ICP, but its effectiveness remains controversial. The theory is that acute reductions in  $P_aCO_2$  are thought to result in cerebral vasoconstriction, reducing cerebral blood volume and ICP. (NOTE: a decreasing  $CO_2$  is associated with an increase in pH.) The effect of  $CO_2$  and pH change on ICP is most pronounced when it is acute and loses its effect as the pH of the cerebrospinal fluid becomes normalized. Therefore  $P_aCO_2$  should be normalized as soon as possible, depending on ICP response. It is important to mention that not all physicians

BOX **7.7** 

# Indications for Mechanical Ventilation in Patients With Head Injuries

#### **Assisted Ventilation**

- Respiratory depression associated with injury. It may be manifested as Cheyne-Stokes respiration, central neurogenic hyperventilation, or apnea.
- 2. Additional injuries to the chest, abdomen, back, or neck.
- 3. Use of medications that depress respiration.
- Neurogenic pulmonary edema (an acute respiratory distress syndrome—like pattern that can occur after head trauma).
- 5. Impending or actual cardiac arrest.
- 6. Upper airway compromise (e.g., presence of stridor or loss of airway clearance mechanisms).
- 7. Aspiration at the time of loss of consciousness.

#### **Airway Management (Intubation)**

- Head injury (particularly with Glasgow Coma Scale score\* of ≤8).
- 2. Face, jaw, neck injuries with bleeding.

#### **Oxygen Delivery**

- 1. Head injury.
- 2. Pulmonary contusion, edema, or both.

\*See Box 7.8.

advocate the use of this technique. Furthermore, if an increased ICP is not present, iatrogenic hyperventilation is not indicated (current standards suggest that the P<sub>a</sub>CO<sub>2</sub> should be maintained between 35 and 40 mm Hg). When a high ICP is present, iatrogenic hyperventilation can be used for a short time. Box 7.7 lists the indications for mechanical ventilation in patients with head injury.<sup>3</sup> Box 7.8 provides information on the Glasgow Coma Scale score mentioned in Box 7.7.

# **Guidelines for Patients With a Closed Head Injury**

The following guidelines are recommended for mechanically ventilation in patients with closed head injuries<sup>3-5,41-42</sup>:

- After head injury, protect the airway because patients with altered levels of consciousness may be unable to do so. There is a high risk for vomiting and aspiration. Orotracheal intubation is often required.
- PC-CMV and PEEP can actually increase ICP. These patients
  often have normal lungs, so high P<sub>alv</sub> can be transmitted to
  the blood vessels, thus affecting venous return from the head.
  Monitoring for elevated ICP can help evaluate this effect.
- Monitor for increased ICP and hypoxemia so that a rapid increase in ventilation and oxygenation can be instituted if needed or if recommended by institutional policy.
- When there is acute uncontrolled increased ICP, maintain P<sub>a</sub>CO<sub>2</sub> from 25 to 30 mm Hg or titrate the ICP if it is being monitored.

### BOX **7.8**

#### Glasgow Coma Scale Score\*

#### **Verbal Response**

- 1 = None
- 2 = Incomprehensible sounds
- 3 = Inappropriate words
- 4 = Confused
- 5 = Oriented

#### **Eye Opening**

- 1 = None
- 2 = To pain
- 3 = To speech
- 4 = Spontaneously

#### **Motor Response**

- 1 = None
- 2 = Abnormal extension to pain
- 3 = Abnormal flexion to pain
- 4 = Withdraws from pain
- 5 = Localizes pain
- 6 = Follows commands

\*The Glasgow Coma Scale score evaluates a patient's verbal, eye, and motor responses. Scores range from 3 to 15.

- If iatrogenic hyperventilation is used, this should be only temporary, with P<sub>a</sub>CO<sub>2</sub> gradually returning to normal levels in 24 to 48 hours, allowing acid-base balance to restore itself. Sudden increases in P<sub>a</sub>CO<sub>2</sub> could trigger increases in cerebral blood flow and ICP. A normal response to acute increases in ICP is hypertension with bradycardia, which is called the Cushing response.<sup>3</sup>
- Ventilator settings include the following:
  - Provide full ventilatory support to start.
  - Either PC-CMV or VC-CMV can be used.
  - Maintain  $V_T$  from 6 to 8 mL/kg IBW while maintaining  $P_{plat}$  less than 30 cm  $H_2O$ .
  - An f of 15 to 20 breaths/min to provide normal acid-base status, as long as auto-PEEP is avoided.
  - $F_1O_2 = 1.0$  initially and titrate as needed to keep  $P_aO_2$  from 70 to 100 mm Hg to avoid hypoxemia.
  - High inspiratory flow (>60 L/min) to keep  $T_{\rm I}$  short, about 1 second (avoid auto-PEEP) using a descending ramp pattern or constant flow pattern.
  - PEEP = ≤5 cm H<sub>2</sub>O, as long as ICP is being measured and is ≤10 mm Hg. Because PEEP can increase ICP, it is used only if necessary to avoid severe hypoxemia.
- Suctioning and chest physiotherapy can dramatically increase ICP, but maintaining a clear airway is also essential. Consequently, bronchial hygiene therapy must be done with extreme caution.
- Monitor for complications of pulmonary infections and pulmonary emboli.



#### ( Clinical Scenario: Acute Head Injury

A 23-year-old man is admitted to the ED after hitting his head against a tree in a skiing accident. He is unconscious on admission. There are no fractures to his head, neck, thorax, or limbs, but some bruising is present on his arms and legs. On admission, his vital signs are blood pressure = 150/ 90 mm Hg; heart rate = 110 beats/min and regular; f = 12 breaths/min; and temperature = 35.6° C. Breath sounds are equal and clear bilaterally. He withdraws from painful stimuli but is otherwise unresponsive. His pupils respond equally to light.

The decision is made to intubate the young man to protect his airway. A computed tomogram of the head reveals an intracranial hemorrhage. After neurosurgery, the patient is transferred to the ICU; an ICP monitor is in place, along with an arterial line and a pulmonary artery catheter. He is receiving phenobarbital (a barbiturate) and midazolam (a short-acting benzodiazepine). The patient is 6 ft, 4 in (76 in) and weighs 225 lb (102 kg). ICP is 15 mm Hg, and hemodynamic data are within normal limits. The following section provides suggestions for his initial ventilator setting.

#### Suggesting Initial Ventilator Settings: Patient With **Head Injury**

- Patient's IBW: 106 + 6(16) = 202 lb (92 kg)
- Patient's BSA: 2.32 m<sup>2</sup>
- Settings:  $V_T = 552$  to 736 mL (range of 6–8 mL/kg IBW)
- Normal  $V_F = 4 \times 2.32 = 9.28$  L/min
- Lung condition assumed to be normal at this time

#### **Possible Initial Settings**

- VC-CMV,  $V_T=0.6$  L; f=15 breaths/min; flow = 60 L/min using descending ramp
- $F_1O_2 = 1.0$ ;  $PEEP = 3 \text{ cm } H_2O$

After 30 minutes on the initial settings, ABGs are pH = 7.43;  $P_aCO_2 = 36 \text{ mm Hg}$ ;  $P_aO_2 = 450 \text{ mm Hg}$ ; and  $HCO_3 = 24$ mEq/L. ICP = 18 mm Hg.  $F_1O_2$  is reduced to 0.5, and the patient is maintained on these settings until reevaluation in 2 hours. Additional changes should be directed toward reducing ICP.

#### **ACUTE RESPIRATORY DISTRESS SYNDROME**

ARDS is recognized as one of the most complex pulmonary disorders to manage. Mortality rates have been reported to range from 30% to 70%. 34-39 Box 7.9 lists the diagnostic criteria for ARDS, and Box 7.10 lists some precipitating factors leading to this disorder. The characteristic pathophysiological findings associated with ARDS include hypoxemia, increased pulmonary vascular permeability, bilateral radiographic opacities, venous admixture, increased lung weight, and decreased lung compliance. ARDS has been described as having two phases: an early phase (first 7-10 days), which is characterized by increased vascular permeability, lung water, and lung protein; and a later phase (after 10 days), which is accompanied by extensive lung fibrosis.<sup>52</sup> Management of ARDS inevitably includes mechanical ventilatory support.55

### BOX **7.9**

#### **Diagnostic Criteria for Acute Respiratory Distress Syndrome**

- History of precipitating condition (see Box 7.10) that occurs within 1 week of a known clinical insult
- Diffuse bilateral alveolar infiltrates on chest radiograph (or computed tomography scan) not fully explained by effusions, lobar/lung collapse, or nodules
- Pulmonary edema not fully explained by cardiac failure or fluid overload. Objective assessment to verify if no risk factor is present
- Reduced lung compliance (C<sub>L</sub>) (<40 mL/cm H<sub>2</sub>O)
- Refractory hypoxemia (reduced partial pressure of arterial oxygen [PaO2]/fractional inspired oxygen concentration  $[F_1O_2]$
- Mild  $\leq$ 200 mm Hg  $P_aO_2/$   $F_lO_2 \leq$ 300 mm Hg with 5 cm H<sub>2</sub>O PEEP
- Moderate <100 mm Hg  $\leq$ 200 mm Hg with 5 cm H<sub>2</sub>O **PEEP**
- Severe  $\leq$ 100 mm Hg with 5 cm H<sub>2</sub>O PEEP

### BOX **7.10**

#### **Examples of Conditions Associated With Development of Acute Respiratory Distress Syndrome**

- Sepsis
- Aspiration of gastric contents
- · Thoracic and nonthoracic trauma
- Heroin or other drug overdose
- Massive blood transfusions
- Smoke inhalation or chemically induced lung injury
- Pulmonary vasculitis
- Rurns
- **Pancreatitis**
- Near-drowning
- · Interstitial viral pneumonitis
- · Disseminated intravascular coagulation
- O<sub>2</sub> toxicity
- Prolonged cardiopulmonary bypass

#### **Guidelines for Patients With ARDS**

For patients with ARDS, a V<sub>T</sub> of 6 to 8 mL/kg with a respiratory rate of 15 to 25 breaths/min is indicated. Use of lower than normal  $V_{TS}$  ( $V_{T} = 4-6$  mL/kg) may be necessary to maintain the  $P_{plat}$ below 30 cm H<sub>2</sub>O. This protective lung strategy has been shown to reduce the risk for ventilator-induced lung injury and improve outcomes for ARDS patients. As discussed in earlier chapters, it is important to remember that the use of high respiratory rates and low V<sub>T</sub> may not provide sufficient time for exhalation and ultimately lead to air being trapped in the lungs during exhalation (auto-PEEP).

The following guidelines are suggested for ventilation in patients with ARDS<sup>3-5,34-36,43,52-55</sup>:


- Choose a mode capable of supporting oxygenation and ventilation, such as PC-CMV or VC-CMV.
- Maintain S<sub>a</sub>O<sub>2</sub> at 88% to 90% or greater. Start at 100% O<sub>2</sub>. To support oxygenation, use PEEP<sub>E</sub> at a level that prevents alveolar collapse but minimizes overdistention to prevent lung damage. PEEP<sub>E</sub> may allow reduction of F<sub>I</sub>O<sub>2</sub> to safe levels.
- When oxygenation is inadequate, sedate, paralyze, and consider prone positioning. Cardiac output and hemoglobin levels should be optimized. High PEEP<sub>E</sub> levels greater than 15 cm H<sub>2</sub>O may be required in ARDS.
- Keep P<sub>plat</sub> below 30 cm H<sub>2</sub>O by lowering V<sub>T</sub> to 4 to 6 mL/kg, if necessary. Allow P<sub>a</sub>CO<sub>2</sub> to rise above normal (permissive hypercapnia) if necessary, unless there is a risk for increased ICP or contraindications exist that demand a normal P<sub>a</sub>CO<sub>2</sub> or pH. Rapid rises in P<sub>a</sub>CO<sub>2</sub> should be avoided.

There is no evidence to date that PC-CMV is superior to VC-CMV, or vice versa. The selection of one mode over the other may depend on clinician comfort levels. If VC-CMV is selected, the clinician should use the descending flow waveform to help ensure early delivery of  $V_T$  and provide a higher mean airway pressure  $(P_{aw})$  than a constant flow pattern, which may benefit oxygenation and minimizes the difference between PIP and  $P_{plat}$ .

During the acute phase of the disease, patients typically require high levels of ventilatory support, although full support is usually not necessary. These levels can be attained with either CMV or IMV + PSV. Adequate ventilation can generally be provided with  $V_T$  in the range of 4 to 6 mL/kg while  $P_{plat}$  is maintained at below 30 cm  $H_2O$  with rates of 15 to 25 breaths/min. Use flow greater than 60 L/min for volume-controlled ventilation. During pressure-controlled ventilation, use a  $T_I$  that is long enough to enhance oxygenation but short enough to allow adequate  $T_E$  to avoid auto-PEEP (e.g.,  $T_I < 1$  second). Because time constants are short for many lung units (decreased compliance), this is usually not difficult even for I/E ratios of 1:1.5 or higher (e.g., 1:1 or 2:1).

PEEP<sub>E</sub> is required for the management of ARDS to prevent the opening and closing of alveoli during each breath. This opening and closing can cause lung injury from the shear stress (frictional forces) between alveoli that have different time constants and may also result in surfactant being "milked" from the alveoli (Fig. 7.4). 54,55 During the early phase of ARDS, it is important to keep PEEP<sub>E</sub> high enough at least to exceed the inflection point on a slow or static pressure-volume curve (see Chapter 13). 55,56 It is generally accepted by clinicians that the deflation limb of a slow pressure-volume loop best approximates the end-expiratory pressure range required to prevent alveolar collapse.<sup>57</sup> Maintaining PEEP<sub>E</sub> above this pressure range helps prevent opening and closing of small airways and alveoli (i.e., this is often referred to as the open lung approach to ventilator management). 55-59 Even if a ventilator does not have a graphics package, this curve can be graphed by hand. PEEPE may also be beneficial in later stages of ARDS to maintain oxygenation and reduce the  $F_1O_2$  levels (<0.5). More information about the management of ARDS is presented in Chapter 13.

Acceptable endpoints for the management of ARDS based on ABGs are  $P_aCO_2=40$  to 80 mm Hg; pH=7.20 to 7.40;  $P_aO_2=60$  to 100 mm Hg. Note that these values may vary across institutions. Some physicians prefer to use tris-hydroxymethyl-aminomethane or sodium bicarbonate when pH drops below 7.20.  $^{42,59}$ 



**Fig. 7.4** The volume from a positive pressure breath distributes homogeneously throughout the lung with normal lung compliance ( $C_L$ ) (*left panel*). In a lung with low regional  $C_L$ , the volume from a positive pressure breath distributes preferentially to the regions with more normal  $C_L$  (*right panel*). Thus a tidal volume ( $V_T$ ) of normal size in a lung with regions of low  $C_L$  can overdistend the healthier regions. This may create shear stress (frictional forces) between adjacent lung units. (Redrawn from MacIntyre NR: Minimizing alveolar stretch injury during mechanical ventilation, *Respir Care* 41:318—326, 1996.)



#### Clinical Scenario: Patient With Acute Respiratory Distress Syndrome

A 60-year-old man sustained multiple lacerations from a motor vehicle crash. Admission to the ED for evaluation revealed a fractured left femur, a deep laceration of the right arm, an open pneumothorax on the right side of the chest, and abdominal bruising. There was evidence of injury to the head or neck. The patient was taken to surgery for repair of internal injuries; a chest tube with pleural drainage was inserted for the pneumothorax.

The patient developed a fever of  $39.5^{\circ}$  C and severe refractory hypoxemia 4 days after surgery. A chest radiograph showed resolution of the pneumothorax and the presence of bilateral fluffy infiltrates. ABGs on a nonrebreathing mask at the time were pH = 7.29;  $P_aCO_2 = 51$  mm Hg;  $P_aO_2 = 76$  mm Hg;  $HCO_3-=24.8$  mEq/L. Vital signs were blood pressure = 148/90 mm Hg; heart rate = 152 beats/min; f = 40 to 42 breaths/min and labored. The patient was restless and anxious. Mask CPAP was initiated with  $F_1O_2 = 1.0$  and greater than 10 cm  $H_2O$ . The face mask was not well tolerated. The patient, who was 6 ft, 2 in (72 in) and weighed 258 lb (117 kg), was sedated, paralyzed, orally intubated, and placed on ventilatory support (Case Study 7.2). (NOTE: The progress of this patient is continued in Chapter 13.)



#### Case Study 7.2

# Key Questions for Acute Respiratory Distress Syndrome (ARDS) Patient

- 1. What were the indications for ventilation of this patient?
- 2. What clinical information suggests this patient may have developed ARDS?
- 3. What would be appropriate initial ventilator settings for this patient?

# ACUTE CARDIOGENIC PULMONARY EDEMA AND CONGESTIVE HEART FAILURE

Cardiovascular disease is the most common cause of death in the United States (Centers for Disease Control and Prevention). It is not surprising that many patients with cardiovascular problems seek medical help in both EDs and urgent care centers. These problems can take the form of shortness of breath with or without accompanying chest pain.

Patients with congestive heart failure (CHF) can rapidly develop acute pulmonary edema. Box 7.11 lists the most common causes of cardiogenic pulmonary edema.

Much of the treatment of acute heart failure is based on medical management. For example, diuretics are given to reduce vascular fluid load, positive inotropic agents are given to improve cardiac contractility, and vasodilators can improve myocardial oxygenation and reduce preload and afterload. Many patients can be successfully managed with drug therapy and do not require mechanical ventilatory support. However, mechanical ventilation may be indicated when severe heart failure leads to increased myocardial work, increased WOB, and hypoxemia. In patients with left ventricular failure the use of positive pressure, particularly PEEP (Box 7.12, 1 through 4), can effectively reduce the size of the heart and therefore reduce venous return and reduce preload to left ventricles.<sup>3,37</sup> Reducing the size of an overdistended left ventricle can improve the relationship of left ventricular length to tension and allow for an increase in stroke volume. PEEP increases intrathoracic pressures and reduces venous return, thus reducing preload to the heart.

# **Guidelines for Patients With Congestive Heart Failure**

The following guidelines are recommended for mechanical ventilation in patients with acute cardiogenic pulmonary edema and  $\mathrm{CHF}^{3-5,41-43}$ :

### BOX 7.11

# **Common Causes of Acute Pulmonary Edema**

- Acute myocardial infarction
- Hypertension
- · Rapid heart rates with inadequate filling time
- · Valvular heart disease
- · Fluid overload

- Select a mode of ventilation that reduces WOB. This may be as simple as noninvasive mask CPAP. NIV by mask CPAP may improve oxygenation, reduce P<sub>a</sub>CO<sub>2</sub>, reduce the WOB, and reduce myocardial work. NIV in patients with CHF may allow sufficient time for pharmacological treatment to become effective.
- When life-threatening hypoxemia occurs with severe CHF, PEEP or positive pressure ventilation may have beneficial effects on myocardial function and improve oxygenation.
- Careful evaluation of the effects of positive pressure ventilation
  on hemodynamics is essential. This may include the use of a
  pulmonary artery catheter in severe cases, particularly if PEEP<sub>E</sub>
  greater than 10 to 15 cm H<sub>2</sub>O is used. However, the use of pulmonary catheters carries a risk for increased mortality and
  morbidity and is controversial (see Chapter 11 for more details
  about hemodynamic monitoring).
- The use of VC-CMV or PC-CMV is recommended to minimize spontaneous breathing, which may divert increased blood flow and O<sub>2</sub> consumption to the respiratory muscles.
- V<sub>T</sub> range is moderate from 6 to 8 mL/kg: set f from 10 or more breaths/min and peak flows 60 L/min or greater using either descending or constant waveforms. T<sub>I</sub> range is 1 to 1.5 seconds.
- Set a PEEP of 5 to 10 cm H<sub>2</sub>O to support the cardiac function.
- Start F<sub>1</sub>O<sub>2</sub> at 1.0 and titrate quickly with S<sub>p</sub>O<sub>2</sub> to maintain S<sub>p</sub>O<sub>2</sub> greater than 90% to 92%.
- Monitor S<sub>p</sub>O<sub>2</sub>, ABGs, urine output, electrolytes, and systemic hemodynamic status.

### BOX 7.12

#### Potential Effects of PEEP in Left Ventricular Dysfunction

- Increased mean airway pressure (P<sub>aw</sub>) and intrathoracic pressure lead to reduced venous return, which can reduce preload to a failing heart, improving its function.
- Increased functional residual capacity from PEEP leads to increased pulmonary vascular resistance and increased afterload to the right heart and decreased left heart filling. Increased right heart pressures with the increased afterload may shift the interventricular septum to the left. This does not seem to alter right ventricular contractility until values for pulmonary artery pressure are critical.
- 3. With the left shift of the interventricular septum, the left ventricular volume is reduced. This may reduce the load it must pump. However, it may also affect the compliance of the left ventricle and either increase or decrease left heart function (the response varies).
- 4. The mechanical compression of the heart and aorta by the pleural pressure surrounding them can also alter ventricular function. The vascular pressure in the heart and thoracic aorta is transiently increased relative to the extrathoracic aorta (i.e., left ventricular afterload decreases). This response is not always consistent, and cardiac tamponade from PEEP can negatively alter myocardial compliance as well
- If ventilator modes increase work of breathing, this increases O<sub>2</sub> demand and can lead to increased myocardial ischemia and a reduction in left ventricular compliance.



#### (🚫) Clinical Scenario: Patient With Congestive Heart Failure

A 63-year-old man who is complaining of severe shortness of breath is brought by ambulance to the ED. He is 5 ft, 11 in (71 in) and weighs 175 lb (79.5 kg). His vital signs are blood pressure = 175/115 mm Hg, heart rate = 140 beats/min and the rhythm is irregular, f = 22 to 24 breaths/min, and normal temperature. His lips are cyanotic, his neck veins are distended, and both of his ankles show evidence of pitting edema. Breath sounds reveal bilateral basilar crackles and wheezes. He has a productive cough with small amounts of pink, frothy secretions. He is anxious and refuses to lie down on the gurney, saying, "I get too short of breath when I lie down."

A chest radiograph shows cardiomegaly and dense, fluffy opacities in the lower lung fields. The electrocardiogram reveals atrial fibrillation with a ventricular rate of 138 to 140 beats/min and occasional premature ventricular contractions. The respiratory therapist places a pulse oximeter sensor on the patient's left index finger and notices that the patient's hand is cold. The respiratory therapist is unable to obtain an accurate pulse oximeter reading (Case Study 7.3). After placing the sensor on the right index finger and rubbing the hand to warm it, an SpO2 reading of 87% is obtained.

The patient is started on a nasal cannula at 2 L/min and given intravenous furosemide, dobutamine, and digitalis. ABGs obtained 1 hour later are pH = 7.16;  $P_aCO_2 = 79$  mm Hg;  $P_aO_2 =$ 33 mm Hg; and  $HCO_3-=28$  mEq/L on 2 L/min by nasal cannula. The patient's urine output was 580 mL in the past hour, and he remained cyanotic. The 2 L/min nasal cannula was not adequate. He is slow to respond to verbal commands. The following information provides an alternative therapeutic approach using NIV.

#### Alternative Solution to Patient Treatment: CHF

......

Noninvasive ventilation is started for this patient using a fullface mask and bilevel PAP with IPAP at 9 cm H2O, EPAP at 3 cm H<sub>2</sub>O, and F<sub>1</sub>O<sub>2</sub> of approximately 0.5. The patient's spontaneous respiratory rate on these settings is 25 breaths/min, and the  $S_pO_2$  is now 88%.

To reduce f and S<sub>p</sub>O<sub>2</sub>, the IPAP and EPAP are increased. After several adjustments, the final values for adequate ventilation are IPAP = 15 cm  $H_2O$ ; EPAP = 5 cm  $H_2O$ ; approximate  $F_1O_2$  = 0.6; f = 16 breaths/min; and  $V_T = 760$  mL.  $S_pO_2 = 95\%$ .

The patient's condition improves with treatment. Urine output is 850 mL over a 2-hour period. Breath sounds reveal a moderate amount of crackles in the lung bases. The patient's color improves and he is alert, responsive, and cooperative. The pressure support levels are gradually reduced. The patient is alternately tested with a 50% O2 mask and returned to the noninvasive ventilator until he is stable on the 50% mask. ABGs on an  $F_1O_2 = 0.5$  are pH = 7.38;  $P_aCO_2 = 45$  mm Hg;  $P_aO_2 =$ 73 mm Hg; and  $HCO_3 - = 26$  mEq/L. The patient is monitored over the next 24 hours, stabilized on medication, and discharged into the care of his wife.

Although NIV was successful in this individual, it is important to recognize that it is not always successful. Some patients with decompensated heart failure will temporarily improve with NIV but then worsen and may even go into cardiac arrest. Some clinicians prefer to intubate and provide invasive ventilation rather than NIV in this patient population because invasive ventilation provides more controlled conditions.



#### Case Study 7.3

#### **Troubleshooting: The Pulse Oximeter**

Why was the therapist unable to get an initial reading from the pulse oximeter? What would you suggest to alleviate this situation?



- Numerous issues must be considered before connecting a patient to a mechanical ventilator. These include selecting appropriate ventilator settings for F<sub>I</sub>O<sub>2</sub>, sensitivity, sigh breaths, alarms, and monitors, as well as concerns regarding humidification of inspired gases.
- Once the patient is connected to the ventilator, the clinician should perform a careful assessment of the patient's response to these initial parameters.

- Titrating the F<sub>I</sub>O<sub>2</sub> using pulse oximetry and ABG findings can minimize the risk for administering too much O<sub>2</sub>.
- · Ventilator sensitivity is normally set so that patients can easily flow-trigger or pressure-trigger a breath.
- It can be particularly difficult to adjust the ventilator sensitivity so that it senses a patient's effort when auto-PEEP is present.
- · Humidity can be provided by a variety of humidification systems. Devices in this category include the following types of humidifiers: pass-over, vapor phase, wick, and active heat and moisture exchangers.
- · Audible and visible alarm systems are designed to alert the operator of potential dangers related to the patient-ventilator interaction.
- · Initial ventilator setting should be based on the patient's condition. Table 7.1 provides a summary of initial ventilator settings for patients commonly encountered in the clinical setting.
- Mechanical breaths of V<sub>T</sub> 6 to 8 mL/kg IBW are usually effective, but lower V<sub>T</sub>s may be required for patients with ARDS to maintain P<sub>plat</sub> below 30 cm H<sub>2</sub>O. Low levels of PEEP (3–5 cm H<sub>2</sub>O) can reduce atelectasis formation.

#### TABLE **7.1**

#### Initial Ventilator Settings Based on Pulmonary Disorder<sup>a</sup>

Lung Disease	Mode	V <sub>T</sub> (mL/kg IBW)	Rate (breaths/ min)	Flow (L/min)	Flow Waveform	T <sub>1</sub> (s)	PEEP (cm H <sub>2</sub> O)	F <sub>I</sub> O <sub>2</sub>
Normal lungs	VC- or PC- CMV	6-8	10-15	60	Descending or constant	1	≤5	≤0.5
COPDb	VC- or PC- CMV	6-8	8-12	>60 (80 -100)	Descending or constant	0.6-1.2	≥5 or 50% of intrinsic PEEP	<0.5
Neuromuscular disorder	VC-CMV	6-8	8-12	≥60	Descending or constant	1	5	0.21
Asthma	VC- or PC- CMV	6-8	10-14	60-70	Descending	≤1	Only to offset intrinsic PEEP and improve triggering	≥0.5
Closed head injury	PC- or VC- CMV	6–8	15—20	60	Descending or constant	1	0-5 with caution Only in severe hypoxemia	1.0
ARDS	PC- or VC- CMV	4-8	12-35	≥60	Descending or constant	1	5 to >15	1.0
CHF	VC- or PC- CMV	6-8	≥10	≥60	Descending or constant	1-1.5	5-10	1.0

<sup>&</sup>lt;sup>a</sup>For all disorders it is important that the plateau pressure be maintained lower than 30 cm H<sub>2</sub>O.

ARDS, acute respiratory distress syndrome; CHF, congestive heart failure; CMV, continuous mandatory ventilation;  $F_1O_{2r}$  fractional inspired oxygen concentration; IBW, ideal body weight; PC, pressure control; PEEP, positive end-expiratory pressure;  $V_{Cr}$  volume control;  $V_{Tr}$  tidal volume.

Sources: Meade MO, Herridge MS: An evidence-based approach to acute respiratory distress syndrome, *Respir Care* 46:1368–1376, 2001; and Slutsky AS, Ranieri M. Ventilator-induced lung injury, *N Engl J Med*. 2013;369:2126–236, 2013.

#### **REVIEW QUESTIONS** (See Appendix A for answers.)

1.	<ul> <li>A male patient has a B</li> </ul>	$SA  ext{ of } 1.5  ext{ m}^2$ ; is 5 ft	t, 8 in; and weighs 175
	lb. The patient has a h	istory of lung dama	age resulting from old
	tuberculosis scars. He	e demonstrates a	restricted breathing
	pattern. What ventila	tor settings would	d you select for this
	patient?		

V <sub>E</sub> :	
$V_T$ :	
f:	

- **2.** A patient with COPD is on ventilation with a PB 980 ventilator. Ventilator parameters are VC-CMV: flow = 40 L/min with descending ramp flow waveform;  $V_T = 0.65$ ;  $F_IO_2 = 0.3$ . At 2:00 p.m., total f = 10 breaths/min, PIP = 28 cm  $H_2O$ , there are no assisted breaths, and the pressure-time curve is normal. At 4:00 p.m., total f = 20 breaths/min, PIP = 37 cm  $H_2O$ , the patient is actively assisting and using accessory muscles to breathe, and the pressure-time graphic shows a concave appearance. What do you think has caused the changes in the patient's condition? What would you do to correct this situation?
- **3.** An 83-year-old man with COPD is being treated in the ED. His wife, who brought him in, states, "He's been so short of breath and pale and I'm worried."  $O_2$  by a 28% air-entrainment mask is begun. The patient is given an aerosol treatment with albuterol. Despite continued therapy, the patient does not improve and continues to use accessory muscles to breathe. He is diaphoretic and pale, and his temperature is  $102^{\circ}$  F. The decision is made to begin noninvasive ventilation. A BiPAP unit is set up with initial pressures of inspiratory positive airway pressure (IPAP) = 6 cm  $H_2O$  and expiratory positive airway pressure (EPAP) = 2 cm  $H_2O$ . These were then adjusted on the basis of pulse oximetry and

patient f. With an IPAP/EPAP ratio of 12 cm  $H_2O$  to 4 cm  $H_2O$  and a measured  $F_1O_2$  of 0.3, the patient has a rate of 25 breaths/min and  $S_pO_2$  of 87%. Vital signs,  $S_pO_2$ , and respiratory rate remain fairly stable.

Two hours later, the patient's respiratory rate has increased to 35 breaths/min. ABGs reveal pH = 7.21;  $P_aCO_2 = 105$  mm Hg;  $P_aO_2 = 47$  mm Hg; and HCO<sub>3</sub>— = 40 mEq/L. Repeated adjustments of the IPAP/EPAP ratio fail to improve the patient's condition; the decision is made to intubate him and provide him with volume-targeted ventilation. The patient is 5 ft, 8 in and weighs 148 lb (IBW = 70 kg). BSA = 1.78 m². The VC-IMV mode is selected.

What initial  $V_T$ ,  $\dot{V}_E$ , and f would you select?

After initiating mechanical ventilation, the following values are noted: PIP = 33 cm H<sub>2</sub>O; P<sub>plat</sub> = 25 cm H<sub>2</sub>O; transairway pressure (P<sub>TA</sub>) = 33 – 25 = 8 cm H<sub>2</sub>O. The patient is spontaneously breathing an additional 10 breaths/min with a V<sub>T</sub> of 200 mL. The decision is made to add pressure support for the spontaneous breaths to overcome the WOB imposed by the artificial airway.

What is an estimated resistance on this patient, assuming a constant flow of 80 L/min is used for calculation? Where would you set pressure support?

**4.** A 50-year-old patient is receiving VC-CMV after surgery for a bowel resection. He is in the recovery room. The patient has an IBW of 80 kg and a BSA of 1.8 m<sup>2</sup>. This patient's lungs are normal. What initial settings would be appropriate?

<sup>&</sup>lt;sup>b</sup>An initial attempt at bilevel PAP should be tried using NIV with IPAP = 10-12 cm  $H_2O$  and EPAP = 2-3 cm  $H_2O$  before intubation is considered. An exception would be a critical emergency with these patients.

#### References

- Mithoefer JC, Holford FD, Keighley JFH: The effect of oxygen administration on mixed venous oxygenation in chronic obstructive pulmonary disease, Chest 66:122-132, 1974.
- Mithoefer JC, Keighley JF, Karetzkey MS: Response of the arterial PO<sub>2</sub> to oxygenation administration in chronic pulmonary disease, *Ann Intern Med* 74:328–335, 1971.
- Hess DR, Kacmarek RM: Essentials of mechanical ventilation, ed 4, New York, NY, 2019, McGraw-Hill.
- Hess DR, MacIntyre NR: Mechanical ventilation. In Hess DR, MacIntyre NR, Mishoe SC, editors: Respiratory care principles and practices, ed 4, Sudbury, MA, 2020, Jones and Bartlet Learning, pp 499

  –540.
- Kacmarek RM: Initiating and adjusting invasive ventilatory support. In Kacmarek RM, Stoller JK, Heuer AJ, editors: Egan's fundamentals of respiratory care, ed 12, St Louis, MO, 2021, Mosby, pp 1072–1104.
- Jubran A, Tobin MJ: Reliability of pulse oximetry in titrating supplemental oxygen therapy in ventilator-dependent patients, *Chest* 97:1420–1425, 1990.
- Branson RD: Understanding and implementing advances in ventilator capabilities, Curr Opin Crit Care 10:23

  –32, 2004.
- Branson RD: Humidification for patients with artificial airways, Respir Care 44:630–641, 1999.
- Restrepo RD, Walsh BK: AARC clinical practice guideline: humidification during invasive and noninvasive mechanical ventilation: 2012, Respir Care 2012(57):782

  –788, 2012.
- Branson RD, Campbell RS: Humidification in the intensive care unit, Respir Care Clin N Am 4:305

  –320, 1998.
- 11. Branson RD, Campbell RS, Johannigman JA, et al.: Comparison of conventional heated humidification with a new active hygroscopic heat and moisture exchanger in mechanically ventilated patients, *Respir Care* 44:912–917, 1999.
- 12. Ari A, Fink J: Humidity and aerosol therapy. In Cairo JM: mosby's respiratory care equipment, ed 11, St Louis, MO, 2022, Elsevier.
- Shelly MP: Inspired gas conditioning, Respir Care 37:1070-1080, 1992.
- Chatburn RL: Physiological and methodological issues regarding humidity therapy, J Pediatr 114:416

  –420, 1989.
- Schultze A: Respiratory gas conditioning in infants with artificial airways, Semin Neonatol 7(5):369-377, 2002.
- Hess D: Prolonged use of heat and moisture exchangers: why do we keep changing things? Crit Care Med 28:1667–1668, 2000.
- Branson RD, Davis K, Campbell RS, et al.: Humidification in the intensive care unit: prospective study of a new protocol utilizing heated humidification and a hygroscopic condenser humidifier, *Chest* 104:1800—1805, 1993.
- Davis K, Evans SL, Campbell RS, et al.: Prolonged use of heat and moisture exchangers does not affect device efficiency or frequency rate of nosocomial pneumonia, Crit Care Med 28:1412–1418, 2000.
- Collard HR, Saint S, Matthay MA: Prevention of ventilator-associated pneumonia: an evidence-based systematic review, *Ann Intern Med* 138:494-501, 2003.
- 20. Walsh BK, Waugh JB: Alarm strategies and surveillance for mechanical ventilation, *Respir Care* 65(6):820–831, 2020.
- Scott JB, De Vaux L, Dills C, et al.: Mechanical ventilation and alarm fatigue, Respir Care 64(10):1308–1313, 2019.
- Bendixen HH, Hedley-White J, Laver MB: Impaired oxygenation in surgical patients during general anesthesia with controlled ventilation: a concept of atelectasis, N Engl J Med 269:991

  –996, 1963.
- 23. Brochard L: Pressure-limited ventilation, Respir Care 41:447-455, 1996.
- Laver MB, Morgan J, Bendixen NH, et al.: Lung volume, compliance, and arterial oxygen tensions during controlled ventilation, *J Appl Physiol* 19:725

  –733, 1964.
- Housley E, Louzada N, Becklake MR: To sigh or not to sigh, Am Rev Respir Dis 101:611

  614, 1970.
- Bergman NA: Concerning sweet dreams, health and quiet breathing [editorial], Anesthesiology 32:297—298, 1970.
- Levine M, Gilbert R, Auchincloss Jr JH: A comparison of the effects of sighs, large tidal volumes, and positive end expiratory pressure in assisted ventilation, *Scand J Respir Dis* 53:101–108, 1972.
- Colgan FJ, Marocco PP: Cardiorespiratory effects of constant and intermittent positive-pressure breathing, Anesthesiology 36:444

  –448, 1970.

- Branson RD, Campbell RS: Sighs: wasted breath or breath of fresh air? Respir Care 37:462, 1992.
- Dammann JF, McAslan TC: PEEP: its use in young patients with apparently normal lungs, Crit Care Med 7:14—19, 1979.
- 31. Sykes MK, Young WE, Robinson BE: Oxygenation during anesthesia with controlled ventilation, *Br J Anaesth* 37:314—325, 1965.
- 32. Visick WD, Fairley HB, Hickey RE: The effects of tidal volume and end-expiratory pressures on pulmonary gas exchange during anesthesia, *Anesthesiology* 19:285–290, 1973.
- Bruce RD, Stock MC, Tarras E, Hancock S: Does a sigh breath improve oxygenation in the intubated patient receiving CPAP? Respir Care 37:1409-1413, 1992.
- Acute respiratory distress syndrome network: ventilation with lower tidal volume as compared with traditional tidal volumes for acute lung injury and the acute respiratory distress syndrome, N Engl J Med 342:1301–1308, 2000.
- Amato MB, Barbas CSV, Medeiros DM, et al.: Effect of a protectiveventilation strategy on mortality in the acute respiratory distress syndrome, N Engl J Med 338:347

  –354, 1998.
- Zambon M, Vincent JL: Mortality rates for patients with acute lung injury/ARDS have decreased over time, Chest 133(5):1120-1127, 2008.
- Tobin MJ, editor: Principles and practices of mechanical ventilation, ed
   New York, NY, 2014, McGraw-Hill.
- 38. Forrette TR: Mechanical ventilators: general-use devices. In Cairo JM, editor: *Mosby's respiratory care equipment*, ed 11, St. Louis, MO, 2022, Elsevier, pp 395—429.
- ARDS Definition Task Force, Ranieri VM, Rubenfeld GD, et al.: Acute respiratory distress syndrome: the Berlin definition, *JAMA* 307:2526–2533, 2012.
- 40. Slutsky AS, Ranieri M: Ventilator-induced lung injury, N Engl J Med 369:2126—2136, 2013.
- 41. Slutsky AS: Ventilator-induced lung injury: from barotrauma to biotrauma, Respir Care 50:646—659, 2005.
- Slutsky AS: Consensus conference on mechanical ventilation. Northbrook, Ill, Jan 27.30, 1994, *Intensive Care Med* 20:64

  –79, 1994.
- Laghi F: Mechanical ventilation in chronic obstructive pulmonary disease. In Tobin MJ, editor: *Principles and practice of mechanical* ventilation, ed 3, New York, NY, 2013, McGraw-Hill, pp 741

  –759.
- Sethi JM, Siegel MD: Mechanical ventilation in chronic obstructive lung disease, Clin Chest Med 21:799—818, 2000.
- Rochwerg B, Brochard L, Elliott MW, et al.: Official ERS/ATS clinical practice guidelines: noninvasive ventilation for acute respiratory failure, Eur Respir J 50:1602426, 2017.
- 46. Demoule A, Brochard L, Dres M, et al.: How to ventilate obstructive and asthmatic patients, *Intensive Care Med* 46:2436–2449, 2020.
- Rowe BH, Edmonds ML, Spooner CH, et al.: Evidence-based treatments for acute asthma, Respir Care 46:1380—1390, 2001.
- 48. Tuxen DV, Lane S: The effects of ventilatory pattern on hyperinflation, airway pressures, and circulation in mechanical ventilation of patients with severe airflow obstruction, *Am Rev Respir Dis* 136:872–879, 1007
- Menchon MN, Palacios IE, Alapont MI: Ventilation in special situations: mechanical ventilation in status asthmaticus, An Pediatr 59:352–362, 2003.
- Rodrigo GJ, Rodrigo C, Hall JB: Acute asthma in adults: a review, Chest 125:1080–1102, 2004.
- Leatherman JW: Mechanical ventilation for severe asthma. In Tobin MJ, editor: Mechanical ventilation: principles and applications, ed 3, New York, NY, 2013, Elsevier, pp 727–739.
- 52. Bernard GR, Artigas A, Brigham KL, et al.: The American-European Consensus Conference on ARDS: definitions, mechanisms, relevant outcomes, and clinical trial coordination, *Am J Respir Crit Care Med* 149:819—824, 1994.
- Fan E, Del Sorbo L, Goligher EC, et al.: An official American thoracic society/European society of intensive care medicine/society of critical care medicine clinical practice guideline: mechanical ventilation in adult patients with acute respiratory distress syndrome, ATS/ESICM/ SCCMCP 195(9):1253—1263, 2017.
- Meade MO, Herridge MS: An evidence-based approach to acute respiratory distress syndrome, *Respir Care* 46:1368–1376, 2001.
- Sahetya SK, Goligher EC, Brower RG: Setting positive end-expiratory pressure in acute respiratory distress syndrome, Am J Respir Crit Care Med 195(11):1429–1438, 2017.

- Gattinoni L, Pelosi P, Crotti S, et al.: Pressure-volume curve of total respiratory system in acute respiratory failure, Am Rev Respir Dis 136:730-736, 1987.
- 57. Harris RS: Pressure-volume curves of the respiratory system, *Respir Care* 50:78–98, 2005.
- Marini JJ, Gattinoni L: Ventilatory management of acute respiratory distress syndrome: a consensus of two, Crit Care Med 32:250

  –255, 2004.
- Marini JJ: Mechanical ventilation in acute respiratory distress syndrome. In Tobin MJ, editor: Mechanical ventilation: principles and applications, ed 3, New York, NY, 2013, McGraw-Hill, pp 699–726.

## **Initial Patient Assessment**

#### **OUTLINE**

DOCUMENTATION OF THE PATIENT-VENTILATOR SYSTEM, 125 THE FIRST 30 MINUTES, 128

Mode, 128
Sensitivity, 129
Tidal Volume, Rate, and Minute Ventilation, 129
Correcting Tubing Compliance, 130
Alveolar Ventilation, 130

Dead Space, 130 Added Mechanical Dead Space, 130 Final Alveolar Ventilation, 130

**MONITORING AIRWAY PRESSURES, 130** 

Peak Inspiratory Pressure, 131 Plateau Pressure, 131 Set Pressure, 131 Transairway Pressure: PIP Minus P<sub>plat</sub>, 131

Mean Airway Pressure: PIP Minus P<sub>plat</sub>, 13 Mean Airway Pressure, 131 End-Expiratory Pressure, 131 Driving Pressure, 132 Pressure Limit, 133

Low-Pressure Alarm, 133

Checking the Circuit: Checking for Leaks, 133

VITAL SIGNS, BLOOD PRESSURE, AND PHYSICAL EXAMINATION OF THE CHEST, 134

Heart Rate, 134
Temperature, 135
Systemic Arterial Blood Pressure, 135
Central Venous Pressure, 135
Pulmonary Artery Pressure, 135
Physical Examination of the Chest, 135

MANAGEMENT OF ENDOTRACHEAL TUBE AND TRACHEOSTOMY TUBE CUFFS, 136

Cuff Pressure Measurement, 136 High Cuff Pressure, 138 Nonexistent or Low Cuff Pressure, 138 Cut in the Pilot Tube, 139 Tube and Mouth Care, 140

**MONITORING COMPLIANCE AND AIRWAY RESISTANCE, 140** 

Static Compliance, 140

Static Compliance, 140

Dynamic Characteristic (Dynamic Compliance), 140

Airway Resistance, 141

Bedside Measurement of Pressure-Volume Curves, 142

COMMENT SECTION OF THE VENTILATOR FLOW SHEET, 144

SUMMARY, 144

#### **KEY TERMS**

- Ascites
- Driving Pressure
- Dynamic characteristic

- Lower inflection point
- Operational verification procedure
- Patient-ventilator system check
- Upper inflection point
- Ventilator flow sheet

### LEARNING OBJECTIVES

On completion of this chapter, the reader will be able to do the following:

- Understand the importance of performing an operational verification procedure.
- State the recommended times when an oxygen analyzer is used to measure the fractional inspired oxygen concentration (F<sub>I</sub>O<sub>2</sub>) during mechanical ventilation.
- Identify various pathophysiological conditions that alter a patient's transairway pressure, peak pressure, and plateau pressure.
- Use pressure-time and flow-time curves obtained during pressure-controlled continuous mandatory ventilation to determine the plateau pressure.
- 5. Identify a system leak from a volume-time curve.
- Use physical examination and radiographic data to determine whether pneumonia, acute respiratory distress syndrome, flail chest, pneumothorax, asthma, pleural effusion, or emphysema is present.
- 7. Determine whether a lung compliance problem or an airway resistance problem is present, using the ventilator flow sheet and

- time, volume, peak inspiratory pressure, and plateau pressure
- Evaluate a static pressure—volume curve for static compliance and dynamic compliance to determine changes in compliance or resistance.
- Estimate a patient's alveolar ventilation based on ideal body weight, tidal volume, and respiratory rate.
- 10. Detect a cuff leak by listening to breath sounds.
- Recognize inappropriate endotracheal tube cuff pressures and an inappropriate tube size and recommend measures to correct these problems.
- Evaluate flow sheet information about a patient on pressure control ventilation and recommend methods for determining whether compliance and airway resistance have changed.
- Explain the technique for measuring endotracheal tube cuff pressure using a manometer, syringe, and three-way stopcock.
- 14. Describe two methods that can be used to remedy a cut pilot tube (pilot balloon line) without changing the endotracheal tube.

ssessing a patient's oxygenation status, respiratory rate, breathing pattern, use of accessory muscles, chest movement, and breath sounds, along with estimates of work of breathing (WOB) and evaluation of the patient's level of consciousness, can provide valuable information about a patient's physiological status. These observations, along with information derived from ventilator displays and hemodynamic monitoring, are among the first assessments the clinician records for a patient who is undergoing mechanical ventilation.<sup>1</sup>

This chapter reviews assessment and documentation of patient-ventilator interactions after a patient has been placed on a mechanical ventilator. The first step in this process involves verification of the physician's orders for initiating mechanical ventilator support (Box 8.1). Once the physician's orders have been verified, the respiratory therapist ensures that the designated ventilator has passed an **operational verification procedure** (OVP). The OVP process is typically described in the respiratory therapy department's policies and procedures manual.

It is important that the respiratory therapy department maintains records showing the OVP history for each ventilator. In addition, a label or form should be attached to each ventilator showing when the OVP was performed, by whom, and whether the ventilator passed the multiple-part test. Newer microprocessor-controlled ventilators are designed to perform a series of automated self-tests once the operator initiates the self-test process. This self-test record may be part of the OVP.

The equipment evaluation process should also involve checking the integrity of the ventilator circuit and humidifier system and ensuring that related equipment has been correctly attached and tested to ensure that the system is free of leaks (Box 8.2).

#### DOCUMENTATION OF THE PATIENT-VENTILATOR SYSTEM

In addition to documentation of the OVP, patient information and ventilator settings should be documented regularly when a patient

### BOX **8.1**

#### **Physician's Orders for Mechanical Ventilation**

The orders written by the physician for mechanical ventilation settings vary among institutions. In some instances the physician's orders may be specific, with little flexibility for respiratory therapist involvement. More commonly, the physician orders simply request a particular protocol for mechanical ventilation, which is then followed by the respiratory therapist, nurse, and other staff members involved with the care of the patient.<sup>2</sup>

The orders or protocol should include at least one (and preferably both) of the following:

- Desired range for the arterial CO<sub>2</sub> partial pressure (P<sub>a</sub>CO<sub>2</sub>) or end-tidal carbon dioxide partial pressure (P<sub>ET</sub>CO<sub>2</sub>), and/or for the arterial oxygen partial pressure (P<sub>a</sub>O<sub>2</sub>), arterial oxygen saturation (S<sub>a</sub>O<sub>2</sub>), oxygen saturation as measured by pulse oximetry (S<sub>p</sub>O<sub>2</sub>), or transcutaneous oxygen partial pressure (P<sub>tr</sub>O<sub>2</sub>).
- Ventilator variables to be initiated or manipulated to achieve the desired arterial blood gases (e.g., mode, tidal volume [V<sub>T</sub>], respiratory rate [f], set pressure, and fractional inspired oxygen [F<sub>1</sub>O<sub>2</sub>]) while protecting the lung.

is receiving ventilatory support. These data can be recorded on a computer software program with specific entry fields or kept as a paper record. Regardless of the form it takes, the document often is called a **ventilator flow sheet**.

The frequency of patient-ventilator system checks depends on the institution's policy. They are generally performed every 1 to 4 hours. In addition to this schedule, patient-ventilator system checks are performed as follows:

- · Before an arterial blood gas (ABG) sample is drawn
- When the physician has entered new orders
- Before hemodynamic data or bedside pulmonary function data are measured
- · After a ventilator change has been made
- If an acute change occurs in the patient's condition (such changes should be documented as soon as possible after the event)
- After a patient returns from testing (e.g., x-ray or magnetic resonance imaging [MRI])
- Whenever the ventilator's performance is questionable

It is important to recognize that **patient-ventilator system checks** represent a documented evaluation of the ventilator's function and the patient's response to ventilatory support. The following points regarding patient-ventilator system checks should be emphasized:

- Data relevant to the patient-ventilator system check are recorded on the appropriate hospital form and are part of the patient's medical record.
- The patient-ventilator system check includes observations of ventilator settings at the time of the check.
- The record should include the physician's order for mechanical ventilator settings.
- The patient-ventilator system check includes a brief narrative of the clinical observations of the patient's response to mechanical ventilation at the time of the check.

Fig. 8.1 shows a typical ventilator flow sheet used to record patient-ventilator system check data. The top of the form contains

### **80X 8.2** Simple Verification of Ventilator Operation

A simple ventilator check should be performed:

- Before connecting a patient to a ventilator for the first time.
- Before reconnecting the patient to a ventilator if the circuit has been changed or disassembled for any reason.

The operational verification procedure should also include checking the system for leaks before the patient is connected to the ventilator. To check for leaks, the operator should:

- Set the tidal volume (V<sub>T</sub>) at 500 mL, the gas flow low (e.g., 20 L/min), the maximum pressure limit high (e.g., 100 —120 cm H<sub>2</sub>O), and an inspiratory pause of 1 to 2 seconds.
- Occlude the Y-connector, cycle the ventilator, and observe the airway pressure rise and pause on the pressure manometer; if no leak is present, the circuit will hold the pressure steady.
- Change the ventilator settings to those appropriate for the patient before connecting the patient to the ventilator.
- Newer microprocessor-controlled ventilators automatically perform a test to check for leaks in the patient-ventilator circuit. This test can be performed at any time, but the patient must be disconnected from the ventilator to perform the test.

Patient Name		Medical Rec	ord Numbe	r	Date of Birth _	Age	
Physician		Diagnosis		Vent. Start Date		Vent Day	
Height	Weight	IBW	BSA	ET size	Position (to	eeth/lips/nose)	
Original Physician	Order			: Circuit Char	nge Due Date		

			_	
	Date	1		_
	Time			
	Therapist Initials			
	MODE*	4		
V	Auto-Wean Mode (on/off)			
0	V <sub>Tset</sub> /V <sub>Texh</sub>			
L	V <sub>⊤ spont</sub>			
U	Machine rate/Total rate			
М	I/E ratio (or Set T <sub>I</sub> %)(or T <sub>HI</sub> /T <sub>LO</sub> )			
E	Minute Ventilation			
	Increase V <sub>Dmech</sub> (mL)			
Р	P <sub>peak</sub> /P <sub>plat</sub>	11		
R	Compliance (V <sub>T</sub> /PIP-PEEP <sub>TOT</sub> )	1		
E	Raw [(PIP-Pplat)/flow(L/s)]			
S	IPAP/EPAP (P <sub>HI</sub> /P <sub>LO</sub> )	Ų.		
S	Mean Airway Pressure			
U	Set Pressure (PCV or PS)			
R	Set PEEP/CPAP			
E	Auto-PEEP			
	Sensitivity (P or Flow setting)			
М	F <sub>I</sub> O <sub>2</sub> (set/analyzed)			
I	Flow rate			
S	Flow waveform			
С	Insp. Rise Setting	1		
	Inspir Flow cycle			
	Automatic Tube Comp. Set (yes/no)			
	Air Temperature			
Α	Apnea Parameters Set (yes/no)			
L	Press. Limit (high/low)			
Α	Low V <sub>T</sub>			
R	V <sub>E</sub> (high/low)			
М	High Rate			
	Low PEEP			
Α	Suctioned (yes/no)			
ı	Secretion color			
			-	

Fig. 8.1 Example of a ventilator flow sheet.

R	Secretion consistency	
W	Secretion Amt. (small/mod./lg)	
Α	ET Repositioned/Taped (yes/no)	
Υ	Cuff (Press/Vol.)/Tube position	
	MLT or MOV	
	Aerosol Therapy (MDI or Neb)	
	Medication/Dose	
	pH/PaCO <sub>2</sub>	
Α	P <sub>ET</sub> CO <sub>2</sub>	
В	P <sub>a</sub> O <sub>2</sub>	
G	S <sub>p</sub> O <sub>2</sub>	
	Hb	
	HCO <sub>3</sub>	
	B.E.	
	PaO <sub>2</sub> /F <sub>I</sub> O <sub>2</sub> or PaO <sub>2</sub> /P <sub>A</sub> O <sub>2</sub>	
	$C_aO_2/C_aO_2$ - $C\bar{v}O_2$	
Н	Pulse	
E	Blood Pressure	
M	CVP	
0	PAP (sys/dys)	
	PAWP	
	C.O./C.I. (C.O./BSA)	3
	SVR	
	PVR	
S	Spontaneous rate	
Р	Spontaneous V <sub>T</sub>	
0	RSBI (f/V <sub>T</sub> [breaths/min/L])	
N	MIP (NIF)	
Т	VC	
	Time of SBT	
	COMMENTS	
М	*VC-CMV (A/C), PC-CMV (PCV),	
o	VC-SIMV; PC-SIMV	
D	VC-SIMV + PS; PC-SIMV + PSV	
Е	PRVC; APRV	
s	Spontaneous, PSV, VS, CPAP	
	BiLevel PAP	

Fig. 8.1, cont'd

basic patient information, including the patient's name and anthropometric data (e.g., age, weight, height, ideal body weight [IBW], body surface area), medical record identification number, patient's diagnosis, name of the attending physician along with the physician's orders, date of intubation, ventilator start date, and ventilator day (number of days on the ventilator).

The form will typically include spaces for entering current information about the patient and measurements of ventilator parameters. These may include the following:

- Date
- Time
- · Mode of ventilation

- Minute ventilation (V<sub>E</sub>)
- · Respiratory rate (f)
- Tidal volume (V<sub>T</sub>)
- · Peak inspiratory pressure (PIP)
- Plateau pressure (P<sub>plat</sub>)
- Static compliance (C<sub>s</sub>)
- Airway resistance (R<sub>aw</sub>)
- Fractional inspired oxygen (F<sub>I</sub>O<sub>2</sub>)
- Temperatures of inspired gases
- Inspiratory-to-expiratory ratio
- Continuous positive airway pressure (CPAP) or positive endexpiratory pressure (PEEP)
- Inspiratory and end-expiratory positive airway pressures
- Arterial blood gases (ABGs)
- Alveolar-to-arterial partial pressure of oxygen (P<sub>[A-a]</sub>O<sub>2</sub>) or ratio of arterial oxygen partial pressure to fractional inspired oxygen (P<sub>a</sub>O<sub>2</sub>/F<sub>I</sub>O<sub>2</sub>)
- Vital capacity (VC)
- · Maximum inspiratory pressure
- Vital signs
- Alarm settings

Volumes, pressures, temperature, vital signs, and  $F_1O_2$  are measured during each patient-ventilator system check. Most intensive care unit (ICU) ventilators have  $O_2$  analyzers that provide continuous monitoring of  $F_1O_2$ . In cases in which continuous  $F_1O_2$  measurements are not available on a particular ventilator, intermittent measurements of  $F_1O_2$  are usually sufficient for adult patients.  $F_1O_2$  should be continuously monitored, however, for infants receiving mechanical ventilation. Alarms should be regularly checked to ensure they have been set appropriately. ABGs, shunt fraction,  $P_{(A-a)}O_2$ , and  $P_aO_2/F_1O_2$  should be determined when the patient's condition or the ventilator settings change significantly.

Regular, accurate documentation of patient-ventilator system checks are essential for the effective use of mechanical ventilation and for maintaining patient safety.<sup>2-4</sup> Case Study 8.1 provides a clinical scenario illustrating the importance of maintaining accurate patient-ventilator records.



#### Case Study 8.1

#### The Importance of Documentation

A 38-year-old woman is intubated for respiratory failure secondary to severe pneumonia. After 24 hours her status improves. The endotracheal tube is kept in place to allow suctioning, because she has large amounts of secretions. On the third day after intubation, her respiratory status declines. She has a cardiac arrest and is resuscitated but suffers brain injury as a result. She dies several weeks later.

The family hires an attorney. At issue is the fact that in the medical record, the respiratory therapist's notes with the ventilator flow sheet indicate that the patient had been suctioned about every 2 hours for large amounts of thick, yellow secretions. However, during the 8 hours before the arrest, nowhere did the notes state that the patient had been suctioned. The therapist states that he had suctioned the patient but had not recorded it in the chart. Was the therapist negligent and did his actions lead to the wrongful death of the patient?

**Key Point 8.1** Positive pressure ventilation can reduce venous return to the heart, cardiac output, and blood pressure. (See Chapter 16 for more information on the cardiovascular effects of mechanical ventilation.)

#### THE FIRST 30 MINUTES

Immediately after the patient is connected to a mechanical ventilator, the clinician should perform auscultation of the patient's chest to confirm adequate volume delivery and proper placement of the endotracheal tube (ET). The patient's vital signs are checked, making particular note of heart rate and blood pressure, because mechanical ventilation may affect these parameters (Key Point 8.1). The alarms (e.g., apnea, low pressure, low V<sub>T</sub>, and high pressure limit) are activated. An arterial blood sample is obtained about 15 minutes after mechanical ventilation is initiated for evaluation of the effectiveness of ventilation and oxygenation. If not already done, a chest radiograph is obtained to confirm proper placement of the ET. Box 8.3 lists other clinical laboratory tests a physician might order to assess the patient's status when mechanical ventilation is initiated.

Once the patient assessment shows the individual is stable, the respiratory therapist then performs the first ventilator check.

#### Mode

The mode of ventilation is recorded in the appropriate space on the ventilator flow sheet. It may be recorded as follows:

- Volume-controlled continuous mandatory ventilation (VC-CMV)
- Pressure-controlled continuous mandatory ventilation (PC-CMV)
- Intermittent mandatory ventilation (IMV), using either volume-controlled ventilation (VC-IMV) or pressurecontrolled ventilation (PC-IMV), with or without pressure support ventilation (PSV)
- Pressure-regulated volume control (PRVC)\*
- Airway pressure release ventilation (APRV)
- PSV, volume support (VS), CPAP, unsupported spontaneous ventilation (these are spontaneous modes)
- Bilevel positive airway pressure (bilevel PAP; noninvasive positive pressure ventilation [NIV])


### BOX **8.3**

# **Clinical Laboratory Tests for Initial Assessment**

The following clinical laboratory tests may be included in the initial evaluation of the patient:

- Complete blood count
- Blood chemistries (glucose, sodium, potassium, chloride, CO<sub>2</sub>, blood urea nitrogen, creatinine, phosphate, magnesium)
- Prothrombin time, partial thromboplastin time, international normalized ratio (PT/PTT/INR), and platelet count
- · Blood, sputum, and urine cultures

<sup>\*</sup>Other names associated with this mode include *AutoFlow* (Dräger V500) and *VC*+ (Medtronics Puritan Bennett 840 and 980 ventilators).



**Fig. 8.2** Measurement of tidal volume (VT) at the endotracheal tube (ET). The respirometer is attached to the ET so that the patient's actual exhaled air can be measured. The respirometer can also be attached at the exhalation valve, but those readings would include compressible volume from the ventilator circuit in addition to volume from the patient's lungs.

#### **Sensitivity**

If a patient-triggered mode is used (i.e., inspiration is initiated by patient effort), the pressure or flow required to trigger the ventilation should be checked; no more than -1 or -2 cm  $H_2O$  should be required. If the ventilator is flow triggered, the sensitivity should be set so that the ventilator will trigger at a flow change of 2 to 3 L/min. The ventilator should be checked for autotriggering, and the patient's ability to trigger a breath should be assessed. Adjustments are made as needed.

As discussed previously, when auto-PEEP is present, the patient has more difficulty triggering breaths. The presence of auto-PEEP should be suspected if the patient is using his accessory muscles of inspiration or demonstrates labored breathing. Ventilator graphics that show failure of the expiratory flow to return to zero before the next breath are also an indicator of auto-PEEP (see Chapter 9).

If auto-PEEP is present, a number of strategies can be used to reduce its effects, including increasing the flow (reducing the inspiratory time  $[T_I]$ ), reducing  $V_T$ , or reducing the rate [i.e., reducing  $\mathring{V}_E$ ]), suctioning the patient, or changing modes to allow for more spontaneous breaths. It is important to recognize that it may not always be possible to eliminate auto-PEEP, particularly in patients with increased flow resistance and airway closure. The addition of extrinsic PEEP (PEEP\_E) in these cases may make triggering easier (see Fig. 7.1). PEEP\_E is increased progressively during VC-CMV until the patient's use of accessory muscles diminishes or until PIP and  $P_{plat}$  begin to rise. (Additional information about treatment of auto-PEEP can be found in Chapter 17.)

#### Tidal Volume, Rate, and Minute Ventilation

 $V_T,\,f,$  and  $\dot{V}_E$  are typically displayed digitally on the front panel of the ventilator in the data display window. Most ventilators display the set  $V_T$  ( $V_{Tset}$ ) and the exhaled  $V_T$  ( $V_{Texh}$ ). Newer microprocessor-controlled ventilators provide excellent, reliable flow and pressure monitoring. If this information is not available,

BOX **8.4** 

# Respirometer Technique for Measuring Tidal Volume (VT) and Minute Ventilation (VE)

Modern microprocessor-controlled ventilators provide digital displays for the clinician to monitor a patient's tidal volume and minute ventilation. Before the introduction of these devices, clinicians typically relied on handheld respirometers to measure these variables. The procedure for measuring  $V_T$  and  $\dot{V}_F$  with a respirometer is relatively easy to accomplish.

- The respirometer is connected directly to the patient's endotracheal tube and Y-connector of the ventilator circuit (see Fig. 8.2). This allows easy measurement of the V<sub>T</sub> that does not have to be corrected for compressible volume from the ventilator circuit. (NOTE: In cases in which the V<sub>T</sub> was measured at the expiratory port, the compressible volume [volume lost to C<sub>T</sub>] must be subtracted from the V<sub>T</sub> reading on the respirometer.)
- Gas exhaled from the lungs is measured for 1 minute, and the f is simultaneously counted.  $\dot{V}_E$  can be calculated ( $\dot{V}_E = V_T \times f$ ) or measured directly. If the patient is receiving intermittent mandatory ventilation (IMV), the total  $\dot{V}_E$  is measured. Mandatory  $V_T$  and f can be measured separately, and mandatory  $\dot{V}_E$  can be subtracted from the total  $\dot{V}_E$  to determine a patient's spontaneous  $\dot{V}_E$ .

 $V_T$  can be measured using a handheld bedside pulmonary function device or other volume-measuring device (e.g., respirometer) and a watch or clock with a sweep second hand. Although this technique is generally used only with older ventilators, it can also be used to verify digital readouts if a question arises about the machine's reliability (Fig. 8.2 and Box 8.4).

#### **Correcting Tubing Compliance**

Accurate reporting of volumes requires correction for volume loss within the patient circuit because of the effects of tubing compliance (also called *compressible volume*). As discussed in Chapter 6, tubing compliance ( $C_T$ ) for most ventilator circuits ranges from about 1.5 to 2.5 mL/cm  $H_2O$ .

Most microprocessor-controlled ventilators (e.g., Medtronics Puritan Bennett 840 [Medtronics Minimally Invasive Therapies], Servo-i [Getinge, Göteborg, Sweden]) do not require calculation of tubing compliance because these machines automatically compensate for this factor. As discussed previously, ventilators that perform this function typically increase the delivered volume so that the set volume is the amount provided to the patient (i.e., the digital readout indicates the  $V_T$  actually delivered to the patient's airway). With older ventilators, the operator can set the value for the circuit's  $C_T$  and the ventilator will add volume to the  $V_{Tset}$  to compensate for volume loss because of tubing compliance.

#### **Alveolar Ventilation**

Monitoring of alveolar ventilation ( $\mathring{V}_A$ ) has declined in popularity in recent years because many acute care facilities do not include this variable on the ventilator flow sheet. Unfortunately, its importance is often overlooked when using low  $V_T$  strategies. Inline heat-moisture exchangers (HMEs), closed suction systems, and other circuit adapters and equipment can add mechanical dead space ( $V_{Dmech}$ ) to the ventilator circuit and affect the  $V_D/V_T$ . Knowledge of the effect of dead space on alveolar volume delivery can be particularly important in infants, children, and smaller adults with acute respiratory distress syndrome (ARDS).\*

The following two factors must be considered in determining alveolar ventilation:

- 1. Anatomical dead space
- 2. Mechanical dead space

#### **Dead Space**


Normal anatomical dead space ( $V_{Danat}$ ) is about 1 mL/lb IBW. Bypassing the upper airway with an artificial airway reduces  $V_{Danat}$  by about half. Using a Y-connector, additional flex tubing between the Y-connector and the ET, or an HME adds mechanical dead space.

#### Added Mechanical Dead Space

Because HMEs or other adapters attached to the ET (Fig. 8.3) add to  $V_{\rm Dmech}$ , the volume of these devices, along with the  $V_{\rm Danat}$ , must be subtracted from the  $V_T$  to determine actual alveolar ventilation (Box 8.5). For example, if a 150-lb adult has a  $V_T$  of 500 mL and the added  $V_{\rm Dmech}$  is 100 mL, the alveolar ventilation for each breath would be:

$$VT - V_{Dmech} - V_{Danat} = 500mL - 100 - 150mL = 250mL$$
 (Key Point 8.2)

**Key Point 8.2** The volume of mechanical dead space can be easily measured for any device added to a ventilator circuit. The device is simply filled with water and then emptied into a graduated container; the volume measured is the volume of mechanical dead space for the device. (A piece of equipment [i.e., tubing] similar to that being placed on the patient should be used for this type of measurement.)



**Fig. 8.3** Airway pressure waveform during volume control ventilation. An endinspiratory breath hold and an end-expiratory breath hold are applied to measure the plateau pleasure and auto-PEEP, respectively. Note the difference between the peak inspiratory pressure (PIP) and plateau pressure ( $P_{plat}$ ); this is the transairway pressure ( $P_{TA}$ ), which is produced by the interaction of the set flow and airway resistance. The  $V_T$  is the product of the pressure difference between  $P_{plat}$  and total PEEP (set PEEP and auto-PEEP) and lung compliance. (From Hess DR, MacIntyre NR, Mishoe SC, et al: *Respiratory care principles and practice,* Philadelphia, PA, 2002, WB Saunders.)

### BOX **8.5** A

#### **Added Mechanical Dead Space**

Some patient situations require the addition of a small amount of mechanical dead space. For example, in Fig. 7.3 a small circuit has been added at the Y-connector to allow for intermittent use of a metered-dose inhaler (MDI) without removing the heat and heat-moisture exchanger (HME) or disconnecting the circuit.

Excessive turbulence at the upper airway and Y-connector can sometimes produce a pressure spike at the beginning of a breath during pressure-targeted ventilation. This has been noted with Vyaire LTV-1000 ventilator in a clinical situation. Autotriggering occasionally occurs in this same ventilator. These two phenomena can be prevented in most cases by adding about 2 inches of corrugated tubing between the Y-connector and endotracheal tube (or between the HME and the endotracheal tube) but must be accounted for as additional V<sub>Dmech</sub>.

#### **Final Alveolar Ventilation**

During VC-CMV (A/C),  $\dot{V}_A$  is calculated by multiplying the number of breaths counted for 1 minute by the corrected  $V_T$ :  $\dot{V}_A = (V_T - V_{Danat} - \text{Added } V_{Dmech}) \times f$ . When a patient is on VC-IMV, the mandatory rate and volume delivery must be calculated separately from the patient's spontaneous rate and volume; these values are then added to determine the total  $\dot{V}_E$  (Box 8.6).

#### **MONITORING AIRWAY PRESSURES**

All positive pressure ventilators have a pressure monitor or display that continuously shows the upper airway pressure. The pressure monitor is probably most accurate when it shows pressures

<sup>\*</sup>Physiological dead space is reviewed in Appendix B.