

Note A: for proper boot up D3 and D4 at the ESP8266 module must be held high.

This can be accomplished by leaving them UNCONNECTED even though they are fed by an OpAmp on the PCB.

This allows a V1 Version of the PCB to be used for the basket target -- although for other targets, V1 cannot be used.