


Product Layout

Wireless PTT






The Up Key and Down Key can be programmed to Volume Control keys or Channel Selector keys. For details, consult your dealer.



Charger



LED Indicator

| LED Indication | | Description |
|----------------|------------------------|--|
| Blue | Flashes for 4 times | The product is being turned on. |
| | On | The BT is pairing. |
| | Flashes twice every 3s | The wireless connection is established, but no voice is being transmitted. |
| | Flashes once every 1s | The wireless connection is established, and voice is being transmitted. |
| | Flashes once every 3s | The wireless connection is not established. |



| LED Indication | | Description |
|----------------|---|---|
| Red | Flashes for 4 times | The product is being turned off (BT not connected). |
| | Flashes 2 times, and then flashes 3 times after 1s stop | The product is being turned off (BT connected). |
| | Flashes once every 3s | The battery is low. |
| | Flashes once every 1s | The product is being charged. |
| | On | The product is transmitting. |
| Green | On | The product is fully charged. |

Specifications

| Item | Specification |
|----------------------------------|----------------|
| Communication Distance | 10 m |
| Battery Life (5-5-90 Duty Cycle) | 120 h |
| Battery Capacity | 33mAh |
| Charging Time | 1.5 h |
| Dust & Water Protection | IP67 |
| Operating Temperature | −20°C to +60°C |
| Storage Temperature | −40°C to +85°C |




Charging the Product



- Turn off the product and get it fully charged if it stays idle for a long time. Charge it every three months to prolong its lifespan.
- Turn off the product before charging; otherwise, it will be reset and turned off automatically.

The LED indicator flashes once every 3s, indicating that the battery is low. To charge the product, do as follows:





After the product is fully charged, go through the steps reversely to remove it.



Wearing the Wireless PTT

Adjust the ring belt to fit your finger and wear it.

Basic Operations

Turning the Product On or Off

To turn on the product, press and hold both **Up** Key and **Down** Key simultaneously until the LED indicator flashes blue rapidly.

To turn off the product, press and hold both **Up** Key and **Down** Key simultaneously until the LED indicator flashes red rapidly.



If the product does not establish wireless connection within five minutes, it will be turned off automatically.



Pairing the Product

The product can work properly only when it is paired with the wireless audio adapter or the radio with BT module.

After initial pairing, whenever you turn on the product, the connection will be automatically established.

To enter paring mode:

- For Wireless Ring PTT: press and hold both **Up** Key and **Down** Key until the LED indicator flashes blue.
- For wireless audio adapter or radio with BT module: refer to corresponding User Manual for details.
 The LED indicator flashes blue, indicating that the wireless connection is established.



- The product will exit if the connection is not established three minutes after entering pairing mode.
- The product will always pair with the last connected wireless audio adapter or radio.

Making a call

To make a call, press and hold the **PTT** key, and then speak into the microphone on the audio device. Release the **PTT** key when finished.