

USER MANUAL

MASTER-APRS


Wi-Fi built in, beacons your position to APRS-IS around the clock.

SETUP WI-FI NETWORK

Wi-Fi	**MASTER-APRS Wx**
Password	**mastersetup**
Open	**192.168.4.1**

Setup

1. Power on the MASTER-APRS dongle. It creates its own setup Wi-Fi network using the details above.
2. Connect your phone to that network, then open 192.168.4.1 in a browser.
3. Enter your home Wi-Fi name and password so it can get online.
4. Enter your callsign and an APRS-ID (for example, 3 forms NOCALL-3), plus your APRS-IS passcode.
5. Pick an APRS icon and, if you'd like, set a custom beacon comment.
6. Tap Save & Reboot. It connects and starts beaconing your position to aprs.fi.



The configuration page at 192.168.4.1.

Not showing up on aprs.fi yet? Give it a couple of minutes, then search for your callsign with its APRS-ID.

Need help? Message me.
Scan the code to message me on WhatsApp.
+91 73884 07388
vu2rcy+social@gmail.com
vu2rcy.com/products/master-aprs