

iDynTree: Free Floating Dynamics Library

Silvio Traversaro

iCub Facility

Istituto Italiano di Tecnologia, Genova, Italy

Loading model

Models can be built programmatically but typically are loaded from **URDF** files (the same robot description format used in **ROS**).

As sometimes we are not interested in all joints contained in a robot, we can explicitly specify the **joints** that we want to load, and their order, using the **iDynTree::ModelLoader** class.

From this class, you obtain a iDynTree::Model that contain the structure and the parameters of the model, that you can pass to iDynTree::KinDynComputations that

```
ModelLoader mdlLoader:
std::vector<std::string> joints; // specify the used joints
joints.push back("torso pitch");
joints.push back("r wrist pitch");
mdlLoader.loadReducedModelFromFile("./model.urdf", joints);
Model model = mdlLoader.model();
KinDynComputations kinDynComp;
kinDynComp.loadRobotModel(mdlLoader.model());
// You can now use the kinDynComp object to compute terms
// of the dynamics equations, transformation between
// frames, jacobians
```

Caveat on iDynTree <--> YARP integration

- Conversion utilities between YARP and iDynTree are available in the <iDynTree/yarp/YARPConversions.h> header.
- **iDynTree** uses *radians* for all its interfaces, **YARP** typically uses *degrees*.
- **iDynTree** assume in input and in output always *floating base quantities*, you will need to do to the appropriate conversions if you want to use them for **fixed base robots** control.

• See the **impedance_control-tutorial** for more on this!