
GRAND CHALLENGE - 2025

Verilog IP Integration with Shakti SoC



DEVELOPED BY :
SHAKTI DEVELOPMENT TEAM @ IITM
SHAKTI.ORG.IN

0.1 Proprietary Notice **3**
0.2 Release Information **4**
Introduction **5**
Integration of IP supports AXI4 **5**
Integration of IP supports AXI4 Lite **9**
Steps to add external interrupts from Verilog IP **13**
Steps to include the Verilog files and run **15**

0.1 Proprietary Notice

Copyright © 2025, **SHAKTI@IIT Madras**.All rights reserved.
Information in this document is provided “as is,” with every effort ensuring that the documentation is as accurate as possible.

SHAKTI@IIT Madras expressly disclaims all warranties, representations, and conditions of any kind, whether express or implied, including, but not limited to, the implied warranties or conditions of merchantability, fitness for a particular purpose and non-infringement.

SHAKTI@IIT Madras does not assume any liability rising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation indirect, incidental, special, exemplary, or consequential damages.

SHAKTI@IIT Madras reserves the right to make changes without further notice to any products herein.

The project was funded by Ministry of Electronics and Information Technology (MeitY), Government of India

0.2 Release Information

Version	Date	Updates	Reviewed by
1.0	16/09/2025	Vignesh K	Kotteeswaran E
2.0	06/10/2025	Poovarasan M	Kotteeswaran E
Draft V.1	07/10/2025	Poovarasan M	Kotteeswaran E

Introduction

This document details the step by step procedure to integrate the **Custom Verilog IP** with Shakti. Any IP that supports AXI4/AXI4 Lite interface will be integrated at fpga_top level. IP should have the AXI4/AXI4 Lite slave interface which will be integrated with the AXI4/AXI4 Lite Master interface of Shakti SoC.

The files specified in this document are present in the gc2025/hw/boards/arty_a7_ganga/ directory. Compare the images with the original content of files to observe the changes. The same steps will be applicable to the integration of custom Verilog IP with Yamuna SoC also, but the changes alone should be made in gc2025/hw/boards/arty_a7_yamuna/ directory.

To integrate the IP operates at higher frequency AXI4 interface [Fast Fabric] will be used, whereas for IP operates at lower frequency AXI4 Lite interface [Slow Fabric] can be used.

This document will have following four sections, the third and fourth section will be common to first and second,

1. Integration of IP supports AXI4.
2. Integration of IP supports AXI4 Lite.
3. Steps to add external interrupts from Verilog IP.
4. Steps to include the verilog files and run.

Note: The highlighted lines in the following images will indicate the changes. The line numbers shown in the images might not match exactly.


Integration of IP supports AXI4

File: “gc2025/hw/boards/arty_a7_ganga/Soc.defines”


Step 1: Increment the “Num_Fast_Slaves” by 1

```
26  `ifdef simulate
27    `define Num_Fast_Slaves 8
28  `else
29    `define Num_Fast_Slaves 7
30  `endif
31  `define Memory_slave_num 0
32  `define Clint_slave_num 1
33  `define Debug_slave_num 2
34  `define FastErr_slave_num 3
35  `define Slow_fabric_slave_num 4
36  `define Boot_slave_num  5
37  `ifdef simulate
38    `define Sign_slave_num 6
39  `endif
```

Step 2: Add "**`define AXI4_slave_num *n***" (replace the *n* by the last slave number - 1) and increment the Sign_slave_num number by 1.



Step 3: Add "**`define AXI4Base *addr1**" and "**`define AXI4End *addr2**" . Define *addr1 and *addr2 such that it does not conflict with other slave addresses.



These are the 3 steps that need to be done in the "Soc.defines" file.

File: “gc2025/hw/boards/arty_a7_ganga/Soc.bsv”

Step 1: Add the decoding logic for “**AXI4_slave_num**” selection.

```
74  function Bit#(TLog#(`Num_Fast_Slaves)) fn_slave_map_fast (Bit#(`paddr) addr);
75    Bit#(TLog#(`Num_Fast_Slaves)) slave_num = 0;
76    if(addr >= `MemoryBase && addr<= `MemoryEnd)
77      slave_num = `Memory_slave_num;
78    else if(addr >= `ClintBase && addr <= `ClintEnd)
79      slave_num = `Clint_slave_num;
80  `ifdef debug
81    else if(addr >= `DebugBase && addr <= `DebugEnd)
82      slave_num = `Debug_slave_num;
83  `endif
84    else if(addr >= `BootBase && addr <= `BootEnd)
85      slave_num = `Boot_slave_num;
86    else if(addr >= `AXI4Base && addr <= `AXI4End)
87      slave_num = `AXI4_slave_num;      You, 4 days ago • Uncommitted changes
88    else if(addr >= `SlowBase && addr <= `SlowEnd)
89      slave_num = `Slow_fabric_slave_num;
90    else if(addr >= `PLICBase && addr <= `PLICEnd)
91      slave_num = `Slow_fabric_slave_num;
92  `ifdef simulate
93    else if(addr >= `SignBase && addr <= `SignEnd)
94      slave_num = `Sign_slave_num;
95  `endif
96    else
97      slave_num = `FastErr_slave_num;
98
99    return slave_num;
100 endfunction:fn_slave_map_fast
```

Step 2: Declare the “**AXI4_Master_IFC**” interface inside the “**Ifc_chip_io**” interface.

```
122 interface Ifc_chip_io;
123   interface Ifc_sspi_io spi0_io;
124   interface RS232 uart0_io;
125   method I2C_out i2c0_out;                    //I2c IO interface
126   (*always_ready, always_enabled*)
127   // interface AXI4_Lite_Master_IFC#(`paddr, 32, 0) xadc_master;
128   interface AXI4_Master_IFC#(`paddr, ELEN, 0) axi4_master;
129   interface AXI4_Lite_Master_IFC#(`paddr, 32, 0) eth_master;
130   interface AXI4_Master_IFC#(`paddr, ELEN, 0) mem_master;
131   interface IOCellSide iocell_io;
```

Step 3: Connect the declared AXI4_Master_IFC with name "**axi4_master**" to the AXI4 fast fabric.

```
651     interface iocell_io = mixed_cluster.pinmuxtop_iocell_side;
652 //    interface xadc_master = mixed_cluster.xadc_master;
653     interface axi4_master = fabric.v_to_slaves[`AXI4_slave_num];
654     interface eth_master = slow_fabric.v_to_slaves[`Eth_slave_num];
655     interface mem_master = fabric.v_to_slaves [`Memory_slave_num];
656     method Action ext_interrupts(Bit#(2) i);
657       wr_ext_interrupts <= i;
658     endmethod
659   endinterface;
660
661   endmodule: mkSoc
662 endpackage: Soc
```

File: "gc2025/hw/boards/arty_a7_ganga/fpga_top.v"

Step 1: Initialise the ports and wires that are required and part of your IP. Refer to the AXI ethernet lite IP of Xilinx as an example.

Step 2: In the mkDebugSoc instantiation, connect the wires from your IP's AXI4 slave interface to the AXI4 Master interface (**axi4_master**) of Shakti SoC.

```
594     // AXI4 Master interface to be connected to Verilog IP
595     .axi4_master_AWVALID(),
596     .axi4_master_AWADDR (),
597     .axi4_master_AWPROT (),
598     .axi4_master_AWLEN  (),
599     .axi4_master_AWSIZE (),
600     .axi4_master_AWBURST(),
601     .axi4_master_AWID   (),
602     .axi4_master_WVALID (),
603     .axi4_master_WDATA  (),
604     .axi4_master_WSTRB  (),
605     .axi4_master_WLAST  (),
606     .axi4_master_WID    (),
607     .axi4_master_BREADY (),
608     .axi4_master_ARVALID(),
609     .axi4_master_ARADDR (),
610     .axi4_master_ARPROT (),
611     .axi4_master_ARLEN  (),
612     .axi4_master_ARSIZE (),
613     .axi4_master_ARBURST(),
614     .axi4_master_ARID   (),
615     .axi4_master_RREADY (),
616     .axi4_master_AWREADY(),
617     .axi4_master_WREADY (),
618     .axi4_master_BVALID (),
619     .axi4_master_BRESP  (),
620     .axi4_master_BID    (),
621     .axi4_master_ARREADY(),
622     .axi4_master_RVALID (),
623     .axi4_master_RRESP  (),
624     .axi4_master_RDATA  (),
625     .axi4_master_RLAST  (),
626     .axi4_master_RID    (),      You, 23 minutes ago • Uncomm
```


File: “gc2025/hw/boards/arty_a7_ganga/constraints.xdc”

Step 1: Add the initialized ports in the fpga_top with the appropriate mapping in the “**constraints.xdc**” file.


Integration of IP supports AXI4 Lite

File: “gc2025/hw/boards/arty_a7_ganga/Soc.defines”


Step 1: Increment the “MixedCluster_Num_Slaves” by 1



Step 2: Add “**`define AXI4Lite_slave_num *n***” (replace the *n* by the last slave number - 1) and increment the MixedCluster_err_slave_num number by 1.



Step 3: Add “**`define AXI4LiteBase *addr1**” and “**`define AXI4LiteEnd *addr2**” . Define *addr1 and *addr2 such that it does not conflict with other slave addresses.



File: “gc2025/hw/boards/arty_a7_ganga/mixed_cluster.bsv”

Step 1: Add the decoding logic for “**AXI4Lite_slave_num**” selection.

```
104   function Bit#(TLog#(`MixedCluster_Num_Slaves)) fn_slave_map (Bit#(`paddr) addr);
105     Bit#(TLog#(`MixedCluster_Num_Slaves)) slave_num = 0;
106     if(addr>= `GPIOBase && addr<= `GPIOEnd)
107       slave_num = `GPIO_slave_num;
108     else if(addr>= `PLICBase && addr<= `PLICEnd)
109       slave_num = `PLIC_slave_num;
110   //    else if(addr>= `I2C1Base && addr<= `I2C1End)
111   //      slave_num = `I2C1_slave_num;
112     else if(addr>= `I2C0Base && addr<= `I2C0End)
113       slave_num = `I2C0_slave_num;
114     else if(addr>= `GPTimer0Base && addr<= `GPTimer0End)
115       slave_num = `GPTimer0_slave_num;
116     else if(addr>= `GPTimer1Base && addr<= `GPTimer1End)
117       slave_num = `GPTimer1_slave_num;
118     else if(addr>= `AXI4LiteBase && addr<= `AXI4LiteEnd)      You, 2 seconds ago •
119       slave_num = `AXI4Lite_slave_num;
120     else if(addr >= `PinmuxBase && addr <= `PinmuxEnd)
121       slave_num = `Pinmux_slave_num;
122     else
123       slave_num = `MixedCluster_err_slave_num;
124
125     return slave_num;
126   endfunction:fn_slave_map
```

Step 2: Declare the “**AXI4_Lite_Master_IFC**” interface inside the “**Ifc_mixed_cluster**” interface.

```
49    interface Ifc_mixed_cluster;
50      interface AXI4_Lite_Master_IFC#(`paddr, 32, 0) axi4lite_master;
51      method I2C_out i2c0_out;                    //I2c IO interface
52    //    method I2C_out i2c1_out;
53      (*always_ready,always_enabled*)
54      interface Ifc_gptimer_io gptimer0_io;
```

Step 3: Connect the declared AXI4_Lite_Master_IFC with name “**axi4lite_master**” to the AXI4 Lite slow fabric.

```
191     interface pinmuxtop_iocell_side = pinmuxtop.pinmuxaxi4lite_iocell_side;
192     interface pinmuxtop_peripheral_side = pinmuxtop.pinmuxaxi4lite_peripheral_side;
193     interface slave= c2s_xactor.axi_side;
194     interface axi4lite_master = fabric.v_to_slaves[`AXI4Lite_slave_num];      You, 5
195   //    interface xadc_master = fabric.v_to_slaves[`XADC_slave_num];
196   endmodule
197 endpackage
198
```

File: “gc2025/hw/boards/arty_a7_ganga/Soc.bsv”

Step 1: Declare the “**AXI4_Lite_Master_IFC**” interface inside the “**Ifc_chip_io**” interface.

```
122   interface Ifc_chip_io;
123     interface Ifc_sspi_io spi0_io;
124     interface RS232 uart0_io;
125     interface AXI4_Lite_Master_IFC#(`paddr, 32, 0) axi4lite_master;
126     method I2C_out i2c0_out;                    //I2c IO interface
```

Step 2: Route the “**axi4lite_master**” interface from “**mixed_cluster**” to “**Soc**”

```
653 //    interface xadc_master = mixed_cluster.xadc_master;
654     interface axi4lite_master = mixed_cluster.axi4lite_master;
655     interface axi4_master = fabric.v_to_slaves[`AXI4_slave_num];
656     interface eth_master = slow_fabric.v_to_slaves[`Eth_slave_num];
657     interface mem_master = fabric.v_to_slaves [`Memory_slave_num];
658     method Action ext_interrupts(Bit#(2) i);
659       wr_ext_interrupts <= i;
660     endmethod
661   endinterface;
662
663   endmodule: mkSoc
664 endpackage: Soc
```

File: “gc2025/hw/boards/arty_a7_ganga/fpga_top.v”

Step 1: Initialise the ports and wires that are required and part of your IP. Refer to the AXI ethernet lite IP of Xilinx as an example.

Step 2: In the mkDebugSoc instantiation, connect the wires from your IP’s AXI4 Lite slave interface to the AXI4 Lite Master interface (**axi4lite_master**) of Shakti SoC.

```
// AXI4 Lite Master interface to be connected to Verilog IP
.axi4lite_master_awvalid(),
.axi4lite_master_awaddr (),
.axi4lite_master_awprot (),
.axi4lite_master_awsize (),
.axi4lite_master_wvalid (),
.axi4lite_master_wdata  (),
.axi4lite_master_wstrb  (),
.axi4lite_master_bready (),
.axi4lite_master_arvalid(),
.axi4lite_master_araddr (),
.axi4lite_master_arprot (),
.axi4lite_master_arsize (),
.axi4lite_master_rready (),
.axi4lite_master_m_awready_awready(),
.axi4lite_master_m_wready_wready  (),
.axi4lite_master_m_bvalid_bvalid  (),
.axi4lite_master_m_bvalid_bresp   (),
.axi4lite_master_m_arready_arready(),
.axi4lite_master_m_rvalid_rvalid  (),
.axi4lite_master_m_rvalid_rresp   (),
.axi4lite_master_m_rvalid_rdata   (),
```

File: “gc2025/hw/boards/arty_a7_ganga/constraints.xdc”

Step 1: Add the initialized ports in the fpga_top with the appropriate mapping in the “**constraints.xdc**” file.

Steps to add external interrupts from Verilog IP


Let assume the Verilog IP generates interrupt, which will be serviced by Shakti SoC through PLIC controller.

File: “gc2025/hw/boards/arty_a7_ganga/fpga_top.v”

Step 1: Increment the width of the wire named “**interrupts**” by 1.




Step 2: Pass the interrupt [for e.g. wire “**verilog_ip_intr**”] from the Verilog IP to the “**interrupts**” at the incremented width position.




File: “gc2025/hw/boards/arty_a7_ganga/Soc.bsv”

Step 1: Increment the width of the method “**ext_interrupts**” by 1 in declaration.



Step 2: Increment the width of the wire “**wr_ext_interrupts**” by 1.



Step 3: Increment the width of the method “**ext_interrupts**” by 1 in instantiation.

```
658     method Action ext_interrupts(Bit#(3) i);
659       wr_ext_interrupts <= i;
660     endmethod      You, 2 months ago • combini
661   endinterface;
662
663   endmodule: mkSoc
664 endpackage: Soc
```

File: “gc2025/hw/boards/arty_a7_ganga/mixed_cluster.bsv”

Step 1: Increment the width of the method “**interrupts**” by 1 in declaration.

```
61    interface PeripheralSide pinmuxtop_peripheral_side;
62    (*always_ready, always_enabled*)
63    method Action interrupts(Bit#(14) inp);      You, 3
```

Step 2: Increment the width of the wire “**wr_external_interrupts**” by 1.

```
149   Wire#(Bit#(14)) wr_external_interrupts <- mkDWire('d0);
150   Wire#(Bit#(2)) wr_sb_ext_interrupt <- mkDWire(0);
151
```

Step 3: Increment the width of the method “**interrupts**” by 1 in instantiation.

```
188   method Action interrupts(Bit#(14) inp);      You, 10 sec
189     wr_external_interrupts<= inp;
190   endmethod
```

Step 4: Increment the number of sources by 1 in the PLIC module “**mkplic**” instantiation.

```
91  (*synthesize*)
92  module mkplic(Ifc_plic_axi4lite#(`paddr, 32, 0, 36, 2, 7));
93    let ifc();
94    mkplic_axi4lite#(`PLICBase) temp(ifc);
95    return ifc;
96  endmodule
```

Step 5: Increment the width by 1 in the "**plic_inputs**" which will be the sources for PLIC. The ordering is rearranged in the way that the existing Interrupts IDs assigned to the peripherals remains unchanged.

```
158   rule rl_connect_plic_connections;
159     let tmp <- gpio.sb_gpio_to_plic.get;
160     Bit#(16) lv_gpio_intr= truncate(pack(tmp));
161     Bit#(36) plic_inputs= {wr_external_interrupts[11], wr_external_interrupts
        [13:12],wr_external_interrupts[10:6], 1'b0, i2c0.isint, 2'b0, gptimer1.
        sb_interrupt, gptimer0.sb_interrupt, lv_gpio_intr, wr_external_interrupts[5:0]};
162     plic.sb_frm_sources(plic_inputs);
163   endrule
```

Steps to include the Verilog files and run

Step 1: Create the directory "**ip_verilog**" to place all the verilog files of your IP inside that

$ git clone https://gitlab.com/shaktiproject/gc2025.git
$ cd gc2025/hw
$ mkdir ip_verilog
$ cp -r your_dir/* ip_verilog/

File: "gc2025/hw/Makefile"
Step 2: Add the following lines in the "**Makefile**"

```
181 .PHONY: generate_verilog
182 generate_verilog: $(BSVBUILDDIR)/$(TOP_BIN)
183     @cp ${BS_VERILOG_LIB}/../Verilog.Vivado/RegFile.v ${VERILOGDIR}
184     @cp ${BS_VERILOG_LIB}/../Verilog.Vivado/BRAM2BELoad.v ${VERILOGDIR}
185     @cp ./ip_verilog/* ${VERILOGDIR}        You, 2 seconds ago • Uncommit
186     @cp ${BS_VERILOG_LIB}/FIFO2.v ${VERILOGDIR}
187     @cp ${BS_VERILOG_LIB}/FIFO1.v ${VERILOGDIR}
```

Step 3: Run the following command to generate the bitstream

For **Ganga** SoC,
$ make build BOARD=arty_a7_ganga

For **Yamuna** SoC,
$ make build BOARD=arty_a7_yamuna XLEN_build=32