

COCKPIT PREPARAT	ION
GEAR PINS and COVERS	REMOVED
FUEL QUANTITY	KG.LB
SEAT BELTS	ON
ADIRS	NAV
BARO REF	

BEFORE START	
PARKING BRAKE	
T.O. SPEEDS & THRUST	(BOTH)
WINDOWS CLOSE	
BEACON	OŃ

AFTER START
ANTI ICE
ECAM STATUSCHECKED
PITCH TRIM
RUDDER TRIM NEUTRAL

TAXI
FLIGHT CONTROLS CHECKED (BOTH)
FLAP SETTINGCONF (BOTH)
RADAR & PRED W/S ON & AUTO
ENG MODE SEL
ECAM MEMO TO NO BLUE
- AUTO BRK MAX
- SIGNS ON
- CABIN READY
- SPLRS ARM
- FLAPS TO
- TO CONFIRM NORM
CABINREADY

LINE-UP
T.O. RWY
TCAS
PACKS 1 & 2

APPROACH
BARO REFSET (BOTH)
SEAT BELTSON
MINIMUM
AUTO BRAKE
ENG MODE SEL AS RQRD

LANDING	
ECAM MEMO	LDG NO BLUE
- LDG GEAR DN	
- SIGNS ON	
- CABIN READY	
- SPLRS ARM	
- FLAPS SET	
CABIN	READY

AFTER LANDING
RADAR & PRED W/SOFF

PARKING
PARK BRK or CHOCKSSET
ENGINESOFF
WINGS LIGHTOFF
FUEL PUMPSOFF
YELLOW ELEC PUMPOFF

SECURING THE AIRCRAFT
OXYGENOFF EMER EXIT LTOFF
EMER EXIT LTOFF
BATTERIESOFF