iTX-CAST OCC MANUAL

DESIGN AND PREVIEW	4
Job History	6
Announcement	
Activate Announcement	8
Deactivate Announcement	9
Equipment Breakdown	11
Activate Equipment Breakdown	
De-activate Equipment Breakdown	
SMP MAP	
Longer Travelling Time	
Activate Delay Event	
Deactivate Delay Event	
No Train Services	
Activate Disruption Event	
Deactivate Disruption Event	
Best Practices	
SMP map	
When "Delay" or "Disruption" event is activated	
What announcements had been activated?	
Dashboard	
SMP	
Announcement	24

DESIGN AND PREVIEW


iTX-Cast is a software that allows users to remotely broadcast a wide range of information to various digital signages. iTX-Cast consists of roles and functions that enables users to broadcast:

- Public Information
- Internal Information
- Advertisements
- Promotions
- Navigation

The documentation consists of several pages with instructions on operating the iTX-Cast software.


Viewer

The Viewer tab displays all the Digital Signage Systems which has been configured by EINS accordingly and signed in with the iTX-Cast Server.




Job History

The Job History tab displays all past activities performed by the viewer.




Users can filter the past activities by schedule name and schedule status.




Announcement

Click the "Announcement" tab located at the side bar will show up all the announcements where "Activated" announcements will be shown on the top of the list.




Activate Announcement

Select an announcement, example "BP13 – Senja – Equipment down Lift 2" and click "Turn On Announcement"




Click "Yes, Turn It On" to confirm the action.




Deactivate Announcement

If the selected announcement has already been turned on, it is indicated by the green status text "Announcement On" indicated by the red arrow and the "Turn Off Announcement" button is shown.

Click "Turn Off Announcement" button.




Click "Yes, Turn It Off" to de-activate the announcement.



SMP

This SMP is the operational control dashboard created for BPLRT to monitor, control and schedule content delivery to all stations digital signage (DS).



It allows operator to trigger the following events:

- 1. Equipment breakdown.
- 2. Delay A longer travelling time with no free bus services.
- 3. Delay B longer travelling time with free bus services.
- 4. Disruption no train service.


The SMP is designed to cater only a single event, a "Delay" or a "Disruption".



Equipment Breakdown


Click SMP on the dashboard side bar will bring up SMP interface.

Click "Equipment Breakdown" button will bring up all station's equipment and its equipment.




Activate Equipment Breakdown

For example, to turn on BP6 – Lift 3 breakdown announcement, click on "Choose BP6 Equipment Breakdown" selector and select "Lift 3".




Click on the slider switch beside "BP6 Announcement" to activate the lift 3 breakdown announcement.




De-activate Equipment Breakdown


Click on the slider switch beside "BP6 Announcement" to de-activate the lift 3 breakdown announcement.



SMP MAP


By hovering the mouse over the station label (e.g. BP5) or the dotted line, the cursor will show the corresponding platform number or track number.






Longer Travelling Time


Longer Travelling Time applies to single track disruption, by selecting a track or single platform, it will generate a longer travelling time message in the SMP.






Activate Delay Event

To activate a "Delay" event, click on the "Delay" button and will pop up the following screen.




User will have a choice to activate the correspondence delay event to selected stations or click on the "Activate All" button for all stations.




User will have option to activate all "Delay A" with no free bus services OR activate all "Delay B" with free bus services announcement.


Deactivate Delay Event

To de-activate a "Delay" event, click on the "Delay" button and will pop up the following screen.



User will have a choice to deactivate the correspondence delay event to selected stations or click on the "Deactivate All" button for all stations.







Click "Deactivate Delay A" or "Deactivate Delay B" button to turn off all delay announcements.

No Train Services


No train services apply to double track disruption, by selecting on both track or both platform, it will generate a no train services message in the SMP.






Activate Disruption Event

To activate a "Disruption" event, click on the "Disruption" button and will pop up the following screen.




User will have a choice to activate the correspondence disruption event to selected stations or click on the "Activate All" button for all stations.




Deactivate Disruption Event

To de-activate a "Disruption" event, click on the "Disruption" button and a pop-up with the following screen will appear.




User will have a choice to deactivate the corresponding disruption event to selected stations or click on the "Deactivate All" button for all stations.

Click "Deactivate All" button.



Best Practices


SMP map



With the example screen shot above, a "station down" event occurred and has been normalized, the status shows all disruption events has been cleared and all announcements had been turned off.

It is recommended that operators click the "Reset All" button to clear the SMP map selections when all events are clear. This is to prevent any accidental trigger of any "Delay" or "Disruption" event will would result in broadcasting wrong information.

The screen shot below shows the default status of how the SMP map should look like when there is no "Delay" or "Disruption" event.



When "Delay" or "Disruption" event is activated

After a "Delay" or "Disruption' event is activated, it is NOT recommended to activate any other announcements e.g., "Equipment breakdown". By doing so, it will overwrite the "Delay" or "Disruption" messages shown on the DS screen.

ItxCast Announcement System is designed to act on the latest announcement sent by the user, it is the user's responsibility to ensure that any delay or disruption announcements broadcasted to the respective digital signages is the intended announcement.

What announcements had been activated?


There are 3 ways to check which announcements are currently activated.

- 1. Dashboard
- 2. SMP
- 3. Announcement


To deactivate announcement, refer to Announcement

Dashboard


The "Active Announcement: 1" is indicating currently there is 1 announcement being activated.




Clicking on the "down" arrow located on the right will bring down the list of activated announcements.



SMP



Clicking on the "down" arrow located on the right will bring down the list of activated announcements.



Announcement

Click the "Announcement" tab located at the side bar will display all the announcements as well as allowing users to view and filter announcement which has the status of "Announcement on".

