VERDANT G4 SMART IRRIGATION CONTROLLER - OWNER'S MANUAL (fictional product, original text)

1. Overview
The Verdant G4 controls up to 8 watering zones. It has a built-in rain sensor port and a rechargeable backup battery that keeps the schedule for 72 hours during a power cut.
The controller connects to Wi-Fi on the 2.4 GHz band only.

2. Installation
Mount the controller on a dry wall at least 1.5 metres away from the water tap.
Connect each zone valve to a numbered terminal. Use 0.8 mm cable for runs up to 30 metres.
Plug in the 24 V adapter only after all valves are wired.

3. Scheduling
Press MENU, choose SCHEDULE, then select a zone. Each zone supports up to 4 start times per day.
The default watering duration is 15 minutes per zone. The longest duration you can set is 120 minutes.
Seasonal adjust can scale all durations from 10 percent to 200 percent.

4. Rain Delay
If the rain sensor is wet, watering pauses automatically. You can also set a manual rain delay of 1 to 7 days. Watering resumes by itself when the delay ends.

5. Maintenance
Clean the filter screen at the water inlet every 3 months. Replace the backup battery every 2 years.
Before winter, drain all pipes and switch the controller to OFF mode to protect the valves from frost.

6. Troubleshooting
Error F2 means a valve wire is short-circuited; disconnect the zone and check the cable.
Error F5 means the Wi-Fi signal is lost; move the router closer or restart the controller.
A blinking blue light means the controller is waiting to be paired with the phone app.
To factory reset, hold the MENU button for 10 seconds until the display shows RST.

7. Warranty
The Verdant G4 has a limited warranty of 4 years. Damage caused by frost is not covered.