



MIMXRT1060-EVKB OSG

MIMXRT1060-EVKB



Evaluation kit for the i.MX RT1060 MCU 600 MHz Arm® Cortex®-M7

GET TO KNOW THE MIMXRT1060-EVKB




Figure 2: MIMXRT1060-EVKB

HOW TO GET STARTED

The evaluation kit is shipped with an MIMXRT1060-EVKB board and a USB cable

- 1. Connect the MIMXRT1060-EVKB board to a PC using the included micro-USB cable to USB connector (J1).
 - The MIMXRT1060-EVKB comes preprogrammed with a demo that will initiate the LED on the board to flash periodically when plugged in.
- Explore more out-of-box demos and download software and tools on <u>www.</u> nxp.com/MIMXRT1060-EVK/StartNow.





Download installation software and documentation under "Jump Start Your Design" at www.nxp.com/MIMXRT1060-EVK/ startnow.

SUPPORT

Visit www.nxp.com/support for a list of phone numbers within your region.

WARRANTY

Visit www.nxp.com/warranty for complete warranty information.

www.nxp.com/MIMXRT1060-EVK/startnow

NXP and the NXP logo are trademarks of NXP B.V. All other product or service names are the property of their respective owners. Arm and Cortex are trademarks or registered trademarks of Arm Limited (or its subsidiaries) in the US and/or elsewhere. The related technology may be protected by any or all of patents, copyrights, designs and trade secrets. All rights reserved. © 2021 NXP B.V.

Document Number: MIMXRT1060EVKBQSG REV 1

Agile Number: 926-79035 Rev B