FDTD, clearly explained

How a time-domain electromagnetic solver works, what it can reveal, and whether it belongs in an SRA board workflow.

The short version

Finite-difference time-domain (FDTD) is a numerical method for simulating electromagnetic fields as they change in time and move through a structure. It divides space into small cells, approximates Maxwell's equations on that grid, and repeatedly updates electric and magnetic fields. A short pulse can reveal the response over a range of frequencies from one run.



One time step

1 Update E from nearby H

2 Update H from nearby E

3 Record fields; repeat

Concept sketch: field locations are staggered in space and time.

For the SRA board described here, FDTD is not a routine design requirement. Its main value would be for a specific RF, high-speed signal-integrity, or electromagnetic-interference question.

At a glance

Question	Short answer
What does FDTD solve?	Maxwell's electromagnetic field equations over space and time.
Why use it?	To see waves, reflections, radiation, coupling, and field distribution in complex structures.
What does it cost?	Fine 3D meshes demand memory and compute time; the time step must remain stable.
For the SRA board?	Usually no. Use the analysis method that matches the actual question: circuit simulation, layout rules, thermal checks, or EM simulation when justified.

Prepared as a technical starting point for a future blog post. The board-specific assessment is scoped to the SRA board blocks summarized on page 4.

1. What FDTD does

FDTD is a full-wave computational electromagnetics method. “Finite difference” means replacing derivatives with differences between nearby sampled values; “time domain” means calculating how those values evolve from one instant to the next. The method is commonly associated with Kane Yee’s 1966 formulation of a staggered grid for Maxwell’s equations. [1]

The two curl equations that drive the update are:

$$\partial D/\partial t = \nabla \times H \qquad \partial B/\partial t = -\nabla \times E$$

In plain language: a changing magnetic field is associated with a circulating electric field, and a changing electric field is associated with a circulating magnetic field. A material model relates E to D and H to B; conductivity and frequency-dependent material behavior can also be represented by supported solver models.

The Yee grid and the update loop

In the standard Yee approach, field components are sampled at interleaved locations in each grid cell. Electric and magnetic samples are also offset by half a time step. This staggering lets each update use nearby values of the other field. The solver alternates: update E using spatial differences of H, then update H using spatial differences of E, and continue. [1, 2]

A useful mental picture: a source launches a pulse; the pulse travels through the modeled materials and geometry; boundaries and objects scatter or absorb it; virtual probes record the fields. Applying a Fourier transform to recorded time traces gives frequency-dependent quantities such as transmission and reflection. [2]

Why a pulse can cover many frequencies

A short pulse contains a band of frequency components. If the source has useful energy across the band of interest and the simulation runs long enough, one time-domain calculation can estimate the structure’s response over that band. A narrowband or continuous-wave question may be better served by another solver or setup; FDTD is not automatically the fastest choice for every frequency problem. [2, 3]

> **FDTD gives a numerical approximation. Accuracy depends on mesh resolution, time step, material data, source setup, boundary treatment, and whether the modeled geometry matches the real structure.**

2. How an FDTD simulation is built

A practical workflow begins with a question, not with a solver button. The question determines the model size, the source, the measured outputs, and how fine the mesh must be.

1. Define the structure

Build or import the geometry and assign material properties such as permittivity, permeability, and conductivity. Include the nearby region that can affect the fields.

2. Choose the mesh

Represent the region with cells. Cells must resolve the smallest important feature and the shortest wavelength in the materials, including at the highest frequency being studied. A finer mesh improves geometric and field resolution but increases memory use and runtime.

3. Set the time step and boundaries

The time step is constrained by the spatial cell size and wave speed so the numerical update stays stable (the Courant stability condition). Open-region problems also need absorbing boundaries, often a perfectly matched layer, to reduce artificial reflections from the edge of the finite simulation region.

4. Excite and measure

Add a source such as a plane wave, dipole, port, or pulse, then place field monitors or ports where the answer is needed. Run long enough for the relevant wave interactions and decays to be captured.

5. Check convergence and interpret

Repeat with a finer mesh or altered boundary placement and check whether key outputs change acceptably. Compare against analytical estimates, simpler models, or measurements when available. A visually convincing field animation alone does not establish accuracy.

Strengths

- Directly shows field evolution, propagation, reflection, diffraction, and interaction with materials.
- Handles broadband transient response efficiently when one pulse covers the frequency range of interest.
- Works well for many electrically small-to-medium 3D structures with complex interactions, especially in photonics and antenna problems. [3, 4]

Limits and common traps

- The grid can become very large: halving cell size in three dimensions can multiply the cell count by roughly eight, before accounting for the smaller stable time step.
- Tiny geometric details can dominate the mesh even when most of the model is electrically simple.
- Material dispersion, thin conductors, ports, and open boundaries require appropriate models and careful setup.
- Results are only as credible as the geometry, material parameters, source, mesh, and convergence checks.

When choosing a method

FDTD is one option among electromagnetic solvers. Frequency-domain finite element and integral-equation methods can be more efficient for some electronics or frequency-specific problems. Circuit simulators answer lumped electrical behavior; they do not replace full-wave field solvers when wave effects matter. Choose based on the physical question and validate the result.

3. Does the SRA board need FDTD?

For the board as currently described, generally no. Its documented blocks are battery and protection, a 12 V motor rail, a TPS54302 5 V buck, 3.3 V regulation, ESP32-S3, USB-C, TB6612FNG motor driver, MAX7219 LED matrix, LSA, MPU, OLED, and test points. The board is two-layer and 1.6 mm thick. [5]

The design question matters: FDTD is useful only if a wave-propagation or coupling effect is important enough to justify a full-wave model. For ordinary low-speed control and power behavior, it is usually unnecessary.

What to use for common SRA questions

Question about the board	More direct starting point
Will the buck rail regulate and what is its ripple?	TPS54302 datasheet design checks plus a switching/transient circuit simulation; confirm with measurements on the board.
Can the motor driver supply the motors?	Check motor stall current, TB6612FNG operating limits, supply droop, copper width, connectors, and thermal conditions. Validate physically.
Are the power rails connected and routed correctly?	Schematic review, ERC/DRC, layout inspection, and staged power-up at the documented test points.
Is a trace or USB connection fast enough?	Check interface data rate, stack-up, trace length/return path, impedance needs, and applicable layout guidance. Consider SI analysis only if edge rate and geometry warrant it.
Is there a radiation or EMI problem?	Start with the suspected source, current return paths, switching loops, enclosure/cabling, and measurement. Use a suitable EM solver, potentially FDTD, if the needed effect cannot be answered with simpler checks.

When FDTD could make sense for this board

- A concrete high-frequency or very fast-edge signal-integrity concern where trace and return-path geometry materially affect the waveform.
- A radiation, susceptibility, or coupling investigation that needs spatial field detail around the board, cables, enclosure, or nearby objects.
- An antenna or RF feature is added and its field distribution, matching, or radiation pattern must be predicted.

Even then, first confirm that FDTD is the right solver and that the needed geometry and material data are available. An FDTD model is a simulation result, not evidence that a physical board passes EMC, signal-integrity, or thermal validation.

Suggested blog takeaway

FDTD is a way to compute how electromagnetic fields evolve. It is powerful when the question is about waves and fields; it is unnecessary overhead when the design question is ordinary low-frequency circuit behavior.

References

[1] K. S. Yee, “Numerical solution of initial boundary value problems involving Maxwell’s equations in isotropic media,” IEEE Transactions on Antennas and Propagation, 1966. doi:10.1109/TAP.1966.1138693.

[2] Ansys Optics, “Finite Difference Time Domain (FDTD) solver introduction.” Solver physics and workflow.

[3] Ansys, “What is Finite-Difference Time-Domain (FDTD)?,” January 23, 2024. Ansys blog article.

[4] Ansys Optics, “Rectangular probe antenna.” FDTD antenna example.

[5] SRA board design notes summarized in the project context: component blocks, layer count, and board thickness. The applicability assessment is a scoping recommendation, not a fresh electrical or EM validation of the PCB.

Blog note: the main explanation and examples above are paraphrased. Cite the linked sources in any published article and distinguish general FDTD claims from project-specific board observations.