

ESP32 Connections and Telegram Setup

1. Pin Connections with ESP32

Component	Pin	ESP32 Pin	Description
MFRC522 RFID	SDA	GPIO 5	SS (Chip Select)
	SCK	GPIO 18	SPI Clock
	MOSI	GPIO 23	SPI MOSI
	MISO	GPIO 19	SPI MISO
	RST	GPIO 4	Reset
	3.3V, GND	3.3V, GND	Power Supply
Fingerprint (R307S)	TX	GPIO 16	RX2 (Receive Data from Sensor)
	RX	GPIO 17	TX2 (Send Data to Sensor)
	VCC, GND	5V, GND	Power Supply
LCD 16x2 (I2C)	SDA	GPIO 21	I2C Data Line
	SCL	GPIO 22	I2C Clock Line
	VCC, GND	5V, GND	Power Supply

2. Get Telegram Chat ID

1. Create your bot using **@BotFather** and get your **Bot Token**.
2. Send any message to your new bot in Telegram.
3. Open this URL in a web browser (replace **<BOT_TOKEN>** with your actual token):
https://api.telegram.org/bot<BOT_TOKEN>/getUpdates

Example for this project:

https://api.telegram.org/bot8359988183:AAEEZfJK-le3P8HTOWam2E779Qhz7GXLj_A/getUpdates

4. You'll get a JSON response – look for your **chat ID** like this:
`"chat": {"id":7129485857,"first_name":"Sid","type":"private"}`

So your **Chat ID** is:
7129485857

5. Add this Chat ID and Bot Token into your ESP32 code to enable Telegram message notifications.