
BLTOUCH Manuals

1. BLTOUCH Wire Connetion





2. Touch Screen Wire Connetion




3. How to use


There are approximately two ways for using BLTOUCH until now.Pls see below details.

1) Direct Auto Leveling.

Pls click the leveling button on the touch screen. Afterwards the 3D printer within the support of BLTOUCH will complete the whole procedure for the Auto Leveling procedure. After the Auto leveling done, U can select the files u want to print.











2) Code Modification

U can add a code named "G29" into the Slice software Cura or Gcode printing files. That indicate the Auto leveling operation is ready to go. Then we can select the code modified file and begin to print. Before u get started for printing. The printer will follow the code instructions and complete the whole auto leveling procedure.

