This section → Data Transfer Instructions
- ↳ single register transfer instructions
- ↳ Multiple register transfer instructions
- ↳ memory mapped I/O in ARM



Data Transfer Instructions

- ARM instruction set supports three types of data transfers.
  - a) Single register loads and stores
    - ↳ Flexible, supports byte, half-word and word transfers.
  - b) Multiple register loads and stores
    - ↳ less flexible, multiple words, higher transfer rate
  - c) Single-transfer memory swap.
    - ↳ mainly for system use.
- All ARM data transfer instructions are register indirect messaging.
  - ↳ before any data transfer, same register must be initialized with a memory address.

```
ADRL    r1, Table    ; r1 = memory address of Table.
```

- Examples

```
LDR     r0, [r1]     ; r0 = mem[r1]
STR     r0, [r1]     ; mem[r1] = r0
```

Single register loads and store

- The simplest form uses register indirect without any offset

```
LDR     r0, [r1]     ; r0 = mem[r1]
STR     r0, [r1]     ; mem[r1] = r0
```

$2^{12} = 4KB$

12

- An alternative form uses register indirect with offset (limited to 4Kbytes)

```
LDR     r0, [r1, #4]     ; r0 = mem[r1+4]
STR     r0, [r1, #12]    ; mem[r1+4] = r0
```

12 → mistake in first version

- We can use auto-indexing in addition

12 → mistake in first version of notes

- We can use auto-indexing in addition

```
LDR     r0, [r1, #4]!    ; r0 = mem[r1+4], r1 = r1+4
STR     r0, [r1, #12]!   ; mem[r1+12] = r0, r1 = r1+4
```

- We can use post indexing

```
LDR     r0, [r1], #4     ; r0 = mem[r1],  r1 = r1+4
STR     r0, [r1], #12    ; mem[r1] = r0,  r1 = r1+12
```

- We can specify a byte or half word to transferred.

```
LDRB    r0, [r1]     ; r0 = mem8[r1]
STRB    r0, [r1]     ; mem8[r1] = r0
LDRSH   r0, [r1]     ; r0 = mem16[r1]
STRSH   r0, [r1]     ; mem16[r1] = r0
```

16

Multiple register loads and stores

- ARM supports instructions that transfer between several registers and memory:

{r2-r5}

Example

```
LDMIA   r1, {r3, r5, r6}   ; r3 = mem[r1]
                           ; r5 = mem[r1+4]
                           ; r6 = mem[r1+8]
```

- For LDMIB, the addresses will be r1+4, r1+8 and r1+12
- The list of destination registers may contain any or all of r0 to r15

Block copy addressing

- supported with addresses that can increment (I) or decrement (D) before (B) or after (A) each transfer

Examples of addressing modes in multiple-register transfer:





- Point to note: → ARM does not support any hardware stack
  → Software stack can be implemented using LDM and STM

Example Copy a block of memory (128 bytes aligned)

→ r9 : address of the source
→ r10 : address of the destination
→ r11 : end address of the source




```
Loop:   LDMIA   r9!,
        STMIA   r10!
        CMP     r9, r11
        BNE     Loop
```

128 ÷ 8 = 16

Memory Mapped I/O in ARM



CPSR

- No separate instructions for input/output
- The I/O ports are treated as data memory locations
  ↳ each with a unique (memory) address
- Data input is done using the LDR instruction

- Data output is done with the STR instruction