

Faculty of Engineering and Architectural Science

Department of Electrical and Computer Engineering

Course Number	COE 718	
Course Title	Embedded Systems Design	
Semester/Year	F2020	
Lab No	1	
Instructor Name	Saber Amini	
Section No	03	

Submission Date	09/29/2020
Due Date	09/29/2020

Name	Student ID	Signature*
Vatsal Shreekant	500771363	JAMO .

*By signing above, you attest that you have contributed to this submission and confirm that all work you have contributed to this submission is your own work. Any suspicion of copying or plagiarism in this work will result in an investigation of Academic Misconduct and may result in a "0" on the work, an "F" in the course, or possibly more severe penalties, as well as a Disciplinary Notice on your academic record under the Student Code of Academic Conduct, which can be found online at:

www.ryerson.ca/senate/current/pol60.pdf

Introduction

The uVision IDE features a preloaded project titled Blinky. This program demonstrates some of the features of the NXP LPC 1768 board such as the ADC (Analog to Digital) function and LED function to change the rate of a blinking LED output.

The requirements of Lab1 are to modify the Blinky sample program to feature Joystick functionality and to simulate the inputs of the Joystick direction through a print statement in the debug viewer window. The preinstalled C functions such as Joystick_Initialize() can be called in the main Blinky file.

The joystick movement can be simulated by accessing the GPIO1 pins manually on PORT1 and de-selecting the appropriate pins depending on the desired direction of joystick movement. The state of the joystick is determined by the Joystick_GetState() function. The states of the joystick are defined by the following variable names JOYSTICK_UP, JOYSTICK_DOWN, JOYSTICK_LEFT, JOYSTICK_RIGHT and JOYSTICK_CENTER.

Procedure

- 1) Load Blinkly example project and complete Tutorial 1.
- 2) Add Joystick Board Support by selecting the following icon in the uVision IDE located in the top center of the toolbar. The 'Manage Run-Time Environment' window will open. Select the Joystick API. Select OK button.
- 3) Modify the C coded in the Blinkly.c file located under the Project window on the left. Select SWO Trace→Source Files→ Blinky.c. Add the following code:

```
int main (void) {
 int32 t res;
 uint32 t AD avg = 0;
 uint16 t AD value = 0;
 uint16 t AD print = 0;
 int32 t joy;
 LED Initialize();
                        // LED Initialization
 ADC Initialize();
                            // ADC Initialization
Joystick Initialize();
 SystemCoreClockUpdate();
 SysTick Config(SystemCoreClock/100); // Generate interrupt each 10 ms
 while (1) {
                           // Loop forever
  // AD converter input
  res = ADC_GetValue();
              /* Joystick input--->Get Joystick positional state and assign it a variable
"joy" --- premade function of
              "Board Joystick.h" & "Joystick MCB1700.c(Joystick)" interface */
joy = Joystick GetState();
  if (res != -1) {
                           // If conversion has finished
   AD_last = res;
   AD avg += AD last << 8; // Add AD value to averaging
   AD avg ++;
   if ((AD avg & 0xFF) == 0x10) { // average over 16 values
     AD value = (AD avg >> 8) >> 4; // average devided by 16
    AD avg = 0;
   }
  }
  if (AD value != AD_print) {
                            // Get unscaled value for printout
   AD print = AD value;
   AD dbg = AD value;
   sprintf(text, "0x%04X", AD_value); // format text for print out
  }
  // Print message with AD value every second
  if (clock 1s) {
   clock 1s = 0;
   printf("AD value: %s\r\n", text);
  }
```

```
/* JOYSTICK CENTER, JOYSTICK DOWN, JOYSTICK LEFT,
JOYSTICK RIGHT and JOYSTICK UP
             are defined in the "Board Joystick.h" header. */
              // Depending on output from Joystick prints the following direction
switch(joy){
             case JOYSTICK CENTER:
                     printf("Joystick center\n");
                     break;
              case JOYSTICK DOWN:
                    printf("Joystick down\n");
                    break;
             case JOYSTICK LEFT:
                    printf("Joystick left\n");
                     break;
             case JOYSTICK RIGHT:
                     printf("Joystick right\n");
                     break;
              case JOYSTICK UP:
                    printf("Joystick up\n");
                     break;
 }
}
```

- 4) Compile project using the build button and start the simulation by selecting the debug button.
- 5) Select Peripherals→GPIO Fast Interface→Port 1 from toolbar and run.
- 6) Under GPIO 1 window, check boxes under the "Pins" label to implement each direction of joystick movement as follows:

Pin 20: Center joystick Pin 26: Left joystick Pin 24: Right joystick Pin 23: Up joystick Pin 25: Down joystick

Conclusion

While performing the Lab, some mistakes were encountered. One of them was to implement joystick functionality without modifying the "Blinky.c" file directly but trying to copy only the bare functions required into a new Project file.

Hence, after referring to the manual, it became clear that modifying "Blinky.c" for joystick implementation would be more efficient.

Moreover, during the execution of this lab, another hurdle was encountered when implementing the C code provided in the Lab Manual. The C code was implemented directly into the "Blinky.c" file. Thus, it was realized that the functions Joystick_GetState() and Joystick_Initialize() in the "Joystick_MCB1700.c" already implement low-level register commands.

Lastly, the print function specified in the lab manual was a huge benefit as opposed to being physically present in the computer labs. By deselecting the pins in the GPIO Fast Interface, the ports could simulate the expected results. All the results were possible by initializing the joystick using the Joystick_Initialize() function and then calling the joystick state using the Joystick_GetState() function.

References

- 1) NXP User Manual, https://www.nxp.com/docs/en/user-guide/UM10360.pdf, 2020
- 2) ARM Keil User Guide, https://www.keil.com/support/man/docs/mcb1700/mcb1700_intro.htm, 2020