

Standard Operating Procedure: Concrete Pouring

1. Preparation

Ensure the site is clear of debris. Formwork must be inspected and securely braced. Reinforcing steel must be placed according to approved design drawings.

2. Mixing and Transport

Concrete must meet the specified compressive strength (e.g., M30). Transport the concrete using transit mixers and ensure it reaches the site within the initial setting time.

3. Pouring

Pour concrete continuously to avoid cold joints. Do not drop concrete from a height greater than 1.5 meters to prevent segregation.

4. Compaction

Use mechanical vibrators to compact the concrete. Do not over-vibrate, as this can cause bleeding and segregation.

5. Curing

Begin curing immediately after the final set. Keep the surface moist for a minimum of 7 days using ponding, wet burlap, or curing compounds.