

9502

## Security Passwords

### SETTINGS

General Setup

IP Address / DHCP

Ethernet

ATC Setup

### Remote SMS Feature

Remote SMS Control

 On  Off

Remote SMS Password

Senders White-list

(List of Allowed Remote-SMS Senders)

If configured, ONLY Remote-SMS messages from this list of Senders will be honoured.**Note:** Substitute '+' for any leading zeros in the MSISDNs entered.**Apply**

### Administration Password

**Administration Password has not been Created****Change Settings...**

### Phone-to-SIM PIN

A Phone-to-SIM PIN (up to 8 digits) can be used to lock the terminal to the installed SIM.

The terminal will require the Phone-to-SIM PIN before another SIM can be used.

**Phone-to-SIM PIN is Disabled****Change Settings...**

### Enhanced Security

Enhanced Security:

 On  Off**Apply Changes**