

9502

M2M Setup

SETTINGS
General Setup
IP Address / DHCP
Ethernet
ATC Setup

Ping Configuration

Context Watchdog:

 On Off

Sends a PING to keep the context alive and test connectivity. If ping fails and the unit can not recover, resets unit.

0.0.0.0

0.0.0.0

(Optional)

0.0.0.0

(Optional)

Time between Pings:

0 minutes

Ping Required:

 Yes No

(Always send ping even if other data sent recently)

Apply Changes

Always ON Context

Always On Context:

 On Off

192.168.2.12

(If the Local IP address field is left blank, a context will be set up for the first device detected via an ARP)

QoS:

Standard ▾

APN Config:

DS1.bgan.inmarsat.com ▾

Apply Changes