


--- v1 adapter / additive — v2 adapter / additive v2 adapter / max



Privileged route diagnostic; no scenarios. Complete traces, including startup, stopping and failures; clocks start at each case's first controlled tick.