PREPARE CAREFULLY. PREVIEW FIRST. THEN SEND LIVE.

Operator Workflow

A calm, reliable service-day guide for VersePoint 1.1. Use it before, during and after a church service.

1. Prepare

Connect displays, organize content and test every output on the computer that will run the service.

2. Preview

Confirm the words, slide order, background and overlays before sending the next item live.

3. Present

Operate from Programs or Service Flow, watch Output status and confirm the physical screen.

What this guide covers

Scripture and Songs; Programs and document slides; Motion Studio; Service Flow, media, overlays and audio; Mobile Requests and device permissions; live output, backups and safe closing.

Use the current build deliberately

This guide describes the current 1.1 workflow. A guide update does not mean a new installer has been published. Use an accepted build and check it on your actual service equipment.

10-20 MINUTES BEFORE

Prepare the room and outputs

Verify the physical Projector and optional Web Output before people arrive.

1 **Connect equipment first**

Connect the projector or TV and audio equipment before opening VersePoint.

2 **Choose Projector Screen**

Open Settings and select the correct external display under Projector Screen.

3 **Turn the screen on**

Select **Screen On**. Confirm the physical display shows VersePoint and Output status says **Projector Live**.

4 **Prepare the visual look**

Open **Backgrounds** and **Style**. Choose a suitable background and readable Scripture or Lyrics styling.

5 **Prepare Audio**

Choose or create an audio list, import tracks and test play, pause, timeline, loop and volume through the room audio path.

6 **Set up Web Output if used**

Choose **Full Background** or **Text Only (Transparent)**, start the server and test the Live Output URL in OBS or a browser.

PREPARE THE SERVICE

Build a predictable Program

Programs hold prepared Scripture, Songs, visual media and documents for manual service operation.

Create the service list

Open **Programs** and select **New Service List**. Use a clear title such as Sunday Morning or Evening Service.

Add Scripture and Songs

In Scripture, open **Add** and choose a Program list or create one. In Songs, use the song menu to add the song to the correct list.

Reorder folders and items before the service. Use the current-service selector to keep preparation in the intended service.

Add visual media and documents

In **Backgrounds > Media**, use the plus menu and **Add to Program**. Images and videos can also go to Service Flow or become a selected item's background.

PDF, PowerPoint and Keynote files use **Add to Program**. Operate their converted static pages from the Program center controls; embedded presentation animations and video do not play as native document effects.

Apply the look

Select a Program Scripture or Lyrics item before **Assign to Program Item**. Use folder Style or Background actions only when the whole folder should share that selected item's look.

Before switching

If Program media is playing, VersePoint warns before switching to another item. Stop or switch only when it is safe.

CONTENT PREPARATION

Prepare readable text

Review the words, slide structure, shortcuts and presentation look before the service.

Scripture

Choose the Bible version, book and chapter, then select the verse. Arrow keys navigate the live Scripture workflow; **Enter** displays or stops the selected verse. **Shift+Enter** opens its Add menu.

Use **History** to revisit displayed verses; **Ctrl/Cmd+Shift+H** opens it from Scripture. A recalled verse enters Preview first; use its display action when ready.

For a verse split into multiple parts, review and navigate the parts in order. Check the final part before moving on.

Songs and lyrics

Choose a song, then use **Arrange Lyrics** to edit and review slides. Keep verse, chorus and bridge labels with the correct slide.

Use **Done Arranging** when finished, then click through every slide. Inside a Program, choose Grid or List view; Grid also provides card-size control.

Assign slide shortcuts only when they make navigation faster and safer. With no song selected, the Preview background remains free of song-selection text.

Typography and language

Use a font that supports the selected language. Check long lines, line breaks and the reference at projection size, especially for Myanmar or other complex scripts.

Readability rule

If the background competes with the words, simplify it or strengthen contrast. Check the actual Projector rather than judging only from a small Preview.

VISUAL PREPARATION

Organize sources and destinations

Keep source files available, then choose the correct destination for each Media Library item.

Media Library

Import image, video, PDF, PowerPoint or Keynote files. Use favorites, pins, List or Thumbnails view and Sort by Type to find important items.

Removing an item from the VersePoint library does not delete the original computer file.

Choose the correct action

Add to Program creates a standalone Program Media item.

Add to Service Flow creates a timed visual-media item for images or videos.

Assign to Program Item saves an image or video as the selected Scripture or Lyrics item's background. Documents offer Add to Program only.

Backgrounds and Style

Use Colors & Gradients for a dependable background, Media for stills or videos, and Motion when the computer and visual setting are suitable.

Review dark-background, light-background and saved custom style presets. Check font size, line height, alignment, reference position and contrast.

Output check

After changing a video or document page, verify the physical Projector and live Web Output. Preview, Projector and Web Output run as separate surfaces.

PDF, POWERPOINT AND KEYNOTE

Navigate readable slide pages

Documents become static pages in Programs. Prepare and check conversion before the service.

Prepare the document

PDF pages open directly. On macOS, other formats need Keynote or LibreOffice. On Windows, PowerPoint needs Microsoft PowerPoint or LibreOffice; export Keynote to PDF on a Mac for the dependable path.

Keep source files available. Check fonts and page layout after conversion. If preparation fails, read the message, fix the source or converter, then use **Retry**.

Browse large presentations

Scroll the slide grid rather than fitting the entire deck into the workspace. Thumbnails retain a readable size for 100+ slides and load as you approach them.

Select a thumbnail or enter a number under **Current slide**. Use first, previous, next and last controls, or **Space / Right / Left / Home / End** while the document workspace is active.

Control timing and transitions

Use **Auto Play**, set seconds per slide and enable **Loop** only when intended. Pause Auto Play before taking manual control.

Under **Animation**, choose Use Settings, Off, Fade, Slide Up or Soft Zoom. These are VersePoint page transitions; the original presentation animations, transitions and embedded video do not play.

Fit the page and confirm live state

Document pages always fit the output frame; their menu omits Fill, Fit and Original. Watch the selected or LIVE slide marker and verify the physical output.

The more visible **Allow mobile control** row opens presentation assignment; see the Mobile Requests page for permission steps.

CREATE BACKGROUNDS BEFORE THE SERVICE

Build and reuse motion designs

Keep a saved design and its generated video distinct. Review the result at projection size.

Choose or create a design

Open **Backgrounds > Motion**. Use **Browse** for presets and personal designs, or **New** for a fresh design. Editing a preset creates a personal copy.

Use the design menu to duplicate, rename or delete. Deleting a design keeps generated videos in Media; **Restore** can undo the recent design deletion.

Tune the motion for readable words

Choose Motion Type, colors, pace and supported patterns. Use **Appearance & Layout** for advanced styling. **Text preview** adds sample words only to the preview; generated videos contain no text.

Use the floating preview when useful. Gentle movement and a quiet text area usually make Scripture and Lyrics easier to read.

Generate to Media

Choose Render quality, Full HD or 4K UHD, Duration and Seamless loop, then select **Generate to Media**. Wait for generation and validation to finish.

The design status tells you when its video matches, or when the design changed after generation. Use **Regenerate to Media** to update the video. A saved design alone does not update an existing video.

Check storage, save state and playback

4K uses more storage and processing than Full HD; allow time to generate and test on the service computer. Confirm the video appears in Media and plays through several loops on all active outputs.

Wait for **Saved** before closing. If saving fails, keep the design open and use **Retry save**.

OPTIONAL WORKFLOWS

Choose the right live tool

Programs, Service Flow, Overlay Graphics and Audio serve different purposes.

Service Flow

Use an ordered sequence of Scripture, visual-media and overlay cues. Filter by All, Scripture, Media or Overlays; **Play All** follows the active filter.

Set media duration carefully. Use **Spacebar** to advance manually when appropriate.

Overlay Graphics

Create Text, Lower Third, Announcement, Countdown, Clock, Ticker, Logo or QR Code overlays in the Service Flow workspace.

Add **Show**, **Hide** or **Toggle** cues. Show cues can auto-hide and repeat. Watch the repeating-overlay status and use **Stop all** when repeating cues are no longer needed.

Check overlays alongside Scripture, Lyrics and media, including output safe areas.

Audio

Audio is independent from Programs and visual output. Use audio lists, ordering, play, timeline, loop and volume. Test the room audio path before the service.

Avoid competing service orders

Choose one main live sequence. Use the other tool for its special purpose instead of running Program and Service Flow as competing orders.

OPERATOR-AUTHORIZED CONTROL

Approve devices deliberately

Guests can submit requests without permission to control the live output. Live control requires PC approval.

1

Start and connect

Start the server in **Settings > Mobile Requests**. Connect phones and PC to the same local network. Scan the QR or open the address, enter a name and continue.

Requests appear in the guest's named Program service. Use the current-service selector and unread-request badge to find new content.

2

Request Scripture or a song

On the phone, pick the Bible version and book. Tap **Chapter** or **Verse** for the number grid; review the text and **Send Scripture**.

In **Songs**, search and select a song, then **Send Song**. **My requests** shows submitted items.

3

Enable and approve live control

Turn on **Allow mobile screen control**, then enable the switch for each trusted device. Check the device name and short device ID; two phones with the same name still need separate approval.

Single device: approving another device transfers control. **Multiple devices:** approve each device that may share control; commands run in order. When returning to Single device, choose which device keeps control.

4

Operate, assign and revoke

Approved phones can show requests, hide text and navigate lyrics or split verses. Submitting a request does not send it live.

Open the document menu > **Allow mobile control**, choose a device and select **Assign / Resume control**. Phone previews leave output unchanged until a slide is sent. PC changes can pause control; resume from the PC.

Use **Revoke presentation control** for the assignment, a device switch for that phone, or the master switch for all control. A server/app restart resets permissions; changed documents need reassignment.

TEST THE COMPLETE LOOK

Keep effects reliable and readable

Use the service computer and actual output setup to test the final combination, not just each effect alone.

Entrance plus text effects

In **Style > Effects**, review the entrance animation and duration together with Shadow, Glow, Outline, Backplate and Perspective.

Before the service, test **Flip + Shadow**, then add Perspective and the other effects you intend to use. Try rapid verse/slide changes and Clear Text / Show Text over the selected motion background.

Check all active surfaces

Compare Preview and the physical Projector through several background loops. Watch for delayed video, stale words, cropped shadows or a jump when changing text.

Web Output has its own presentation settings. Configure its look separately and verify the live URL or OBS Browser Source, including resizing and transparent output when used. Do not assume PC effects automatically match Web Output.

Use a conservative look on slower computers

If a combination hesitates, first disable Perspective or choose a simpler entrance. Reduce stacked blur effects or use a still background if needed.

Retest long Myanmar lyrics and gradient/hollow text on that computer. Improvements measured on one Mac do not guarantee the same timing on every GPU.

Agree on a fallback before going live

Keep one readable still background and a simple text style ready. During the service, restore clear output first; investigate the complex effect combination afterward.

DURING THE SERVICE

Preview, confirm, then present

Keep attention on the next item, Output status and the physical screen.

1

Watch Output status

Confirm **Projector Live**, Web readiness if used, and **Text On** before the content is needed.

2

Select the next item

Use Programs or Service Flow. Confirm the words, background, media and overlays in Preview before sending live.

3

Navigate Scripture and Songs

For Scripture, press **Enter** to display the selected verse. For Songs, select the next slide or use arrow keys.

4

Clear words temporarily

Use **Clear Text** for a clean background; use **Show Text** when words are needed again. **Screen Off** is a separate output control.

5

Operate media carefully

Use center controls for Program Media and document pages. For Service Flow Media, follow timing or advance manually.

Useful shortcuts

Workspace: **Ctrl/Cmd+1 to 4** | Reference search: **Ctrl/Cmd+K** | History: **Ctrl/Cmd+Shift+H** | Clear/Show Text: **Ctrl/Cmd+Shift+C** | Screen On/Off: **Ctrl/Cmd+Shift+S**

STAY CALM

Recover quickly and close safely

Use the smallest correction that restores clear output, then preserve the service setup.

If something looks wrong

Wrong projector: check **Settings > Projector Screen**. Missing words: check Text On/Cleared and **Show Text**. Hard-to-read words: simplify the background or adjust Style.

Web Output stopped: check server status, the Live Output URL and the OBS Browser Source. For a media or animation issue, use a safe still background and simple style.

Unexpected phone control: revoke the device or disable **Allow mobile screen control**; the PC operator remains responsible for live output.

Save and Load backups

Open **Settings > Save** and select Songs, Programs & Service Flow, Audio Library, Presets & Backgrounds, Output Settings and/or UI & Layout.

Songs merge when loaded; other selected categories restore from the backup. External media, audio, imported Bible and custom font files are not embedded. Copy or re-import them separately.

Keep dated backups and test a restore before an important service.

After the service

Stop Web Output, Mobile Requests, playback and repeating overlays. Select **Screen Off** before disconnecting the projector.

Review the **Close VersePoint** or **Quit VersePoint** confirmation, which lists active outputs/services. Cancel if the service is still active.

Allow saves to finish

Closing waits for pending saves, including Motion Studio changes. If saving fails, keep the app open, correct the storage or access problem and use **Retry save**. If loading fails, saved files are preserved and saving pauses; fix access, then use **Retry loading**. Do not force-quit with unsaved changes.

MAINTENANCE BETWEEN SERVICES

Review before resetting

Settings > Storage & Maintenance saves edits and restarts VersePoint. Finish live operation first.

Use the smallest maintenance action

Clear cache removes temporary HTTP, code, thumbnail and song caches. Content and converted presentations are kept; caches rebuild as needed.

Reset preferences returns appearance, layout, output preferences and hints to defaults. Libraries, presets and media are kept. Review the projector and Web Output configuration afterward.

Factory reset is a fresh profile

Factory reset starts with empty libraries and default settings. The current profile, including generated media, is kept in a local recovery copy; external source files stay in place.

Read the review screen and type **RESET** only when you intend this fresh start. Keep a separate dated backup of valuable content.

Restore a recovery copy

Open **Recovery copies**, choose the dated copy and use **Show** to locate it or **Restore** to review. Type **RESTORE** to replace the active profile.

The current profile is archived before restoration. External files must still exist at their original paths. Recheck libraries, Programs, saved styles and all outputs after restart.

Local recovery is not an off-computer backup

Recovery copies remain on this computer and can use substantial storage. Save dated settings backups and copy external media, fonts and imported Bibles separately to a safe location.

Stop if maintenance reports a failure. Keep the recovery copy and current files intact while investigating.