FORM REF-PTW · REV. 5   POST-STASIS REFRESHER · REFERENCE SHEET   POST AT EVERY PERMIT BOARD

DUNEWRIGHT COLONY WORKS
Settlement Site 4 · Construction Division · Safety & Health

PERMITS AT A GLANCE.

NO PERMIT, NO START. EVERY LIVE PERMIT HANGS AT THE JOB AND ON THE STRUCTURE'S PERMIT BOARD.

EVERY PERMIT AND PLAN

SIGNERS BY STATION AND HAT
ROLES AND TERMS: REF-GL

PERMIT	NEEDED FOR	SIGNED BY	CLOSED BY	LASTS	POSTED	LEARN IT IN
PTW-HW HOT WORK	Welding, cutting, grinding, brazing or torch work outside a designated welding bay. Stops in wind 20+ mph or a blowing-dust advisory. No hot work at 1% LEL or above (SITE RULE).	⬜ The foreman responsible for the work area. Never the person doing the hot work.	The signing foreman, after the fire watch reports "watch complete" 60 min after the hot work ends (NFPA 51B; the OSHA 1910.252 minimum is 30), and after any walk-through checks logged on the permit are done (SITE RULE, HS-05). Opened and closed on Ch 13.	One location, one shift.	At the job and on the permit board.	HS-05
PTW-CS CONFINED SPACE	Any entry into a confined space. Every one counts as permit-required (SITE RULE) until the entry supervisor signs a written certificate at the hatch that every hazard has been removed (HS-SA). Entry stops at 10% LEL.	⬜ The entry supervisor: a foreman or general foreman with the HS-SA endorsement.	The entry supervisor, when the job is done, conditions change or the shift ends, with every entrant out and counted.	The task, never past one shift (SITE RULE). A new shift needs a new PTW-CS and fresh air tests. Entry supervisor or attendant changes mid-shift (8 h role limit): the incoming one signs the permit before the outgoing one leaves. Attendants pass the entrant count in person.	At the hatch and on the permit board, with names, air tests, times and the rescue plan.	Supplement A (HS-SA)
PTW-HE HEAT ENTRY	Any work at the Extreme heat entry level, 140–159°F.	⬜ The area general foreman, 🟩 countersigned by a Safety officer.	The signing general foreman, once every entrant is out and has had a medical check (SITE RULE).	One location, one shift (SITE RULE). Each entry: time set on the permit, never over 15 min, then at least 30 min in a cooled space (SITE RULE). Entrants must have finished the ramp and Days 6–14 and be cleared for heat entry that shift by Revival Med Bay or the FAS (SITE RULE).	At the job and on the permit board, with every entry logged.	HS-03
PTW-EE ENERGIZED ELECTRICAL	Work on or near exposed live parts, only when de-energizing is infeasible or creates a greater hazard. Qualified electrical workers (blue hats) only. Testing and voltage measuring by a qualified worker need no PTW-EE (HS-SB).	⬜ The Electrical & Power general foreman.	The Electrical & Power general foreman, when the work is done and the equipment is closed up (SITE RULE).	One task, one shift (SITE RULE).	At the job and on the permit board.	Supplement B (HS-SB)
PTW-DG DIG PERMIT	Any digging, trenching or drilling into the ground, and driving stakes, pins or anchors.	⬜ The area foreman, after ▨ Survey and 🟦 Electrical & Power locate and mark buried services.	The area foreman, when the dig is backfilled or handed over (SITE RULE).	Until the job is done, while the marks last. Marks blown away by sand: locate again before digging (SITE RULE).	At the job and on the permit board.	HS-06
LP- CRITICAL LIFT PLAN	Any critical lift: 75%+ of chart capacity, two or more cranes, personnel lifts, loads over occupied structures, or unusual loads. Every other lift is still planned (HS-06).	Prepared by Design & Structures. ⬜ Approved by the Lift Director, who directs the lift on site.	The Lift Director, when the load is landed and unrigged (SITE RULE).	That lift, as planned. Any change to load, crane, radius, path or rigging goes back to the Lift Director (SITE RULE).	In the crane cab and on the permit board. Names the lift talkgroup and who scans Ch 1 + Ch 16 for the crew, never the operator.	HS-06
Fall rescue RESCUE PLAN	Any work that needs fall protection: 6 ft and up, Deck 1 and above, scaffolds at 10 ft. No rescue plan, no climb.	🟨 The crew lead names the method and gear before anyone goes up. The fall-protection competent person checks it (SITE RULE).	The crew lead, when everyone is down.	That task and location, one shift. Re-check whenever the work moves (SITE RULE).	At the work, with the rescue gear, and on the permit board (SITE RULE).	HS-04 · Supplement C (HS-SC)
PTW-SP SPRAY PERMIT · ISOCYANATES · VEILCOAT	Spraying isocyanate coatings or foams, QuickSet C-4X or VeilCoat. Respirator: supplied air for all isocyanate spraying (SITE RULE); full-face P100 + organic vapor for VeilCoat. IH may require more, never less. Bystanders out of the spray zone.	🟩 Industrial Hygiene sets the respirator and spray zone. ⬜ The area foreman signs (SITE RULE).	The area foreman, when spraying ends and the solvent has flashed off.	One location, one shift (SITE RULE).	At the spray-zone boundary and on the permit board.	HS-08

Designated welding bays in the Fabrication Yards need no PTW-HW. Hot work inside a confined space needs both a PTW-CS and a PTW-HW. A confined space at 140°F or hotter needs both a PTW-CS and a PTW-HE.

RULES FOR EVERY PERMIT

READ IT · POST IT · STOP WHEN IT CHANGES

BEFORE WORK STARTS

- The signer walks the job and checks the permit board before signing. Never from an office. (SITE RULE)
- The signer runs the conflict check below.
- Read the permit before you start. Your name on it means you've been briefed on its hazards and controls.
- Posted at the job and on the board, or no start.

WHILE IT'S LIVE

Something changes: stop. The permit is suspended until the signer re-checks the job. (SITE RULE)

- Wind 20+ mph or a blowing-dust advisory (hot work).
- A meter alarm: 1% LEL for hot work, 10% LEL for entry, or O_2 outside 19.5–23.5%.
- A sandstorm warning, a flood warning, a lightning alert, a take-shelter or evacuate siren, or ALL STOP. A sandstorm watch or the weekly siren test doesn't suspend permits.
- A new task, location or crew.

Missing or expired permit at a job: use your stop-work authority.

THE PERMIT BOARD

- One at every structure. Work on open ground uses the board at the sector office. (SITE RULE)
- It holds every live permit, LP- plan and fall-rescue plan, and every group lockout with the group-lockout lead's name. (SITE RULE)
- Signers check it for conflicting work before they sign.
- Closed permits come off the board and go to Safety & Health for the record. (SITE RULE)

CONFLICT CHECKS (SIMOPS)

SIMULTANEOUS OPERATIONS
CHECKED BEFORE THE SECOND PERMIT IS SIGNED

SIMOPS means two jobs close enough to endanger each other. Before signing, the signer checks the permit board and walks the area. The second job isn't signed until both signers agree how the jobs stay apart, and write it on both permits. (SITE RULE)

HOT WORK NEAR SPRAYING

VeilCoat solvent and spray mist burn. No hot work within 35 ft of VeilCoat or any other solvent spraying (PTW-SP), while it runs or until the solvent flashes off.

DO: schedule them apart, or put 35 ft and a barrier between them. Test the air below 1% LEL before the torch lights.

LOADS OVER HOT WORK OR ENTRIES

No load path over a hot-work zone, an open hatch, an attendant or a trench crew. Slag and sparks cut and melt synthetic slings.

DO: the Lift Director reroutes the lift, or the other job pauses and clears out while the load passes.

INERT-GAS PURGES NEAR ENTRIES

Argon and nitrogen vent from purged tanks and hull voids and pool in low spots: pits, trenches, the next hatch over.

DO: route purge vents away from hatches, trenches and air intakes. The entry supervisor checks the board for purges before signing a PTW-CS, and the air is tested at the hatch.

SHARED LOCKOUTS

Two crews on one machine or circuit share one group lockout: yellow job locks, keys in the yellow lockbox, every worker's red lock on the box, one group-lockout lead. Crews under different foremen: the foremen agree on one lead and write the name on the lockbox tag. If they can't agree, the general foreman names the lead.

DO: Electrical & Power's blue locks stay on until their own release. Nothing is re-energized until every crew's locks are off (HS-07).

ALSO CHECK

- **Digging near a crane:** no excavation beside or under outrigger mats unless the Lift Director and the excavation competent person agree.
- **Engines and exhaust:** keep generators, vehicles and compressors away from confined-space air intakes (HS-SA).
- **Energized work:** barricade the limited approach boundary of a PTW-EE job. No other crew works inside it (HS-SB).
- **Work below work:** no crew under overhead work, hot work from above, or a load path.

WHEN SIGNERS DISAGREE

- Foremen who can't agree take it to their general foreman, then the Assistant Super on shift. (SITE RULE)
- Until it's settled, the second job waits.
- Any green hat can stop both jobs.

STOP-WORK AUTHORITY

No permit, an expired permit, or a conflict nobody checked: that's unsafe work. **Anyone can stop unsafe work. No penalty, no questions.** Stop it, make it safe, tell your crew lead (your foreman if there's no crew lead; any green hat if it isn't fixed). Work restarts only when the crew lead confirms the fix with the person who stopped it. Every stop is logged.

Adapted from Old Earth standards: UK HSE HSG250 permit-to-work guidance, OSHA 1910.252 and NFPA 51B (hot work), OSHA 1910.146 (permit-required confined spaces), NFPA 70E (energized electrical work permit), OSHA 1926.651(b) (underground installations), OSHA 1926 Subpart CC and ASME B30.5 (lift planning), OSHA 1926.502(d)(20) (prompt rescue), OSHA 1910.134 (respiratory protection), OSHA 1910.147 (group lockout). The heat entry permit, spray permit (PTW-SP) and permit board rules are DCW site rules.