
# Review







#### Final examination

- □Close-text, with a handwritten A4 memo sheet
- □Selections 26%
- □Answering Questions in 150 words. 20%
- □Calculation 10%
- ☐Storage 10%
- □Cache /Memory 12%
- □Pipeline 22%

□July 3, 14:00-16:00, Building 4-410(Yu Quan)







#### Chapter1: Fundamentals

- ■What's Computer architecture ?
- ■What's a computer architect's task?
- ■What should a computer architect need to know?





#### What's Computer architecture?

- Computer Architecture is the science and art of selecting and interconnecting hardware components to create computers that meet functional, performance, cost and power goals.

  Tradeoff
- Computer architecture is the conceptual design and fundamental operational structure of a computer system. Computer architecture is a blueprint and functional description of requirements (especially speeds and interconnections) and design implementations for the various parts of a computer focusing largely on the way by which the central processing unit (CPU) performs internally and accesses addresses in memory.



#### What's Computer Architect's task?


- ☐ Define the requirements
  - Application field, computer market(1.2)
  - Functional requirement
  - non-functional requirements
- ☐ Architecture design (blueprint)
  - > ISA
  - Organization
  - Hardware
- Optimization

Supercomputer PC, workstation Embedded system Server





#### Computer Design Engineering life cycle









#### 1.4 Technology Trends

- Designers often design for the next technology.
- □ Technology improves continuously, an impact of this improvements can be in discrete leaps.

#### ■ Moore Law

- ➤ In 1965, number of components the industry would be able to place on a computer chip would double every year.
- > In 1975, he updated his prediction to once every two years.

#### Rule of thumb

- Bandwidth grow rate ~ improvement in latency2
- > transistor perf. Improves linearly with decreasing feature size.
- > signal delay for a wire increase in proportion to the product of its resistance and capacitance.





#### 1.5 Trends in Power

- Power also provide challenges as device scaled
  - first microprocessor: 1/10watt --> 2GHz P4: 135watt

#### □Challenges:

- > distributing the power
- > removing the heat
- > preventing hot spot
- □What to do? power-aware design





#### 1.6 Cost trend

- Understanding cost trends of component is important, since we design for tomorrow!
- ☐ How to learn? Learning curve.
- ☐ The impact factors for cost:
  - > Time, Volume, modification
- □Rules of Thumb
  - Twice the yield will have half the cost.
  - Cost decrease about 10% for each doubling of volume.







#### Cost vs. Price

- □ Component costs
  - > Raw material cost.
- □ Direct cost:
  - Costs incurred to make a single item. Adds 20% to 40% to component cost.
- ☐ Gross margin (Indirect cost):
  - Overhead not associated with a single item, i.e. R&D, marketing, manufacturing equipment, taxes, etc.
- ☐ Average Selling Price (ASP):
  - > Component cost + direct cost + indirect cost.
- ☐ List price:
  - Not ASP. Stores add to the ASP to get their cut. Want 50% to 75% of list price.
  - Small changes in cost can have an unexpected large increase in price.







#### 1.7 Dependability

- Dependability is a deliberately broad term to encompass many facets including reliability, security and availability.
- ☐ Service level Agreements(SLA)/Service level objectives (SLO)
  - Service accomplishment
  - Service interruption
- $\Box$  Failures:  $S_{accomplishment} \rightarrow S_{interruption}$
- $\square$  Restorations:  $S_{interruption} \rightarrow S_{accomplishment}$
- □ Redundancy:
  - Time redundancy: repeat the operation again to see if it is still in erroneous.
  - Resource redundancy: have other components to take over from the one that failed.





#### Measurements of Dependability

- Module reliability: continuous service accomplishment
  - ➤ MTTF: Mean Time To Failure
  - ➤ MTTR: Mean Time To Repair
  - > FIT: Failure In Time = 1/MTTR
  - ➤ MTBF: Mean Time Between Failure = MTTF+MTTR
- Module availability
  - MTTF = MTTF
    MTTF + MTTR MTBF







#### 1.8 Measuring and Reporting Perf.

#### □ Performance Metrics

- > response time or elapsed time user perception
- > Throughput --administrator perception
- > User CPU time computer architect
- > MIPS millions of instructions per second

#### □ Comparing Machines Using Sets of Programs

- > Choosing which program to evaluate performance
  - Benchmark Suites
- Different Means: Arithmetic, Harmonic, and Geometric Means





#### Summary of performance metrics

- Response (Execution) time
  - > user perception
  - > system performance
  - > the only unimpeachable measure of performance
- □ CPU time
  - > designer perception
  - > CPU performance
- ☐ Throughput
  - > administrator perception
- **□**MIPS
  - > merchant perception





### 1.9 Quantitative Principles

- ☐ Take Advantage of Parallelism
- □ Focus on the common case
- □Principle of Locality
- □Amdahl's Law
- □ CPU Performance Equation

Where the principles are used? Could you give some examples?







#### **Exploiting the Parallelism**

□ Taking advantage of parallelism is one of the most important methods for improving performance.

#### ■ Many example

- > system level: multiple processors / multiple disk,
- > individual processor: pipelining
- > digital design level: set-associative caches





### What the Amdahl's Law imply?

- ☐ If an enhancement is only usable for a fraction of task, then the total speedup will be no more than 1/(1-F).
- ☐ Serve the guide
  - > to how much an enhancement will improve performance
  - > to how to distribute resource to improve cost-performance
- Useful for comparing
  - > the overall system performance of two alternatives,
  - > two CPU design alternatives
- ☐ We can improve the performance by
  - > increasing the Fraction enhanced
  - > or, increasing the Speedupenhanced





#### **The CPU Performance Equation**

- ☐ The "Iron Law" of processor performance:
  - Often it is difficult to measure the improvement in time using a new enhancement directly.
- □ CPU Performance Equation

CPU time = CPU clock cycles for a program × Clock cycle time

$$CPU time = \frac{CPU \ clock \ cycles \ for \ a \ program}{Clock \ rate}$$





#### Calculation of CPU Time

CPU time = Instruction count × CPI × Clock cycle time

Or 
$$CPU time = \frac{Instruction count \times CPI}{Clock rate}$$

$$CPU time = \frac{Instructions}{Program} \times \frac{Clock \ cycles}{Instruction} \times \frac{Seconds}{Clock \ cycle}$$

Architecture --> Implementation --> Realization
Compiler Designer Processor Designer Chip Designer

Component of performance	Units of measure
CPU execution time for a program	Seconds for the program
Instruction count	Instructions executed for the program
Clock cycles per instructions (CPI)	Average number of clock cycles/instruction
Clock cycle time	Seconds per clock cycle



#### Related technologies

- CPU performance is dependent upon 3 characteristics:
  - > clock cycle (or rate) (CC)
  - clock cycles per instruction (CPI)
  - > instruction count. (IC)

	Inst Count	CPI	Clock Rate
Program	X		0.137
Compiler	X	(X)	
Inst. Set.	X	X	
Organization	- ////	X	X
Technology			X

☐ One difficulty: It is difficult to change one in isolation of the others.






#### Principle of Locality

- □ Programs tend to reuse data and instructions they have used recently.
- □ a program spends 90% of its execution time in only 10% of the code.
- □ Temporal locality
  - > Recently accessed items are likely to be accessed in the near future.
- □ Spatial locality
  - > Items whose addresses are near one another tend to be referenced close together in time.



## ChapterB Outline of ISA







## Seven dimensions of ISA

- ☐Class of ISA
- Memory addressing
- ■Addressing modes
- Types and sizes of operands
- Operations
- Control flow instructions
- Encoding an ISA
- ☐ The impact of compiler





#### Important step for ISA design

□ To analyze and evaluate the existing machines with a large collection of programs before making architectural decisions.





#### Classifying Instruction Set Architectures

- ☐ The type of internal storage in CPU
  - > Stack, accumulator, GPR(General-Purpose Register) architecture
- ☐ Max number of operands in ALU instruction.
  - ➤ R-R, R-M, M-M
  - > What's Load/Store architecture?





# Other Taxonomy of Computer Architecture

#### 1989 IEEE taxonomy:

- . Personal Computer (PC)
- . WorkStation (WS)
- . Mini Computer
- . Mainframe
- . Minisupercomputer
- . Supercomputer


- > Server
- > Embedded systme
- ➤ Cluster、Grid Computer






#### Flynn taxonomy

 based on the number of streams of instructions and data on bottleneck









#### CSIC & RISC

- ■What's a RISC ?
- ■What are a RISC machine's characteristics?
- □Could you compare RISC & CISC? From which viewpoint?






# How you make decision when design ISA?

- Measure the existing ISA
- ■Make the common case fast
  - Memory addressing mode:
    - aligned memory access
  - Oprand
  - Operation
  - > Ecoding
    - Fixed, variable, Hybrid





# Basic pipeline





## What is Pipelining?

#### □Pipelining:

➤ is a set of data processing elements connected in series, so that the output of one element is the input of the next one. The elements of a pipeline are often executed in parallel or in time-sliced fashion; in that case, some amount of buffer storage is often inserted between elements.





#### Instruction Pipeline

- An **instruction pipeline** is a technique used in the design of computers and other digital electronic devices to increase their instruction throughput (the number of instructions that can be executed in a unit of time).
  - implementation technique whereby different instructions are overlapped in execution at the same time.
  - > implementation technique to make fast CPUs






## Why pipelining: conclusion

☐ The key implementation technique used to Make fast CPU: decrease CPUtime.

- ☐ Improving of Throughput (rather than individual execution time)
- ☐ Improving of efficiency for resources (functional unit)



#### Multi-cycle implementation vs. pipelining





#### Ideal Performance for Pipelining

☐ If the stages are perfectly balanced, The time per instruction on the pipelined processor equal to:

Time per instruction on unpipelined machine

Number of pipe stages

□So, Ideal speedup equal to

Number of pipe stages.







#### Pipeline hazard: the major hurdle

- □ A hazard is a condition that prevents an instruction in the pipe from executing its next scheduled pipe stage
- ☐ Taxonomy of hazard
  - > Structural hazards
    - These are conflicts over hardware resources.
  - > Data hazards
    - Instruction depends on result of prior computation which is not ready (computed or stored) yet
  - > Control hazards
    - branch condition and the branch PC are not available in time to fetch an instruction on the next clock







# What we need to know?

- ■What results in the various hazards?
  - > The causes
  - How to judge whether there is hazard?

☐ The approaches to solve the hazards.

☐ How to evaluate the performance considering the hazards?






# 5-cycle MIPS CPU

Steps	Rtype	lw/sw	beq	j			
Instruction fetch		IR=Mem	ory[PC]				
(IF)		PC=P	C+4				
Instruction decode		A=Re	g[rs]				
and register fetch	B=Reg[rt]						
(ID)		C=PC+(sign-exte	end(imm)<<2	)			
Execution	C=A op B	C=A+	if (A-B)==0	PC=PC[31-28]			
(EXE)		sign-extend(imm)	then PC=C	(address<<2)			
Memory access (MEM)	Reg[rd]=C	lw: DR=Memory[C]					
or Rtype completion (WB)	(WB)						
Memory access		w: Reg[rt]=DR					
completion (WB)		(WB)					





# Pipeline with 1 delay slot and forwarding path and load stall









### Could you write the logic expression?

- ■LoadStall ?
- □FowardA?
- □FowardB?
- □BranchStall?
- ■When and How many stalls? Examples?
- ■Which Forwarding path will be used?
- ☐ How to implement "stall"?

■What if give an 7-stage pipeline?







### Structural hazard: Pipe Stage Contention

#### □Structural hazards


- > Occurs when two or more instructions want to use the same hardware resource in the same cycle
- > Causes bubble (stall) in pipelined machines
- Overcome by replicating hardware resources
  - Multiple accesses to the register file
  - Multiple accesses to memory
  - some functional unit is not fully pipelined.
  - Not fully pipelined functional units







### Split instruction and data memory



Split instruction and data memory / multiple memory port / instruction buffer means:


fetch the instruction and data inference using different hardware resources.







# Multi access to the register file



- □ Simply insert a stall, speedup will be decreased.
- ☐ We can resolve it with "double bump"








# Double Bump Works!

□ allow WRITE-then-READ in one clock cycle (double bump)







# Not fully pipelined function unit: may cause structural hazard

ADDD	IF	ID		ADDD					WB	
ADDD		IF	ID	stall	stall	stall	stall	stall	AD	DD
Not fully pipelined Adder										
ADDD	IF	ID	А	.1	А	.2	Α	.3	WB	
ADDD		IF	ID	stall	А	.1	А	2	А	3

#### Resolved using fully pipelined Adder

ADDD	IF	ID	A1	A2	A3	A4	A5	A6	WB	
ADDD		IF	ID	A1	A2	A3	A4	A5	A6	WB

#### Or multiple unpipelined Float Adder

ADDD	IF	ID		ADDD1	WB	
ADDD		IF	ID	ADDD2		WB







### Data hazard

- □Data dependence = Data hazard?
  - RAW, WAR, WAW

- ☐ How to resolve?
  - > Double bump
  - > Forwarding path
  - > Load stall
  - > Compiler scheduling
  - > Dynamic scheduling, Register renaming





## Data hazard

- Data hazards occur when the pipeline changes the order of read/write accesses to operands comparing with that in sequential executing.
- Let's see an Example

```
DADD R1, R1, R3
```

**DSUB R4**, **R1**, **R5** 

AND R6, R1, R7

OR R8, R1, R9

XOR R10, R1, R11








### Forwarding:reduce data hazard stalls

□ Data may be already computed - just not in the Register File



**EX/MEM.ALUoutput** → **ALU** input port


MEM/WB.ALUoutput → ALU input port







### Hardware Change for Forwarding



→ EX/Mem. ALUoutput → ALU input

MEM/WB.ALUoutput → ALU input


MEM/WB.LMD → ALU input







# Forwarding Doesn't Always Work









# So we have to insert stall: Load stall

Time (clock cycles) sub r4,r1,r6 and r6,r1,r7 Reg r8,r1,r9

5

t



# Example of Forwarding and Load Delay

- Why forwarding?
  - > ADD(R4) R5, R2
  - > LW R15, 0(R4)
  - > SW R15, 4(R2)


- Why load delay?
  - > ADD R4, R5, R2
  - > LW (R15), O(R4)
  - > SW (R15), 4(R2)








# Solution (without forwarding)







# Solution (with forwarding)



EX/MEM.ALUoutput → ALU input port MEM/WB.ALUoutput → DM data write port







# Instruction reordering by compiler to avoid load stall

☐ Try producing fast code for a = b + c; d = e - f: assuming a, b, c, d, e, and f in memory. ☐ Slow code: Fast code: LW Rb,b LW Rb,b Rc,c LW LW Rc,c ADD Ra, Rb, Rc LW Re,e ADD SW a,Ra Ra, Rb, Rc LW Re,e LW Rf,f Rf,f LW a,Ra SW SUB Rd, Re, Rf SUB **SW** d,Rd Rd, Re, Rf



d, Rd



# Deal with Control Hazards

- ☐Flushing the pipeline
- ■Predict-taken
- ■Predict-not-taken
- □ Delayed branch


Resolve the branch as earlier as possible

□ Branch predict, Specluation





# Deal with Control Hazards









# Flushing the pipeline

### □Simplest hardware:

- > Holding or deleting any instruction after branch until the branch destination is know.
- > Penalty is fixed.
- > Can not be reduced by software.






# The pipeline status --flushing

Branch instruction	IF	ID	EX	MEM	WB	100	
Branch Successor		IF	stall	stall	idle	idle	
Branch successor+1					IF	ID	EX
Branch successor+2						IF	ID
Branch successor+3					8		IF






### Move the Branch Computation Forward







# Move the Branch Computation more Forward







### Why "waste" the fetched instruction?

Branch instruction	IF	ID	EX	MEM	WB	100-	E
Branch Successor		(IF)	idle	idle	idle	idle	
Branch successor+1		$\gamma$	ID	EX	MEM	WB	ID
Branch successor+2				ID	EX	MEM	WB
Branch successor+3					ID	EX	MEM

■ We have fetched the instruction 48, why should we waste the delay slot?





# Delayed branch

#### ☐Good news

- > Just 1 cycle to figure out what the right branch address is
- > So, not 2 or 3 cycles of potential NOP or stall

### □Strange news

- > OK, it's always 1 cycle, and we always have to wait
- > And on MIPS, this instruction always executes, no matter whether the branch taken or not taken. (hardware scheme)





## Branch delay slot

☐ Hence the name: branch delay slot

```
branch instruction

sequential successor

sequential successor

...

sequential successor

branch delay slots
```


- The instruction cycle after the branch is used for address calculation, 1 cycle delay necessary
- > 50...we regard this as a free instruction cycle, and we just DO IT
- Consequence
  - You (or your compiler) will need to adjust your code to put some useful work in that "slot", since just putting in a NOP is wasteful (compiler scheme)







# How to adjust the codes?







# Example: rewrite the code (a)

Withou	ıt Branch Delay Slot	With Branch Delay Slot				
Address	s Instruction	Addre	ss Instruction			
36	NOP	36	NOP			
40	ADD R30,R30,R30	- 0	BEQ R1, R3, 28			
44	BEQ R1, 24,	44	ADD R30, R30, R30			
48	AND R12, R2, R5	48	AND R12, R2, R5			
52	OR R13, R6, R2	52	OR R13, R6, R2			
56	ADD R14, R2, R2	56	ADD R14, R2, R2			
60		60	•••			
64	•••	64	•••			
68	***	68	F100			
72	LW R4, 50(R7)	72	LW R4, 50(R7)			
76	•••	76	•••			

- □ Flow of instructions if branch is taken: 36, 40, 44, 72, ...
- □ Flow of instructions if branch is not taken: 36, 40, 44, 48, ...







# Example: rewrite the code (b-1)

Loop: LW R2, 0(R1) ADD R3, R2, R4 SW R3, 0(R1) SUB R1, R1, #4 BNEZ R1, Loop

LW R2, 0(R1) Loop: ADD R3, R2, R4 R3, 0(R1) SW SUB R1,R1, #4 BNEZ R1, Loop R2, 0(R1)





# Example: rewrite the code (b-2)


```
Loop: LW R2, 0(R1)
     ADD R3, R2, R4
         R3, 0(R1)
     SW
     DIV
     SUB R1, R1, #4
     BNEZ R1, Loop
```

```
Loop: LW R2, 0(R1)
     ADD R3, R2, R4
     DIV
     SUB R1, R1, #4
     BNEZ R1, Loop
     SW R3, +4(R1)
```






# MIPS Pipeline



























### Load stall even with forwarding path




To stall the pipeline, we can generate two signals (WritePC and WriteIR) to disable the writing to PC and the ID pipeline register (IR and PC+4).







#### Pipeline with 3 branch delay slot










#### Pipeline with 2 branch delay slot










### Pipeline with 1 branch delay slot










# Pipeline with 1 delay slot and forwarding path and load stall










### Still need to stall sometime








## THE

### Move forwarding to ID









# Extending 5-MIPS pipeline to deal with multi-cycle operations

□ Is there WAR hazard or WAW hazard?

□Could you judge when and what hazard?





#### you clear about these terms?

#### 36 terms of Cache

Cache Virtual memory

data cache Instruction cache unified cache

block page tag field

Block address index field block offset

full associative set associative direct mapped

n-way set associative set address trace

misses per instruction Memory stall cycles miss penalty

Valid bit dirty bit locality

cache hit hit time

cache miss miss rate page fault

Write through write back write allocate

random replacement least-recently used no-write allocate

Average memory access time write buffer write stall





## Memory Hierarchy (C.1)

- What's Memory hierarchy? Why?
- ☐ Basic four questions for Memory Hierarchy
  - Block placement
    - Relations among direct mapped, set associate, full associate
  - Block identification
    - Structure description ← → graph?
    - Could you break the Physical Address down to Tag/ Index / block offset ?
  - > Replacement
    - RAND, LRU, FIFO
  - Write strategy
    - Write through / write back
    - Write allocate / No write allocate





### Memory Hierarchy (cont.)

#### What's the difference between cache and Virtual memory?

- □ Cache ← L2 cache, memory
- Line( block)
- Direct mapped/set/full associate
- Pseudo RAND/ LRU / FIFO
- Write through / write back
- Hardware
- CPU Stall waiting for miss
- Aim at Memory Speed
- .....

- □ Physical Memory ←VM
- □ Page / segment
- ☐ Full associate
- LRU
- Write back
- TLB & software ( page table )
- Interrupt while page fault
- □ Aim at Memory Size

What's TLB? Can we call it a cache? What are included in a TLB entry?







#### Cache Performance

- ■What metric is used to evaluate cache performance?
  - Miss Rate? AMAT? CPU time?
- ■How to calculate AMAT ? (examples )
- □ How to calculate CPUtime taking into account of memory system?

What's the difference between Miss Rate and Misses per instruction?







# How to Improve Cache Performance?

- □3C model (C.3)
  - Compulsory
  - Capacity
  - ➤ Conflict
- □4<sup>th</sup> C –Coherency (4.3)
  - > Truth sharing miss
  - > False sharing miss





# How to Improve Cache Performance? (C.3, 5.2)

- Reduce the time to hit in the cache.--4
   —small and simple caches, avoiding address translation, way prediction, and trace caches

   Increase cache bandwidth .--3
- Increase cache bandwidth .--3
   —— pipelined cache access, multibanked caches, non-blocking caches,
- 3. Reduce the miss penalty--4
  ——multilevel caches, critical word first, read miss prior to writes, merging write buffers, and victim caches
- 4. Reduce the miss rate--4
  ——larger block size, large cache size, higher associativity, and compiler optimizations
- associativity, and compiler optimizations
  5. Reduce the miss penalty and miss rate via parallelism--2
  —hardware prefetching, and compiler prefetching







### Memory Technology

- What's difference between DRAM & SRAM ?
- Memory organization
  - Wider memory
  - Simple interleaved memory
  - Independent memory banks
  - Avoiding Memory Bank Conflicts (complier / Hardware)
- Memory chip
  - FPM (Fast Page Mode DRAM)
  - Synchronize DRAM
  - DDR ( Double Date Rate )
  - > RDRAM





### Multiprocessor

- ☐ Catalogue the Parallel (MIMD) processors
  - Centralized shared memory / Distributed memory multi-processor
  - Pros vs. Cons
- concepts
  - SMP / DSM / CSM / Multiple computer
  - > UMA / NUMA
  - > SPP / MPP
- Communication Model
  - Share memory
  - Message passing





#### Cache coherence

- What's cache coherence ?
  - Write serialization
- Snooping protocol
  - Write Invalidate / Write update
  - What's the difference between them?
  - State machine
- Directory-based protocol
  - Status machine (cache block, directory) (case 4.16)

