METHOD

One fuel plan, from supply to flight

Choose your route and solve procurement, transport, airport stocks and aircraft uplift in one calculation.

Scenario data

Airport coordinates come from public data. Prices, supplier and transport capacities, stocks and aircraft inputs are generated assumptions that you can edit. Imported quotations provide another price input to the same model.

1 Choose your route

Choose the departure and destination, then add stops for a continuous route of 1–5 legs. Each departure is one planning stage. The airport order stays fixed while the model decides how fuel moves through the whole chain. An example route is available separately.

2 Set the supply conditions

Generate the route inputs, then adjust supplier capacity, transport cost and lead stages, opening airport stock and storage limits. Set the aircraft profile, starting fuel and reserves in the same form. Repeated visits to an airport draw on the same stock pool.

3 Calculate once

The calculation connects supplier purchases to transport arrivals, airport stock and aircraft uplift. Fuel must arrive before it can be loaded. Supplier and route capacities, storage, airport reserves and aircraft fuel and weight limits are enforced together. Transport lead times are counted in departure stages.

4 Read the complete plan

Follow quantities from each supplier to each airport and flight leg. The cost breakdown separates procurement, freight, handling, stock holding, into-plane service and applicable adjustments. Compare aircraft uplift and extra burn with a minimum-uplift baseline that uses the same supply network and starting and final stocks.

5 Use your own quotations

Import dated, fee-inclusive into-plane offers in USD per metric tonne and choose the flight date. The quoted price enters procurement directly, so modeled upstream and service fees are not added again. Supply, storage and aircraft constraints still apply. Export the complete inputs and plan to keep the calculation.

Compare like with like

The baseline loads only the fuel needed for each flight leg while optimizing upstream supply under the same constraints. Both plans use the same final aircraft fuel and airport-stock targets. If the baseline cannot be served, inspect the limiting conditions first. Extra carriage fuel is already included in the purchase quantities.

Replace inputs with operational data

Data used by the connected model

Input	Source	Use in the model
Prices and supply rights	Supplier offers, contracts and invoices	Set procurement prices, valid dates, fee coverage and allocated volumes.
Aircraft performance	Operator flight-planning and performance data	Set burn, reserves, payload, weight limits and the extra-weight fuel penalty.
Transport and airport stocks	Logistics operators, fuel operators and delivery schedules	Set delivery capacity and lead stages, usable opening stock, storage space and stock targets.
Market background	Public energy prices, exchange rates and national balances	Inform scenario assumptions and market comparisons in the Data tab.

Change one constraint and compare

Reduce one supplier’s capacity, delay a delivery or raise an airport’s reserve target. Calculate again and see how procurement, stock and uplift change together. The same result also shows the fuel burned to carry extra fuel.

Updated 13 November 2026